# NASA Contractor Report 3442

A Computer Code for Swirling
Turbulent Axisymmetric
Recirculating Flows in Practical
Isothermal Combustor Geometries

D. G. Lilley and D. L. Rhode

GRANT NAG 3-74 FEBRUARY 1982



# A Computer Code for Swirling Turbulent Axisymmetric Recirculating Flows in Practical Isothermal Combustor Geometries

D. G. Lilley and D. L. Rhode Oklahoma State University Stillwater, Oklahoma

Prepared for Lewis Research Center under Grant NAG 3-74



Scientific and Technical Information Branch

	CONTENTS		
1.	INTRODUCTION	1	
	1.1 The Problem	1	
	1.2 Previous Work	3	
	1.3 Outline of the Present Contribution	4	
2.	THE MATHEMATICAL PROBLEM	6	
	2.1 The Governing Equations	6	
	2.2 The Solution Technique and Finite Difference Formulation	9	
	2.3 Boundary Conditions	17	
	2.4 Wall Functions and the Effect of Swirl	23	
	2.5 Boundary Conditions Summary	28	
	2.6 Solution Procedure	30	
3.	THE STARPIC COMPUTER PROGRAM	34	
	3.1 Outstanding Features	34	
	3.2 The MAIN Subprogram	40	
	3.3 Subroutine INIT	43	
	3.4 Subroutine PROPS	43	
	3.5 Subroutines CALCU and CALCV	47	
	3.6 Subroutine CALCP	48	
	3.7 The Other CALC Subroutines	49	
	3.8 Subroutine LISOLV	50	
	3.9 Subroutine PRINT	51	
	3.10 Subroutine PROMOD	51	
	3.11 Subroutine STRMFN	55	
	3.12 Subroutine PLOT	56	

4.	USER'S GUIDE				
	4.1 Problem Specification				
	4.2	Iteration and Accuracy	61		
	4.3	The Sample Computation	64		
5.	CLOS	67			
6.	6. REFERENCES				
7.	NOMENCLATURE				
	APPENDICES				
	Α.	Derivation of the Hybrid Differencing Scheme	74		
	В.	Derivation of Eq. (A7) from Eq. (A6)	80		
	С.	The Superiority of the Hybrid Differencing Scheme	81		
	D.	Fortran Symbol List	86		
	Ε.	Computer Program Listing	97		

### 1. INTRODUCTION

### 1.1 The Problem

In combustion chamber development, designers are aided by experiments but, as a supplement to them, economical design and operation can be greatly facilitated by the availability of prior predictions of the flowfield. These may be obtained by use of a mathematical model incorporating a numerical finite difference prediction procedure. This work combines the rapidly developing fields of theoretical combustion aerodynamics and computational fluid dynamics, and its improvement and use will significantly increase understanding and reduce the time and cost of development. 1-6

The present research work is concerned with complementary experimental and theoretical studies and is described in a recent paper. The problem being investigated is restricted to steady turbulent flow in axisymmetric geometries, under low speed and nonreacting conditions - a study area highlighted recently  $^{8-10}$  as a fundamental research requirement in combustion modeling. The particular problem is concerned with turbulent flow of a given turbulence distribution in a round pipe entering an expansion into another round pipe, as illustrated in Fig. 1. The in-coming flow may possess a swirl component of velocity via passage through swirl vanes at angle  $\phi$ [equal approximately to  $\tan^{-1}(w_{in}/u_{in})$ ], and the side-wall may slope at an angle lpha, to the main flow direction. The resulting flowfield domain may possess a central toroidal recirculation zone CTRZ in the middle of the region on the axis, in addition to the possibility of a corner recirculation zone CRZ near the upper corner provoked by the rather sudden enlargement of the crosssectional area. Of vital concern is the characterization of flows of this type in terms of the effects of side-wall angle  $\alpha$ , degree of swirl  $\phi$ , turbulence intensity  $k_{in}$  of the inlet stream and expansion ratio D/d  $\underline{on}$  the resulting flowfield in terms of its time-mean and turbulence quantities.




Fig. 1. The flowfield being investigated.

Such problems have received little attention, yet there is a definite need for work in this area even under nonreacting flow conditions.

The objective of the present document is to present details of the computational solution procedure which has been developed to perform the prediction function in the configuration just described. The finally developed computer program (written in Fortran 4) is code-named STARPIC (mnemonic for swirling turbulent axisymmetric recirculating flows in practical isothermal combustor geometries) and it is the purpose of this document to serve as a user's manual and describe it in sufficient detail for it to be used and amended by persons whose interest is confined more to the basis and results of the computations.

### 1.2 Previous Work

A mathematical solution of the flowfield of interest should provide results, if possible more cheaply, quickly, and correctly than possible by other means (for example, experiments on real-life systems or models). In order to achieve this, the model should simulate the flow in all its important respects (geometry, boundary conditions, physical properties of gases, turbulence, etc.) and provide a means whereby the governing equations may be solved. Mathematical models of steadily increasing realism and refinement are now being developed, both in the dimensionality of the model (together with the computational procedures) and in problems associated with the simulation of the physical processes occurring. Clearly there are two areas of difficulty: the simulation and solution.

Several previous publications discuss these problems at length, in terms of practical application,  $^5$ ,  $^6$  turbulence modeling  $^{11}$ ,  $^{12}$  and numerical solution of 2-D axisymmetric problems via the stream function  $\sim$  vorticity or primitive pressure  $\sim$  velocity approach.  $^{13-15}$  Whereas the former approach, used in the 1968 computer program from Imperial College for example  $^{16}$ , reduces by one

the number of equations to be solved and eliminates the troublesome pressure (at the expense of trouble with the vorticity equation), the preferred approach now is SIMPLE (mnemonic for <u>semi-implicit method</u> for <u>pressure linked equations</u>) which focuses attention directly on the latter variables. Because it possesses many advantages, the present work has been developed immediately on this new technique, the basic ideas of which have been embodied into the latter variables. Imperial College TEACH ( $\underline{t}$ eaching  $\underline{e}$ lliptic  $\underline{a}$ xisymmetric  $\underline{c}$ haracteristics  $\underline{h}$ euristically) computer program. Advances to this code have been made elsewhere and applied to other  $2-D^{18-25}$  and  $3-D^{26-29}$  problems of interest to the combustor designer.

### 1.3 Outline of the Present Contribution

The present document serves as a user's manual for the STARPIC computer program, with three subsequent major sections dealing with the basic ideas, the computer program and the user's guide. Consideration is given to recent work in the finite difference solution, via a primitive variable code, of axisymmetric swirl flow in the combustor geometry of Fig. 1, where the inlet expansion sidewall may slope obliquely to the central axis. Section 2 describes the mathematical problem, by providing the basic equations and assumptions for the flow, and discussing the primitive variable solution technique to be used. Section 3 concerns itself with the organization and structure of the computer program. Sub-sections of the program are here described and linked with the equations previously noted in the text; and explanations are given of the special features of the program. Readers primarily interested in using the program, without concerning themselves greatly with the computational details, can give their main attention to Section 4. This is a user's guide to the program and the emphasis is on those parts of the program which will require alteration to suit particular flow configurations, to obtain the desired output, to test for accuracy and to improve it when necessary. Appendices are provided dealing with the hydrid differencing scheme and reasons for its superiority, a Fortran symbol list, a listing of the STARPIC computer program, The program output is included in a microfiche supplement at the back of the report.

### 2. THE MATHEMATICAL PROBLEM

### 2.1 The Governing Equations

The turbulent Reynolds equations for conservation of mass, momentum (in x, y and  $\theta$  directions), turbulence energy k and turbulence dissipation rate  $\epsilon$ , which govern the 2-D axisymmetric, swirling, steady flow may be taken as previously. 19-15 The transport equations are all similar and contain terms for convection and diffusion (via turbulent flux terms) and source  $S_{\varphi}$  of a general variable (which contains terms describing the generation (creation) and consumption (dissipation) of  $\varphi$ ). Introducing turbulent exchange coefficients and the usual turbulent diffusion-flux (stress  $\sim$  rate of strain type) laws, it can be shown that the similarity between the differential equations and their diffusion relations allows them all to be put in the common form:

$$\frac{1}{r} \left[ \frac{\partial}{\partial x} \left( \rho u r \phi \right) + \frac{\partial}{\partial r} \left( \rho v r \phi \right) - \frac{\partial}{\partial x} \left( r \Gamma_{\phi} \frac{\partial \phi}{\partial x} \right) - \frac{\partial}{\partial r} \left( r \Gamma_{\phi} \frac{\partial \phi}{\partial r} \right) \right] = S_{\phi}$$
 (1)

for  $\phi$  = 1 (continuity equation), u, v, w (three velocity components), k and  $\epsilon$  (two turbulence quantities). The forms for the source term  $S_{\varphi}$  are given in Table 1, where certain quantities are defined as follows:

$$S^{U} = \frac{\partial}{\partial x} \left( \mu \frac{\partial u}{\partial x} \right) + \frac{1}{r} \frac{\partial}{\partial r} \left( r \mu \frac{\partial v}{\partial x} \right)$$
 (2)

$$S^{V} = \frac{\partial}{\partial x} \left( \mu \frac{\partial u}{\partial r} \right) + \frac{1}{r} \frac{\partial}{\partial r} \left( r \mu \frac{\partial v}{\partial r} \right)$$
 (3)

$$G = \mu \left[ 2 \left\{ \left( \frac{\partial u}{\partial x} \right)^{2} + \left( \frac{\partial v}{\partial r} \right)^{2} + \left( \frac{v}{r} \right)^{2} \right\} + \left( \frac{\partial u}{\partial r} + \frac{\partial v}{\partial x} \right)^{2} + \left\{ r \frac{\partial}{\partial r} \left( w/r \right) \right\}^{2} + \left( \frac{\partial w}{\partial x} \right)^{2} \right]$$
(4)

Implicit here is the use of the two-equations  $k-\epsilon$  turbulence model 11,12

Table 1. The Form of the Source Term in the General Equation for  $\varphi$  (Eq. (1))

ф	Sφ
u	$-\frac{\partial x}{\partial p} + S^{u}$
v	$-\frac{\partial p}{\partial r} + \frac{\rho w^2}{r} - \frac{2\mu v}{r^2} + S^{V}$
w	$-\frac{\rho vw}{r}-\frac{w}{r^2}\frac{\partial}{\partial r}(r\mu)$
k	G - C <sub>D</sub> ρε
ε	(C <sub>1</sub> εG - C <sub>2</sub> ρε²)/k

$$\mu = C_{\mu} \rho k^2 / \varepsilon + \mu_{\ell}$$
 (5)

$$\Gamma_{\phi} = \mu/\sigma_{\phi} \tag{6}$$

which is commonly used in computer codes for turbulent flow prediction.

These equations have to be solved for the time-mean pressure p and velocity components u, v, and w. Then other useful designer information like streamline plots showing breakaway and reattachment points, recirculation zones and stagnation points are easily produced. Streamline plots are obtained from the dimensionless stream function which is given by

$$\psi^* = \int_0^r \operatorname{urdr} / \int_0^{d/2} \operatorname{urdr}$$
 (7)

This quantity is calculated for all u-cells, and the coordinates of points constituting each of eleven streamlines ( $\psi^*$  = 0.0 through  $\psi^*$  = 1.0) is stored for plotting. Earlier publications<sup>17-21</sup> provide details of the present simulation and solution technique, and only highlights of the primitive-variable approach need be given here in the context of the specific problem being investigated.

All the linkages provide a high degree of non-linearity in the total problem, and given the numerical analysis of fluid flow its peculiar difficulty and flavor. The above equations do not alone specify the problem; additional information of two kinds is needed: initial and boundary conditions for all the dependent variables. Details of this are given in Section 2.3. The difficulties in solution spring mainly from the interlinkages between the  $\varphi$ 's. Those between the axial and radial velocity components are of a peculiar kind, each containing an unknown pressure

gradient and the components are linked additionally by another equation, that of mass conservation, in which pressure does not appear. A successful solution procedure is one which takes account of these interactions and ensures that successive adjustments, which must be made to one variable after another, form an involuntary convergent sequence.

## 2.2 The Solution Technique and Finite Difference Formulation

Solution may be via the stream function-vorticity or primitive pressure-velocity approach, and, as discussed in Section 1.2, the present solution technique is based on the latter. The basic TEACH computer program using SIMPLE with TDMA provides the starting point upon which the present work is based.<sup>17</sup> The following features are incorporated into the program:

- (i) a finite difference procedure is used in which the dependent variables are the velocity components and pressure;
- (ii) the pressure is deduced from an equation which is obtained by the combination of the continuity equation and the momenta equations (yielding a new form of what is known in the literature as the Poisson equation for pressure);
- (iii) the idea is present at each iteration of a first approximation of u, v, and p followed by a succeeding correction;
- (iv) the procedure incorporates displaced grids for the axial and radial velocities u and v, which are placed between the nodes where pressure p and other variables are stored; and
- (v) an implicity line-by-line relaxation technique is employed in the solution procedure (requiring a tridiagonal matrix to be inverted in order to update a variable at all points along a column), using the TDMA (tri-diagonal matrix algorithm).

The incorporation of these enhances the accuracy and rapidity of convergence


of the finally developed computer program.

The finite difference equations are solved on a complex mesh illustrated in Fig. 2. The intersections, the point P for example, of the solid lines mark the grid nodes where all variables except the u and v velocity components are stored. The latter are stored at points which are denoted by arrows (and labeled w and s respectively) located midway between the grid intersections, and the boomerang-shaped envelope encloses a triad of points with reference location P at (I,J). Details of the special merits of this staggered grid system have been reported previously!<sup>7,18</sup> The different control volumes C, U and V which are appropriate for the P, w and s locations respectively are given in Fig. 3.

The finite difference equations for each  $\phi$  are obtained by integrating Eq. (1) over the appropriate control volume (centered about the location of  $\phi$ ) and expressing the result in terms of neighboring grid point values. The convection and diffusion terms become surface integrals of the convection and diffusive fluxes while the source term is linearized, resulting in

where  $S_p^\varphi$  and  $S_U^\varphi$  are tabulated in Table 2 and subscripts n, s, e and w refer to north, south, east and west cell faces.

The additional source terms in the equations for swirling flows may induce instability if one is not careful. Only terms which are always negative are permitted in the SP(I,J) expression in order to aid the convergence of the iterative solution procedure by increasing the diagonal dominance of the equation set to be solved at each iteration. Inspection of the arrangement given in Table 2 reveals that the forms given enjoy this desirable stabilizing



THREE GRIDS: FOR p, w ETC. - AT POSITION MARKED (O)

FOR u VELOCITY - AT POSITION MARKED (-)

FOR v VELOCITY - AT POSITION MARKED ( !)

Fig. 2. Staggered grid and notation for the rectangular computational mesh.




Fig. 3. The three control volumes associated with points of the three grids.

12

Table 2. The Form of the Components of the Linearized Source Term\*, The Cell Volume Integral  $\int_V S_\phi dV = S_p^{\phi} \phi_p + S_U^{\phi}$  of Eq. (1).

φ	Г	S <sub>p</sub> Ø/V	S <sub>U</sub> Ø/V
Ψ	ф	p / •	3 <sub>U</sub> / •
1	0	0	0
u	μ	0	$S^{u} - \frac{\partial P}{\partial x}$
v	μ.	$-2\frac{\mu}{r^2}$	$S^{V} + \frac{\rho w^2}{r} - \frac{\partial P}{\partial r}$
W	μ	0	$-\frac{\rho vw}{r}-\frac{w}{r^2}\frac{\partial}{\partial r}(r\mu)$
k	μ/σ <sub>k</sub>	$-C_{\mu}C_{D}\rho^{2}k/\mu$	G
ε	μ/σ <sub>ε</sub>	-C <sub>2</sub> ρε/k	$C_1 C_{\mu} G_{\rho} k/\mu$
		·	

In this table certain quantities are defined as follows:

$$S^{U} = \frac{\partial}{\partial x} \left( \mu \frac{\partial u}{\partial x} \right) + \frac{1}{r} \frac{\partial}{\partial r} \left( r \mu \frac{\partial v}{\partial x} \right)$$

$$S^{V} = \frac{\partial}{\partial x} \left( \mu \frac{\partial u}{\partial r} \right) + \frac{1}{r} \frac{\partial}{\partial r} \left( r \mu \frac{\partial v}{\partial r} \right)$$

$$G = \mu \left[ 2 \left\{ \left( \frac{\partial u}{\partial x} \right)^{2} + \left( \frac{\partial v}{\partial r} \right)^{2} + \left( \frac{v}{r} \right)^{2} \right\} + \left( \frac{\partial u}{\partial r} + \frac{\partial v}{\partial x} \right)^{2} + \left( \frac{\partial w}{\partial r} \right)^{2} \right]$$

$$+ \left[ \left\{ r \frac{\partial}{\partial r} \left( \frac{w}{r} \right) \right\}^{2} + \left( \frac{\partial w}{\partial x} \right)^{2} \right]$$

<sup>\*</sup>In this table, V stands for the cell control volume and  $\mu$  =  $\mu_{\mbox{eff}}.$ 

characteristics. A false source stabilizing trick, which has no effect on the final solution, is used in the form of a false source of magnitude:

$$S_{\text{false}} = |\mathring{m}_{\text{net}}| (\phi_{\text{p}}^{\text{old}} - \phi_{\text{p}})$$
 (9)

That is used in the program although not detailed in Table 2.

For the representation of the convective and diffusive terms over the cell control volume surfaces a hybrid scheme is used,  $^{30}$  which is a combination of the so-called central and upwind differences. Consider the transport across one face of a control volume. Figure 4 shows the western face of area  $A_W$  normal to the x-direction, which lies midway between the grid-points W and P distant  $\delta x$  apart. The contribution  $c_W$  to the surface integral by the western face area  $A_W$ , for example, is given by

$$C = \begin{cases} (\rho u)_{W} A_{W} (\phi_{W} + \phi_{P})/2 - (\frac{\Gamma}{\phi})_{W} A_{W} (\phi_{P} - \phi_{W})/\delta x \text{ for } |Pe| < 2 \\ (\rho u)_{W} A_{W} \phi_{W} \text{ for } Pe \ge 2 \\ (\rho u)_{W} A_{W} \phi_{P} \text{ for } Pe \le -2 \end{cases}$$

$$(10)$$

where  $Pe = (\rho u)_W \delta x/(\Gamma_{\phi})_W$  is a cell Peclet number calculated at the western face of the cell. Similar expressions are used at the other three faces of the cell. Details regarding the derivation and superiority of this differencing technique may be found in Appendixes A, B and C.

When the various terms are handled in this manner the following general equation is obtained:

$$a_{\mathbf{p}}^{\phi} \phi_{\mathbf{p}} = a_{\mathbf{j}}^{\phi} \phi_{\mathbf{j}} + S_{\mathbf{U}}^{\phi} \tag{11}$$

where 
$$a_p^{\varphi} = \sum_{i} a_j^{\varphi} - S_p^{\varphi}$$

 $\Sigma_{\mathbf{i}}$  = sum over N, S, E and W neighbors

thus linking each  $\phi$ -value at a point P with its four neighboring values.




Fig. 4. One face of a control volume across which convective and diffusive fluxes are considered.

When  $\phi$  = W, k and  $\epsilon$ , equations of this type hold for values located at intersections of the grid system, but for  $\phi$  = u and v there are two points of difference: (i) these variables are located to the west and south respectively of the point P and (ii) pressure gradient terms  $\partial p/\partial x$  and  $\partial p/\partial r$  respectively occur on the right hand side of their equations in addition to the usual source expression. Since the pressure field is not known when the u and v equations are required to be used at any stage of the iteration process, the best estimate so far of the pressure field p\* is used. Solving the u and v equations with this p\* field gives estimates u\* and v\* in the flowfield. These p\*, u\* and v\* fields constitute any any iteration stage a first approximation to the solution and they are immediately followed by a succeeding correction at each point P:

$$p_p = p_p^* + p_p' \tag{12}$$

$$u_p = u_p^* + D^u(p_W^! - p_P^!)$$
 (13)

$$v_p = v_p^* + D^V(p_S^! - p_P^!)$$
 (14)

where 
$$D^{U} = A_{W}/a_{P}^{U}$$

$$D^{V} = \frac{1}{2}(A_{n} + A_{s})/a_{p}^{V}$$

These corrections can be applied only after the pressure correction p' field has been found and this is obtained from a Poisson equation for pressure which may be deduced from a combination of the continuity and momentum equations, resulting in finite difference equations like

$$a_{p}^{p} p_{p}^{i} = \sum_{j} a_{j}^{p} p_{j}^{i} + S_{U}^{p}$$
 (15)

where 
$$a_p^p = \sum_j a_j^p$$
  
 $\sum_j$  = sum over N, S, E and W neighbors

 $S_{II}^{p}$  = term which results from mass sources of u\* and v\* fields.

Thus the application of Eqs. (13) and (14) at any iteration stage brings the first approximation obtained from solution of momentum equations into line with the requirement of continuity - it is here where the continuity equation is used, incorporated in fact in the derivation of the equation for p', Eq. (15).

### 2.3 Boundary Conditions

There are several methods of numerically positioning an irregular boundary, such as a sloping boundary segment, in finite difference computer programs. In order to retain conceptual simplicity, the stairstep simulation shown in Fig. 5 is utilized. The figure shows an example of grid specification for the geometry under consideration. The flowfield is covered with a nonuniform rectangular grid system. Typically the boundary of the solution domain falls halfway between its immediate nearby parallel gridlines. Clearly, specification of the x and r coordinates of the gridlines, together with information concerned with the position of the sloping sidewall boundary (via specification of JMAX(I) for each I) is sufficient to determine the flowfield of interest.

Up to this point the application of boundary conditions has not yet been considered, and the formulation has been concerned with regular internal mesh points. Insertion of correct boundary conditions requires amendment of the finite difference formulation for the near boundary points. 16 For cells




Fig. 5. An example of a grid system being employed to fit the flow domain.

adjacent to the west wall for example, as shown in Fig. 6, there is no convective flux through the cell west boundary which is coincident with an impervious wall. Hence the term for total  $\phi$ -flux through this cell boundary in Eq. (8) is set to zero, and the diffusive flux term  $\Gamma_{\phi}$   $\partial \phi/\partial x$  is transferred to the right-hand side of the equation as a false source. In the case of a western wall boundary the normal P-W link is broken by setting:

$$\mathbf{a}_{ld}^{\Phi} = \mathbf{0} \tag{16}$$

and the correct expression is inserted by way of the  $S_U^\varphi$  and  $S_P^\varphi$  values:

(i) If a value M for the diffusion terms  $\Gamma_{\phi}$   $\partial \phi/\partial x$  is specified for the western face of a cell adjacent to a western wall, then as seen in Eq. (8):

$$S_{II}^{\varphi} = -M/Vol \tag{17}$$

$$S_{p}^{\phi} = 0 \tag{18}$$

It is clear that this specification results in correct  $\phi$  balance for the boundary cell, and that if zero normal gradient is the required condition (M = 0) then Eq. (16) is sufficient in itself.

(ii) If the value of  $\varphi$  on the boundary  $\varphi_B$  is specified, for a western boundary for example, then:

$$S_{U}^{\phi} = a_{W}^{\dagger} \phi_{B} \tag{19}$$

$$S_{D}^{\phi} = -a_{W}^{\dagger} \tag{20}$$

where

$$a_W' = (\Gamma_{\Phi})_W A_W / \delta x$$

It is clear that this specification gives the correct gradientdiffusion flux out of the western boundary of the cell. (iii) If  $\varphi_{p}$  is required to be fixed at a value of  $\varphi_{F}$  then:

$$S_U^{\phi} = \phi_F^{10^{30}}$$
 (21)

$$S_{D}^{\phi} = -10^{30} \tag{22}$$

to that these terms dominate in the equation for  $\varphi_p$  with solution  $\varphi_p$  =  $\varphi_F.$ 

- (iv) Velocities tangential to a wall boundary usually have boundary conditions of the type  $v_B$  given,  $\tau_B$  ( = tangential shear stress) given, or  $\tau_B = \alpha v_p + \beta$  (from drag law for example). Any of these may be inserted by the usual treatment (break link and insert via linearized source).
- (v) Velocities normal to a wall boundary are given zero values on the wall, but because this leads to incorrect gradient calculations for the first interior point away from the wall, zero normal gradient conditions are applied via breaking the appropriate coupling coefficient in the finite difference equation for this first interior point.

The above discussion about boundary condition types (i) - (v) has been concerned with a western wall boundary shown in Fig. 6. Analogous discussion is appropriate with a northern wall boundary shown in Fig. 7.

Conditions must be specified on the entire boundary around the solution domain, and special novelties concern the pressure correction p', velocity components and the two turbulence quantities k and  $\varepsilon$ . At the inlets all variables are given definite fixed values (Dirichlet conditions) and at the outlet all variables are given zero normal gradient  $\partial \phi/\partial x = 0$  (Neumann conditions) via

$$a_{\mathsf{F}}^{\varphi} = 0 \tag{23}$$

except radial velocity v which is set to zero.




Fig. 6. Wall  $\phi$ -value prescription for western wall.




Fig. 7. Wall  $\phi$ -value prescription for northern wall.

The u velocities are then readjusted slightly at each iteration so as to ensure overall mass conservation as compared with the inlet flow. At the symmetry axis  $\partial \phi/\partial r=0$  is assumed for all variables except v (which is given a definite zero value) and w (which is given an implied zero value as follows. Based on measurements<sup>31</sup> of swirl velocity, the BC for w along the centerline specifies solid body rotation through linear interpolation of w(I,2) between the latest value of w(I,3) and zero for w on the centerline. Also p' is given zero normal gradient specification everywhere except at the inlet, where it has zero value: as far as the aerodynamics is concerned it is immaterial what the absolute pressure is, only pressure gradients entering the equations.

### 2.4 Wall Functions and the Effect of Swirl

To avoid the need for detailed calculations in the nearwall regions, equations are introduced to link velocities, k and  $\varepsilon$  on the wall to those in the logarithmic region. This one-dimensional Couette flow characterization of the flow (diffusion perpendicular to the wall is dominant) is extremely useful. Also it provides a way around this region of steep nonlinear variation of the variables and the fact that laminar and turbulent effects become of the same order of magnitude. The new equations introduced, called 'wall functions', are introduced and used in the finite difference calculations at near-wall points. They occur in the momenta equations and k-generation terms, and their implementation is discussed elsewhere 11,12 together with appropriate near-wall  $\varepsilon$  specification.

The effect of swirl on wall function specification is handled as follows: The previous ideas are extended to find <u>total</u> tangential wall shear stress near boundaries [involving x and  $\theta$  directions for an r = constant wall, and r and  $\theta$  directions for an x = constant wall]. Then appropriate

components are deduced directly [for the u and w velocities which are tangential to an r = constant wall, and v and w velocities which are tangential to an x = constant wall]. The effects on u, v and w momentum equations are incorporated via the usual linearized source technique.

Northern Wall. The applicability of wall function formulations for swirl flows, especially for swirl momentum, appears uncertain a priori. However, from boundary layer velocity measuremeths in turbulent, swirling, pipe flows Backshall and Landis<sup>31</sup> showed that total tangential velocity near the northern top wall  $V = (u^2 + w^2)^{1/2}$  is correlated by the universal velocity profile

$$V^{+} = (1/\kappa) \ln (E Y^{+})$$
 (24)

where  $\kappa$  and E are constants. The dimensionless total velocity V<sup>+</sup> and total distance Y<sup>+</sup> are obtained by nondimensionalizing with respect to the total shear velocity  $(\tau_t/\rho)^{1/2}$ . Hence the total tangential north wall shear stress  $\tau_t = (\tau_{rx}^2 + \tau_{r\theta}^2)^{1/2}$  is obtained from

$$V(\tau_{\mathbf{k}}\rho)^{\frac{1}{2}}/\tau_{\mathbf{t}} = (1/\kappa) \ln[Ey(\tau_{\mathbf{k}}/\rho)^{\frac{1}{2}}/\nu]$$
 (25)

where  $\tau_k$  is an approximation for  $\tau_t$  very near the wall. The quantity  $\tau_k$  is formulated by observing that convection and diffusion of turbulence kinetic energy are nearly always negligible in this region. Deleting these terms from the k-transport equation and invoking isotropic viscosity  $\mu_{eff}$  leads to the result

$$\tau_{\mathbf{k}} = (C_{\mathbf{D}} C_{\mathbf{u}})^{\frac{1}{2}} \rho \mathbf{k} \tag{26}$$

Thus one obtains

$$\tau_{t} = -V_{p} \kappa \rho C_{u}^{\frac{1}{4}} C_{D}^{\frac{1}{4}} k_{p}^{\frac{1}{2}} / \ln(E Y_{p}^{+})$$
 (27)

where the negative sign is inserted since  $\tau_t$  and  $V_p$  must have opposite directions. The quantities with subscript P are evaluated at the appropriate near-wall points as shown in Fig. 7 for this case of a northern wall.

The north wall diffusion flux for the x-momentum equation is  $\mu_{\mbox{eff}} \ \mbox{3u/3r.} \ \ \mbox{The} \ \tau_{\mbox{rx}} \ \mbox{component of} \ \tau_{\mbox{t}} \ \mbox{is given by}$ 

$$\tau_{rx} = \mu_{eff} \left( \frac{\partial u}{\partial r} + \frac{\partial v}{\partial x} \right) \tag{28}$$

however  $\partial v/\partial x$  approaches zero near the north wall. Hence  $\tau_{rx}$  is the required diffusion flux term to be included as a false source for north wall u-cells; its wall function expression asserts the required boundary influence by indirectly incorporating the boundary condition  $u_B = 0$ . The above wall function formulation, Eq. (27), is multiplied by the factor  $\cos \theta$  (= u/V) to obtain  $\tau_{rx}$ . Where  $\theta$  is the angle between the total tangential velocity vector near the wall and the axial velocity vector ( $\theta$  = arctan w/u). This is valid since  $\theta$  is essentially constant near the wall. Thus this wall function for u is

$$\mu_{\text{eff}} \frac{\partial \mathbf{u}}{\partial \mathbf{r}} = \left[ -\kappa \rho C_{\mu}^{\frac{1}{4}} C_{\mathbf{D}}^{\frac{1}{4}} \mathbf{k}_{\mathbf{p}}^{\frac{1}{2}} / \ln(\mathbf{E} \ \mathbf{Y}_{\mathbf{p}}^{\dagger}) \right] \mathbf{u}_{\mathbf{p}}$$
 (29)

which is precisely the same expression found for nonswirling flows in TEACH, although different values result due to swirl effects on  $k_p$ . Also, this result is consistent with an expression obtained by Date.<sup>33</sup>

For w-cells along the north wall, the diffusion is  $\mu_{\mbox{eff}}$   $\partial w/\partial r.$  This quantity appears in the expression for  $\tau_{\mbox{r}\theta}$  which is

$$\tau_{r\theta} = \mu_{eff} \left( \frac{\partial w}{\partial r} - \frac{w}{r} \right) \tag{30}$$

Applying the factor sin  $\theta(\text{=w/V})$  to the  $\tau_{t}$  wall function yields the following expression for  $\tau_{r\theta}$  :

$$\tau_{r\theta} = \left[ -\kappa \rho C_{\mu}^{\frac{1}{4}} C_{D}^{\frac{1}{4}} k_{p}^{\frac{1}{2}} / \ln(E Y_{p}^{+}) \right] w_{p}$$
 (31)

Hence the north wall function for w is given by

$$\mu_{\text{eff}} \frac{\partial w}{\partial r} = \left[ -\kappa \rho C_{\mu}^{\frac{1}{4}} C_{D}^{\frac{1}{4}} k_{p}^{\frac{1}{2}} / \ln(E Y_{p}^{+}) \right] + \mu_{\text{eff}} / r \right] w_{p}$$
 (32)

Western wall. Momentum wall functions along the west wall are similarly formulated. The total tangential velocity is now V =  $(v^2 + w^2)^{1/2}$ , and  $\tau_{xr}$  reduces to  $\mu_{eff}$   $\partial v/\partial x$ . Equation (27) for  $\tau_t$  is again obtained and the  $\tau_{xr}$  wall function is formulated by employing the factor  $\cos \phi$ ;  $\phi$  is the angle between the total tangential velocity vector and the radial velocity vector ( $\phi$  = arctan w/v). Thus one obtains the v-momentum expression:

$$\mu_{\text{eff}} \frac{\partial \mathbf{v}}{\partial \mathbf{x}} = \left[ -\kappa_{p} C_{\mathbf{u}}^{\frac{1}{4}} C_{\mathbf{D}}^{\frac{1}{4}} k_{\mathbf{p}}^{\frac{1}{2}} / \ln(\mathbf{E} \ \mathbf{Y}_{\mathbf{p}}^{+}) \right] \mathbf{v}_{\mathbf{p}}$$
(33)

The w-equation wall function on the western wall approximates  $\mu_{\mbox{eff}} \ \ ^{\mbox{dw/dx}}, \ \mbox{which is } \tau_{\mbox{X}\theta}. \ \ \mbox{Here the factor sin } \phi \ \mbox{is used to obtain the necessary wall function as}$ 

$$\mu_{\text{eff}} \frac{\partial \mathbf{w}}{\partial \mathbf{x}} = \left[ -\kappa \rho C_{\mathbf{u}}^{\frac{1}{4}} C_{\mathbf{D}}^{\frac{1}{4}} k_{\mathbf{p}}^{\frac{1}{2}} / \ln(\mathbf{E} \ \mathbf{Y}_{\mathbf{p}}^{+}) \right] \mathbf{w}_{\mathbf{p}}$$
 (34)

Other details. In accordance with Gosman and Pun, <sup>17</sup> if Y<sup>+</sup> for a cell adjacent to any solid boundary is less than 11.63, it lies within the laminar sublayer where the laminar viscosity dominates. Hence, the wall function employed for north wall u-cells, for example, is

$$\mu_{\text{eff}} \frac{\partial u}{\partial r} = -\mu_{\ell} u_{p} / \delta_{p} \tag{35}$$

where  $u_B = 0$  has been employed. Similar expressions are analogously obtained for other momentum diffusion terms of the problem.

For turbulence energy, from Eq. (30)

$$k_{\rho}/|\tau_{B}| = (C_{\mu}C_{D})^{-\frac{1}{2}} = constant$$
 (36)

near a solid boundary which implies that the wall flux is zero. Accordingly, zero normal gradient prescription for k is appropriate for wall cells via Eq. (16). Also the shear stress wall functions are employed for the k-generation source G for k-cells along a wall. The general expression for G, given in Table 2, can alternately be expressed as

$$G = 2\mu_{eff} \left[ \left( \frac{\partial u}{\partial x} \right)^{2} + \left( \frac{\partial v}{\partial r} \right)^{2} + \left( \frac{v}{r} \right)^{2} \right] + \left[ \tau_{rx}^{2} + \tau_{r\theta}^{2} + \tau_{x\theta}^{2} \right] / \mu_{eff}$$
 (37)

For north wall cells  $\tau_t^2 = \tau_{rx}^2 + \tau_{r\theta}^2$  which yields

$$G = 2\mu_{eff} \left[ \left( \frac{\partial u}{\partial x} \right)^2 + \left( \frac{\partial v}{\partial r} \right)^2 + \left( \frac{v}{r} \right)^2 \right] + \tau_t^2 / \mu_{eff} + \mu_{eff} \left( \frac{\partial w}{\partial x} \right)^2$$
 (38)

where the previous wall function expression for  $au_{t}$  is employed. Similarly, the result for west wall cells is

$$G = 2\mu_{eff} \left[ \left( \frac{\partial u}{\partial x} \right)^2 + \left( \frac{\partial v}{\partial r} \right)^2 + \left( \frac{v}{r} \right)^2 \right] + \tau_t^2 / \mu_{eff} + \mu_{eff} \left( \frac{\partial w}{\partial r} - \frac{w}{r} \right)^2$$
 (39)

where  $\tau_t^2 = \tau_{xr}^2 + \tau_{x\theta}^2$ .

As for energy dissipation, near a wall the length scale is assumed to be proportional to the normal distance from the wall which leads to

$$\varepsilon = \frac{\left(C_{\mu}C_{D}\right)^{3/4}}{C_{D}\kappa} \frac{k_{p}^{3/2}}{\delta_{p}} \tag{40}$$

This is the effective wall boundary condition on  $\varepsilon$  and in the code this value is fixed for near wall points via the linearized source procedure, using Eqs. (21) and (22).

# 2.5 Boundary Conditions Summary

Table 3 summarizes the boundary values used in the present study, which are incorporated into the computer program. The symbol N in the table signifies that zero normal gradient prescription is appropriate. Footnotes (a) to (g) are dealt with as follows:

- (a) Inlet values UIN etc. are directly specified and easily altered.
- (b) The axial velocities at the outlet are deduced from their immediate upstream values by adding a fixed amount of each of U(NIM1,J)(J = 1 to NJM1); this amount is calculated to ensure overall mass conservation.
- (c) Near wall tangential velocities are connected with their zero wall values by way of the tangential shear stress wall functions.
- (d) Near-axis swirl velocity at J = 2 is <u>fixed</u> for solid body rotation in terms of the previous w at J = 3 and its zero value on the axis.
- (e) Outlet values of k and  $\epsilon$  are unimportant because of the limited upstream influence at high Reynolds numbers and zero gradient is

Boundary Conditions (N stands for zero normal gradient specified) Table 3.

(Footnotes are detailed in section 2.3 of the text)

z	0	(p) <sup>0</sup>	z	Z	Z	
z	(၁)	(c)	Z	(f)	Z	
(2)	z	(c)	Z	(f)	z	
adjusted <sup>(b)</sup>	0	Z	N(e)	N(e)	Z	
UIN	0	NIM	TEIN	EDIN	(6)0	
ח	>	3	¥	ω	'α	
	UIN adjusted <sup>(b)</sup> (c) N	UIN adjusted <sup>(b)</sup> (c) N 0 0 N (c)	UIN adjusted <sup>(b)</sup> (c) $(c)$ $(c)$ $(c)$ $(c)$ $(c)$	UIN adjusted <sup>(b)</sup> (c) N  0 0 N (c)  WIN N (c) (c)	UIN adjusted <sup>(b)</sup> (c) N  0 0 N (c)  WIN N (c) (c)  TEIN N(e) N N  EDIN N(e) (f)	UIN     adjusted(b)     (c)     N     N       0     0     N     (c)       WIN     N     (c)     (c)       TEIN     N(e)     N     N       EDIN     N(e)     (f)     (f)       .     0(9)     N     N     N

specified. If the local Peclet number is greater than +2, there is no upstream influence because of the implications of the hybrid formulation of convection and diffusion, and the downstream convection dominates.

- (f) Near wall  $\epsilon$  values are <u>fixed</u> using the length scale near the wall and the current value of k.
- (g) The pressure correction p' possesses <u>zero normal gradient</u> specification everywhere except the inlet. Just one internal pressure p specification at (2,2) is then required to allow all the pressures to be calculated.

This concludes the discussion of boundary condition specification; its implementation is returned to in Section 4 of the present text.

### 2.6 Solution Procedure

The finite difference equations and boundary conditions constitute a system of strongly-coupled simultaneous algebraic equations. Though they appear linear they are not since the coefficients and source terms are themselves functions of some of the variables, and the velocity equations are strongly linked through the pressure. The solution proceeds by the cyclic repetition of the following steps:

- (i) Guess the values of all variables including p\*. Hence calculate auxiliary variables like turbulent viscosity etc.
- (ii) Solve the axial and radial momentum equations to obtain  $u^*$  and  $v^*$  from equations like Eq. (11).
- (iii) Solve the pressure correction equation, Eq. (15), to obtain p'.
- (iv) Calculate the pressure p and the corrected velocities u and v from Eqs. (12) through (14).
- (v) Solve the equations like Eq. (11) for the other  $\phi$ 's successively.

(vi) Treat the new values of the variables as improved guesses and return to step (i); repeat the process until convergence.

In the solution procedure algebraic equations like Eq. (11) are solved many times, coefficient and source updating being carried out prior to each occasion. The practice used here is to make use of the well-known tridiagonal matrix algorithm (TDMA), whereby a set of equations, each with exactly three unknowns in a particular order except the first and last which have exactly two unknowns, may be solved sequentially. One considers the values at gridpoints along a vertical gridline to be unknown (values at P, N and S for each point P), but take as known, most recent values being used, the values at each E and W neighbor. The TDMA is then applied to this vertical gridline. In this manner one can traverse along all the lines in the vertical direction sequentially from left to right of the integration domain.

Two points clarify the solution technique regarding the stairstep sloping boundary. Firstly, interior points adjacent to the boundary must 'feel' the boundary in the usual way. Thus values in the external field must not be inadvertently picked up at these points. Usually the standard coupling coefficient of interest is set to zero and the wall effect given by way of a false source, according to the previous description. Secondly, if the TDMA is applied in columns over the entire 2-D array of points, the solution at external points can be automatically forced to zero by giving  $S_p^{\varphi}$  a very large negative value at these locations. This term then dominates in its finite difference equation at P with solution  $\varphi=0$ . Alternatively, the domain of TDMA execution can be restricted to the physically meaningful portion of the 2-D array of points. The latter technique is incorporated into the present computer code.

At each iteration it is necessary to employ some degree of underrelaxation when solving equations like Eq. (11). A weighted average of the newly calculated value and the previous value is taken at each point. If  $\stackrel{}{\varphi}_p$   $^{n+1}$  represents the newly calculated value of  $\varphi$  at the n+l iteration, it is obtained from

$$a_{p}^{\phi} \stackrel{\sim}{\phi}_{p}^{n+1} = \sum_{j} a_{j}^{\phi} \phi_{j}^{n} + S_{U}^{\phi}$$

$$\tag{41}$$

The notation and similarity to Eq. (11) is obvious and

$$\phi_p^{n+1} = f \phi_p^{n+1} + (1-f) \phi_p^{n}$$
 (42)

where  $\phi_p^{n+1}$  represents the underrelaxed value of  $\phi_p^{n}$ , employing the norelaxation value  $\widetilde{\phi}_p^{n+1}$  and the underrelaxation parameter f (0 < f < 1). Rather than calculate and store the  $\widetilde{\phi}^{n+1}$  values and then apply Eq. (42), it is more convenient to modify and use Eq. (41) directly in the form

$$(a_{p}^{\phi}/f)\phi_{p}^{n+1} = \sum_{j} a_{j}^{\phi}\phi_{j}^{n} + [S_{U}^{\phi} + (1-f)\frac{a_{p}^{\phi}}{f}\phi_{p}^{n}]$$
 (43)

so that the underrelaxed value is calculated immediately. This is the version used in the present code.

The effect of underrelaxation factor values on convergence rate is considerable. Unacceptably slow convergence or divergence of the solution is obtained if the factors are too low or too high, respectively. Large pressure corrections arise which produce large u- and v-velocity corrections. If these corrections are too large per iteration, the nonlinearity of the FDEs causes divergence.

Velocity and pressure corrections per iteration become smaller as the solution proceeds toward convergence. Thus the underrelaxation factors (especially for u-and v-velocities) have small initial values, to prevent

divergence, and increase for faster convergence as the corrections become smaller. Hence the underrelaxation factors for u, v and w are increased linearly during the first 40 iterations.

Increased accuracy of the initial estimate of field variables clearly reduces the amount of computational work required. Also it yields a slower rate-of-variable change and smaller corrections for continuity, which promotes convergence.

Since the user generally desires to utilize such a computer code to solve a series of problems, as in a parametric study for example, he almost always has converged (or partially-converged) solutions from previous computer runs of a similar problem. By storing field values of all variables on disk upon convergence for each swirl loop, a much better initial estimate conveniently becomes available for corresponding swirl cases of future problems, or for more stringent convergence of the same problem.

Final convergence is decided by way of a residual-source criterion, which measures the departure from exactness for the variable  $\phi$  at the point P. The residual sources are defined for each variable at each point by equations like

$$R_{p}^{\phi} = a_{p}^{\phi} \phi_{p} - \sum_{i} a_{j}^{\phi} \phi_{j} - S_{U}^{\phi}$$

$$(44)$$

When each of these quantities becomes smaller than a certain fraction of a reference value, the finite difference equations are declared to be solved. Typically, the solution is considered to be converged if the cumulative sum of the absolute residuals throughout the field for <u>all</u> variables is less than 0.5 per cent of the inlet flow rate of the corresponding variable.

### 3. THE STARPIC COMPUTER PROGRAM

## 3.1 <u>Outstanding Features</u>

The case described. The computer program code described and listed performs the function outlined in Section 2 for the particular 2-D axisymmetric geometry shown schematically in Fig. 5. The flowfield is covered with a gradually expanding rectangular grid system. The quantity EPSX specifies the degree of grid expansion in the axial direction, and in the radial direction it is determined through specification of the radial position of each individual horizontal grid line. The boundary of the solution domain falls halfway between its immediate nearby parallel gridlines; and clearly specification of JMAX(I) for each I (see Fig. 5) is sufficient to determine the flowfield of interest. This provides a stairstep approximation to any monotonically increasing top wall radius as required so as to simulate any sudden expansion, sloping straight or curved sidewall. The code is equipped to handle any of these with ease. The program is an advanced version of a framework of ideas embodied into the 1974 Imperial College TEACH computer program, 17 from which the present work has been developed. The following discussion is a commentary on the final developed program. A listing is supplied as Appendix E and should be read simultaneously with the discussion.

General arrangement. The STARPIC program (see the flow chart of Fig. 8) has been written (in Fortran 4) primarily with a view to maximizing simplicity and ease of amendment at the expense of computer time. This is achieved by limiting to the MAIN subprogram those features which characterize the particular flow conditions being investigated, while different boundary conditions may be inserted by way of the PROMOD (problem modifications) subroutine. The various functions of these and other subroutines are given briefly in Table 4 and in detail in sections 3.2 to 3.12. MAIN is the section of the




Fig. 8. Flow chart of computer program showing the subroutine arrangement.

Table 4. Subroutine Tasks

Subroutine	<u>Task</u>
MAIN	· Controls and monitors the entire sequence of calcula-
	tions: initialization, properties and initial output;
	the iteration loop with calls to update main variables,
	other mixture properties and intermediate output; and,
	after termination of the iteration loop, final output,
	an increment in inlet degree of swirl and a return to
	the beginning again.
INIT	Sets values to the numerous geometric quantities con-
	cerned with grid structure, see Figs. 9-11, and initial-
	izes most variables to zero or other reference value.
PROPS	Updates the fluid properties via calculation of turbulent
	viscosity, under-relaxed using its previous value. In
	nonisothermal flows, perhaps with chemical reaction,
	additional species' mass fractions, temperature and density
	are also calculated here, with an appeal to PROMOD (1) for
	any other modifications.
PRINT	Prints out an entire variable field according to a
	standard format.
CLACU and	Calculates coupling coefficients of finite difference
CALCV	equation for axial velocity u* and radial velocity v*,
	calls PROMOD (2) and PROMOD (3) for boundary modifica-

updated to get  $u^*$  and  $v^*$  fields.

tions and LISOLV for entire field of variables to be

### Table 4 (continued)

CALCP

Calculates coupling efficients of finite difference equation for pressure correction p'; calls PROMOD (4) for boundary modifications and LISOLV to obtain p' field. The subroutine closes with p\*, u\* and v\* being 'corrected' with p', u' and v'.

Other

CALC

Calculates coupling coefficients of appropriate finite difference equation, calls appropriate part of PROMOD and then LISOLV for complete update of the variable

Subroutines

in question.

PROMOD

Modifies the values of the finite difference equation coefficients, or the variables, near walls or other boundaries where particular conditions apply. The subroutine is divided into chapters, each handling a particular variable and being called from a CALC subroutine, and each chapter considers all the boundaries around the solution domain.

LISOLV

Updates entire field of a particular variable, by applying TDMA ( $\underline{t}$ ridiagonal  $\underline{m}$ atrix  $\underline{a}$ lgorithm) to all the lines in the r-direction sequentially from left to right of the integration domain.

program to which a user will devote most of his attention, provided that he wishes to investigate configurations easily derivable from that shown in Fig. 5. He may also be concerned with PROMOD to adjust boundary condition types. Moreover all the subprograms are divided into chapters, each with a prescribed task to accomplish, thus decreasing the possibility of error on problem specification and modification.

MAIN controls the entire iterative solution procedure, with initial calls to INIT (initialization), PROPS (properties) and PRINT (for output of all variable fields). Repeated intermediate calls occur during the iteration loop to the CALC subroutines (CALCU for updating calculation of the <u>U</u>-velocity field, etc.), PROPS and PRINT (when required). Finally, after convergence or MAXIT (<u>maximum iterations</u>) number of iterations, PRINT is called again, together with the calculation and output of any special quantities required which are deducible from the flowfield values. Each of the CALC subroutines calls PROMOD (<u>problem modifications</u>) for modifications to the usual formulation because of boundary conditions. Subroutine LISOLV (<u>line solve</u>) is also called by each CALC subroutine to make several update sweeps of the relevant field of variables by applying the TDMA (<u>tridiagonal matrix algorithm</u>) to all the lines in the r-direction sequentially from left to right of the integration domain (NSWPU times for the u-field, etc. - <u>n</u>umber of <u>sweeps</u> for <u>u</u>).

Major variables. The discussion of Fortran variables is restricted to those symbols enjoying major significance in the accompanying listing of the program in Appendix E. Other symbols will readily yield their meanings on inspection of the context and their memonics; or they appear in parts of the program which the user is enjoined not to disarrange, the user restricting most of his attention to MAIN and PROMOD. A glossary of Fortran symbols is given in Appendix D. Table 5 lists principal dependent variables and controlling parameters.

Table 5. Principal Dependent Variables and Controlling Parameters

Residual Source Term	RESORU	RESORV	RESORW	RESORK	RESORE	(RESORM for mass calcu- lated in CALCP)	
Prandt]/ Schmidt Number	ı	1	PRW	PRTE	PRED	1	ı
Number of Sweeps of LISOLV per iteration	NSWPU	NSWPV	NSWPW	NSWPK	NSWPD	NSMPP	ı
Underrelax- ation factor	URFU	URFV	URFW	URFK	URFE	URFP	URFVIS
CALC Subroutine	CALCU	CALCV	CALCW	CALCTE	CALCED	CALCP	PROPS
Inlet Value	NIN	VIN	NIM	TEIN	EDIN	ı	1
Logical Variable	INCALU	INCALV	INCALW	INCALK	INCALD	INCALP	INPRO
Alphanumeric Heading	HEDO	HEDV	HEDW	HEDK	HEDD	HEDP	HEDVIS
Fortran Variable	Ð	>	3	12	ED	dd	VIS
Algebraic Variable	3	>	3	<u>~</u>	ω	<b>-</b>	ュ

### 3.2 The MAIN Subprogram

General arrangement. MAIN is that section of the program to which a user will devote most of his attention. The function of MAIN has been described in section 3.1. It is divided into chapters, each with a specific task, and a description of the individual chapters of MAIN now follows.

CO Preliminaries. Dimension, common and data blocks are followed by user input logical variables, which activate (when specified as true) certain special features of the program. As discussed in detail in Chapter 4, IFINE specifies a fine mesh in the x-direction with NI=35 as opposed to a coarser mesh with NI=23; IWRITE writes all dependent variables onto allocated disk storage; NONDIM calculates and prints the nondimensional solution in addition to the dimensional one; IREAD reads from allocated disk storage the initial solution guess, which is a previous solution of a similar problem; INITAL prints the initial guess of the solution; and INPLOT produces a line-printer plot of streamlines. Specification of NSWPU (number of sweeps for U), etc. and input read statements for alphanumeric headings HEDU (heading for U velocity), etc. are also located here. These alphanumeric headings are the only input data which appear after the program and are listed here in order:

U VELOCITY

V VELOCITY

W VELOCITY

**PRESSURE** 

**TEMPERATURE** 

TURBULENCE ENERGY

TURBULENCE DISSIPATION

VISCOSITY

DIMENSIONLESS LENGTH SCALE

DIMENSIONLESS STREAM FUNCTION

RADIAL COORDINATE OF STREAMLINES

DIMENSIONLESS U VELOCITY

DIMENSIONLESS V VELOCITY

DIMENSIONLESS W VELOCITY

DIMENSIONLESS PRESSURE

DIMENSIONLESS TURBULENCE ENERGY

DIMENSIONLESS STREAMLINE COORDS

DIMENSIONLESS EFF. VISCOSITY

C1 Parameters and control indices. This chapter really defines the problem to be solved. It is implicity that the problem is axisymmetric in cylindrical coordinates with the setting of INDCOS = 2. The problem domain is specified by dealing with the grid exemplified in Fig. 5, and giving values to the key parameters there-in. Other matters include dependent variable selection (setting .TRUE. or .FALSE. to INCALU etc.), fluid properties (see Prandtl/Schmidt numbers of Table 4), turbulence constants, boundary values (see inlet values of Table 4), pressure calculation reference point (IPREF, JPREF) and program control and monitor.

C2 Initial operations. Based on the problem specification already accomplished in C0 and C1, certain other initial operations are needed prior to the iteration procedure. In C2 the geometric quantities for the grids (see Figs. 9-11) are calculated and main 2-D array variables are set to zero or obvious initial values by way of the call to subroutine INIT. Returning to MAIN, the dependent variable fields are first specified at the inlet boundary including swirl velocity which uses VANB or SWNB for flat or solid-body rotation profile according to whether NSBR (number for solid body rotation) equals 0 or 1. Then estimates of dependent variables in the

field are calculated, as many of them depend on inlet values. Following the call to PROPS for fluid properties, an initial output is made of certain flow and geometric quantities. Finally, if IREAD = .TRUE. each dependent variable array is read sequentially from the disk storage allocated to unit 12 to re-specify the initial field estimates with improved values. Thus the user should specify IREAD = .TRUE. when a previous solution to a similar problem is available on disk, as this reduces the number of iterations required for convergence.

<u>C3 Iteration loop.</u> This is the section of MAIN that is repeated at each iteration where NITER counts the <u>number of iterations</u>. The task of C3 is several-fold: to adjust the underrelaxation factors for enhanced convergence based on numerical experience; to update dependent variables (via calls to subroutine CALCU if INCALU is true, etc.); to update fluid properties (if INPRO is true the call to PROPS updates secondary dependent variables); to give intermediate output of residual source sums and field values at monitored location (IMON, JMON) for all values of NITER; to include appropriate field prints when NITER=JPRINT; and finally to make appropriate iteration termination tests.

<u>C4 Final operations and output</u>. Having decided to terminate the iteration process, control transfers to C4 to obtain final variable field printouts and to calculate and print nondimensional variables if NONDIM = .TRUE. Also, a call to subroutine STRMFN calculates dimensionless stream function and determines the coordinates of points along NSTLN streamlines for plotting. Further, if IWRITE = .TRUE. each dependent variable array is stored sequentially on the disk space allocated to unit 11.

Control has now finished with the current problem. However, if LFS ( $\underline{1}$ oop  $\underline{f}$ or  $\underline{s}$ wirl) is less than LFSMAX ( $\underline{1}$ oop  $\underline{f}$ or  $\underline{s}$ wirl  $\underline{m}$ aximum) then LFS is incremented by 1, and the inlet swirl velocity profile is recalculated

for the next swirl problem based on SWNB ( $\underline{swirl\ number\ block}$ ) or VANB (vane angle block) according to whether NSBR ( $\underline{number\ for\ solid\ body\ rotation}$ ) equals 0 or 1. Before control begins C3 for the new swirl problem, the precious solution of a similar problem will be read from disk storage allocated to unit 12 if IREAD = .TRUE. This improved initial field estimate reduces the number of iterations required for convergence.

### 3.3 Subroutine INIT

INIT consists of two main chapters:

Cl Calculate geometric coefficients. Geometric quantities for the three grids for C, U and V cell control volumes (see Figs. 3 and 9-11) are here calculated once and for all for the particular geometric system previously specified in MAIN. Notice that setting INDCOS = 1 suppresses the variation of R with Y and thus obtains cartesian coordinates. In the current program, however, the problem is correctly coded only for cylindrical coordinates.

<u>C2 Set variables to zero</u>. In C2 most dependent and other 2-D array variables are set to zero throughout the flowfield although some are set to obvious nonzero initial values.

### 3.4 Subroutine PROPS

There is only one chapter:

<u>Cl Viscosity</u>. The turbulent viscosity  $\mu$  is calculated from the two-equation k- $\epsilon$  turbulence model, Eqs. (5) and (6), making use of the URFVIS underrelaxation parameter.




Fig. 9. Fortran variables related to the grid for C cells.




Fig. 10. Fortran variables related to the grid for U cells.




Fig. 11. Fortran variables related to the grid for V cells.

## 3.5 Subroutines CALCU and CALCV

CALCU has the task of calculating the appropriate coupling coefficients linking the value of U\* at each 'w' point of the mesh system with its four neighbors via Eq. (11). The formulation is completely general and correct only for internal points but the call to PROMOD (2)(problem modifications, chapter 2) corrects for near boundary points by applying the correct formulation via a linearized source technique (see section 2.3). Underrelaxation via Eq. (43) precedes the updating of the U\* field via a call to LISOLV, this being called NSWPU (number of sweeps for  $\underline{U}$ ) times for multiple inner updates of the U\* field. The task of CALCV is similar as it renews the V\* field and utilizes PROMOD (3). The chapters are:

- $\underline{\text{Cl Assembly of coefficients}}$ . Two nested loops for I and J ensure that all internal points of the mesh are considered in Cl. For each (I, J) point the following sequence of calculations is performed:
  - (i) the cell face areas and volume (utilizing the geometric variables of Figs. 9-11.
  - (ii) the convection coefficients via the mass-velocities GN etc. and mass flow fluxes through the faces CN etc.
  - (iii) the diffusion coefficients utilizing viscosities, areas and distances to obtain DN etc.
  - (iv) the coefficients of source terms here only the 'false' source stabilizing trick components of Eq. (9) are used; other parts of the source term are added in later.
  - (v) the main coefficients AN etc. are assembled, using the 'hybrid' formulation of central and upwind differences, Eq. (10). The SU and SP components of the source expression are now determined with the pressure term going into SU, see Tables 1 and 2.

- <u>C2 Problem modifications</u>. The general forumlation of C1 is modified for near boundary points via the call to PROMOD. The call is to Chapter 2 of PROMOD in the case of CALCU and to Chapter 3 in the case of CALCU.
- C3 Final coefficient assembly and residual source calculation. Two nested loops for I and J allow all points of the grid to be dealt with in turn. Firstly, AP (=  $a_p$ ) is calculated and RESORU (residual source for U) is incremented, and secondly, the underrelaxation demands of Eq. (43) are applied.

C4 Solution of difference equation. LISOLV is called NSWPU times in order to update the U\* field several times (NSWPV times in the case of V\*). The LISOLV parameter list begins 3, 2, ... in the case of CALCU, but 2, 3, ... in the case of CALCV. Careful observation of the relationship between the physical and reference storage locations of the displaced grid systems for U and V confirm this requirement.

#### 3.6 Subroutine CALCP

CALCP deals with the variable PP (= p' the pressure correction) in a similar fashion to the CALCU and CALCV subroutines just described. However, there are several points of difference:

- (i) the subroutine is concerned with Eq. (15) and the calculation of p',
- (ii) the assembly of coefficients is simpler than the previous two subroutines,
- (iii) the subroutine closes with the application of the p' field to correct the latest estimates so far of the u, v and p fields, that is u\*, v\* and p\*, by appropriate use of Eqs. (12) through (14).

<u>Cl Assembly of coefficients</u>. Two nested loops sweep through the entire grid system. At each point the following sequence of calculations is performed: areas and volume of cells, coupling coefficients, source terms and absolute mass sources.

C2 Problem modification. A call statement to PROMOD (4) is included.

<u>C3 Final coefficient assembly</u>. Coefficient AP is calculated for all points of the mesh.

<u>C4 Solution of difference equations</u>. LISOLV is called NSWPP times in order to obtain a good estimate of the p' field. The parameter list, beginning 2, 2, ..., is appropriate since pressures are stored at grid intersections.

C5 Correct velocities and pressure. When this stage is reached, first estimates of the u, v and pfields (U\* from CALCU, V\* from CALCV and p\* from previous iteration) are known. Equations (12) through (14) are applied to obtain better estimates and ensure that the U\* and V\* momentum equation first-estimate solutions are brought into conformity with the continuity equation. Notice that the D0 loop ranges are a little complicated so as to operate only on internal field points. There is no underrelaxation here on the velocity components (this was done prior to obtaining the U\* and V\* fields). Also, the required p' correction is added to the latest estimate of the pressure field p\*.

### 3.7 The other CALC subroutines

The other main dependent variables which are to be solved from their governing partial differential equations are w, k, and  $\epsilon$  as seen in Table 1. Each of these is dealt with in a separate subroutine denoted by the name CALC followed by W, TE and ED. They are each called sequentially in this order directly from the MAIN subprogram; and each of them is structured

similarly to the CALCU and CALCV subroutines described in section 3.5. Only highlights of the differences need be described.

C1 Assembly of coefficients. Since all these variables are physically located at the grid intersections, both the I and J loops begin with the value 2 and ensure a sweep over all internal mesh points. The third part of C1 is concerned with diffusion coefficients and it is here that the Prandtl/Schmidt numbers PRTE, etc. in Table 4 are brought into play: viscosities are divided by PRTE, etc. in order to obtain the appropriate exchange coefficients. The fourth part concerns source terms and rather longer expressions are formulated as required from Table 1.

<u>C2, C3 and C4</u>. These bear such a strong resemblance to their corresponding chapters already described in section 3.5 that no further elaboration need be given here, except to remark that the LISOLV call always begins with the parameters 2, 2.

## 3.8 Subroutine LISOLV

LISOLV (<u>line solver</u>) is called from each of the CALC subroutines. When called it provides one complete sweep of the relevant interior points at which the variable is located. Also it replaces the 2-D array PHI, the last parameter of the call list, with the solution of the equations previously built-up in the calling subroutine. This is effected by means of the well-known TDMA (<u>tridiagonal matrix algorithm</u>) being applied to each vertical gridline in turn, and traversing along all such lines in the vertical direction sequentially from left to right of the integration domain.

The subroutine begins with a DO loop for the W-E sweep. There is some complexity here involving ISTART and JSTART, the first two parameters of the call list (these are usually given the values 2, 2 but are 3, 2 and 2, 3 when the call is from CALCU and CALCU respectively). But careful perusal of

the steps involved will assure the reader that the calculations are correct. The subsequent parts of the subroutine concern implementation of the TDMA technique: with the S-N traverse, assembling the TDMA coefficients, the calculation of the coefficients of the recurrence formula and the back-substitution to obtain the solution values of the S-N gridline.

### 3.9 Subroutine PRINT

The task of PRINT is to print out the values of a 2-D array PHI, together with associated heading HEAD, the last parameter of the call list. The X and Y coordinates are written horizontally and vertically around the output matrix of values. Again, as discussed in Section 3.8, the first two parameters of the call list, ISTART and JSTART, are usually 1,1 so that all internal and external values are printed to help diagnostics. Also, for U the XU values are printed and for V the YV values so that correct physical position values accompany the output of these variables which are located on displaced grids.

#### 3.10 Subroutine PROMOD

The finite difference equation coefficients are formulated in each of the CALC subroutines on the assumption that each point is a usual internal point. Of course some points lie near or on the rectangular boundary of the flow domain in which the solution is sought and the general formulation of a CALC routine is not correct at these points. So that all required corrections to the general formulation are simple to understand and apply, each CALC routine calls a particular chapter of PROMOD (problem modifications). This subroutine has the task of modifying the values of the finite difference equation coefficients, or the variables, near walls or other boundaries where particular conditions apply. Each chapter concerns itself solely with one

particular variable and each chapter considers in turn each of the boundaries around the solution domain. Boundary conditions are thus easy to formulate and simple to apply; and this novel feature makes PROMOD second only to MAIN as a subroutine to which a prospective user needs to apply his attention.

According to the value given to NCHAP (<u>n</u>umber of <u>chap</u>ter required) of the call list, control proceeds to one and only one of the eight chapters of this subroutine. These chapters deal with:

- Cl Properties
- C2 U momentum
- C3 V momentum
- C4 Pressure correction
- C5 Thermal Energy
- C6 Turbulent kinetic energy
- C7 Dissipation
- C8 W momentum

where C5 is retained from the original TEACH arrangement, but is not used in the present version of the code.

Figure 5 reveals that amongst the boundaries of the solution domain only at the inlet is the usual formulation of the finite difference equations, as computed in the CALC subroutines, correct. At other boundaries of the solution domain appropriate sections of PROMOD have to supply the correct influence of the boundary conditions on the coupling coefficients  $a_j^{\varphi}$  (j = N, S, E, W and P) and components  $S_U^{\varphi}$  and  $S_p^{\varphi}$  of the linearized source term. In PROMOD each of the chapters is further divided into sections dealing with

- (i) Northern top wall, I = 2 to NIM1
- (ii) Southern symmetry axis, I = 2 to NIM1
- (iii) Western side wall, J = 2 to NJM1
- (iv) Eastern outlet, J = 2 to NJM1

In what follows all four cases of a N, S, E and W near-boundary point are dealt with simultaneously. One merely reads the appropriate line (designated by (N), (S), (E) and (W)) of the equations which follow, according to the particular case in which the reader is temporarily interested. Notation follows that of the boundary cells of Figs. 6 and 7.

Boundary conditions are inserted for each boundary cell. The first step generally involves breaking the link to any adjoining external cell by setting to zero the appropriate  $a_i$  of Eq. (11). Then, for each boundary

AN 
$$(I, J) = 0$$
 (N)  
AS  $(I, J) = 0$  (S)  
AE  $(I, J) = 0$  (E)  
AW  $(I, J) = 0$  (W)

This step is followed by insertion of the correct boundary flux (diffusion and/or convection) for the cell boundary in question into the linearized source terms SU and SP, as exemplified in the following sections.

Neumann conditions. If zero normal gradient condition is the one to be applied, breaking the appropriate link is all that is required. For then the terms

$$a_{N} (\phi_{P} - \phi_{N}) = 0 \quad (N)$$
 $a_{S} (\phi_{P} - \phi_{S}) = 0 \quad (S)$ 
 $a_{E} (\phi_{P} - \phi_{E}) = 0 \quad (E)$ 
 $a_{W} (\phi_{P} - \phi_{W}) = 0 \quad (W)$ 
(46)

are all zero in Eq. (11) so there is no flux through the boundary in question.

Dirichlet conditions. If the value of  $\phi$  is prescribed as  $\phi_B$  on the boundary then the usual boundary link is broken via Eq. (16). For a solid boundary the convective flux through the boundary face of the cell is zero,

but the diffusive flux is typically nonzero. Hence the diffusion term of Eq. (8) is transferred to the right-hand side RHS of the equation where it is incorporated into SU(I,J) and SP(I,J); on the RHS it is expressed in terms of  $\phi_P$  and  $\phi_B$  as

$$\Gamma_{B} (\phi_{B} - \phi_{P}) r_{B} \Delta x/\delta y \qquad (N)$$

$$\Gamma_{B} (\phi_{B} - \phi_{P}) r_{B} \Delta x/\delta y \qquad (S)$$

$$\Gamma_{B} (\phi_{B} - \phi_{P}) r_{B} \Delta y/\delta x \qquad (E)$$

$$\Gamma_{B} (\phi_{B} - \phi_{P}) r_{B} \Delta y/\delta x \qquad (W)$$

where  $\Gamma_B$  is the appropriate exchange coefficient for  $\phi$  evaluated at point B. Appropriate cell boundary face areas appear here. North and south face areas are given by  $r_B$   $\Delta\theta$   $\Delta x$  whereas east and west areas are expressed as  $r_B$   $\Delta\theta$   $\Delta r$ ; but  $\Delta\theta$  cancels from the governing equations. These expressions may be split between SU(I,J) and SP(I,J) as

$$SU(I,J) = SU(I,J) + \begin{cases} \Gamma_{B} r_{B} \phi_{B} \Delta x/\delta y & (N) \\ \Gamma_{B} r_{B} \phi_{B} \Delta x/\delta y & (S) \\ \Gamma_{B} r_{B} \phi_{B} \Delta y/\delta x & (E) \\ \Gamma_{B} r_{B} \phi_{B} \Delta y/\delta x & (W) \end{cases}$$

$$(48)$$

and

$$SP(I,J) = SP(I,J) - \begin{cases} \Gamma_{B} r_{B} \Delta x/\delta y & (N) \\ \Gamma_{B} r_{B} \Delta x/\delta y & (S) \\ \Gamma_{B} r_{B} \Delta y/\delta x & (E) \\ \Gamma_{B} r_{B} \Delta y/\delta x & (W) \end{cases}$$

$$(49)$$

Flux specified. If the flux of  $\phi$  through a boundary face of the cell is specified. When brought to the RHS of Eq. (8) it may be approximately expressed as  $b\phi_p$  + c where b and c are known (if possible, retaining (-b) and (c) both positive to aid the convergence of the finite difference iteration procedure). This is implemented by breaking the boundary link and augmenting the source terms appropriately:

$$SU (I,J) = SU (I,J) + c (N,S,E, and W)$$
 (50)

$$SP (I,J) = SP (I,J) + b (N,S,E, and W)$$
 (51)

Fixing a value at an internal point. The value of  $\varphi$  at a near-boundary point P may be fixed at a value of  $\varphi_F$  via setting

SU (I,J) = 
$$\phi_F 10^{30}$$
 (N,S,E, and W) (52)

$$SP (I,J) = -10^{30} (N,S,E, and W)$$
 (53)

so that these terms dominate in the equation for  $\varphi$  at P, with the solution  $\varphi_P$  =  $\varphi_F.$ 

Convective and diffusive influences. If both convection and diffusion through a cell boundary occurs, the hybrid formulation should be used. In this situation the contribution C for the flux passing the surface in question (N,S,E, or W) is calculated according to Eq. (10) and used along with the other surface contributions and source terms to formulate the usual finite difference equation. This is ensured automatically in the program for a normal inflow/outflow boundary.

### 3.11 Subroutine STRMFN

Subroutine STRMFN has been developed to calculate the dimensionless stream function  ${\sf STRMFN}$ 

$$STFN = \int_{0}^{r} urdr / \int_{0}^{d/2} urdr$$
 (54)

for all internal field points of the u-cell grid. The quadrature formulation for calculating STFN is essentially the Trapezoidal Rule. The integration proceeds radially one step SNSV(J) at a time so that a finite difference mesh which is either uniform or nonuniform in the radial direction is permissible.

The coordinates of points constituting each of NSTLN streamlines with dimensionless stream function values STVAL ranging from 0.0 to 1.0 are subsequently calculated for plotting. The present code calculates the coordinates of eleven streamlines with  $\psi^* = 0.0$ , 0.1, ..., 1.0. Each streamline is represented by NI-1 points whose dimensionless x- and r-coordinates are stored as XUND(I) and YSTLND(I,K) (K = 1,...,11) respectively, where the k-index indicates the particular streamline. These two arrays are employed in producing COMPLOT streamline plots via the usual CALCOMP subroutines. Immediate line printer plots of alternate streamlines are obtained through the use of corresponding arrays XUDPLT(I) and YSLPLT(N,I) (N = 1,...,6) for the six streamlines  $\psi^* = 0.0$ , 0.2, ...,1.0.

#### 3.12 Subroutine PLOT

The PLOT subroutine is a variant of the  $\phi$  - profile line printer plot routine supplied with some versions of the GENMIX computer program. It is now described at length in a recent text. <sup>34</sup> In the present version supplied, it is called twice after each converged solution has been obtained. Firstly, with the parameter LARGE equal to 0 (giving a small-sized plot) and secondly with LARGE equal to 1 (giving a larger-sized plot). Prominent in the call list are XUDPLT(I) and YSLPLT(N,I) (N = 1,...,6) as described in Section 3.11 from which the required six streamlines are plotted. A 50 x 100 array is filled with alphanumeric characters as appropriate so as to give labels

0,2,4,6,8 and 1 corresponding to the nondimensional streamlines  $\psi^{\star}$  = 0.0, 0.2,...,1.0.

#### 4. USER'S GUIDE

### 4.1 Problem Specification

General. The listing of the program, which is supplied in Appendix E, is used for precisely those calculations which have been described in Sections 2 and 3 of this report. The user of the program will wish to make other calculations; for this he must modify the program. Although the description of the program which was given in Section 3 will allow the discerning reader already to distinguish the parts of the program which must be altered, the following notes will aid him to make the modifications to suit his case, without going through the whole program.

The general principles which the user should adopt are:

- (i) Read through MAIN, paying special attention to the Chapter titles, and other subtitles, and considering whether any of the features of the problem which relate to those titles have suffered changes which should be incorporated.
- (ii) Make the corresponding changes to MAIN.
- (iii) If modifications are desired to the turbulence model, introduce these in C2 of MAIN and/or C2 of PROPS.
- (iv) If different wall boundary conditions are required, read carefully Sections 2.3 and 3.10 and then change PROMOD accordingly.
- (v) Check that the COMMON statements are still adequate.
- (vi) Leave the general parts of the program alone, including the CALC subroutines, INIT, PROPS, LISOLV and PRINT (except those minor nonstructural parts just mentioned).

The following discussion is organized under the headings: Input data specification, system specification, boundary conditions, and turbulence specification.

Input data specification. Much of the data is internally specified. However, if IREAD = .TRUE. has been declared in CO of MAIN, the unformatted reading of all input data from disk storage is activated. This input requires the proper job control "card" to allocate the logical unit number of the READ statement to the disk storage data file from which the data is to be read. The dependent variable fields are read from disk storage as an improved (near-solution) initial estimate to reduce the number of iterations required for convergence.

As seen in Section 4.2, the X(I) and Y(J) [=R(J)] arrays preced the dependent variable arrays sequentially written on each data file stored. Hence in CO of MAIN, these two independent variable arrays are read to enable the next unformatted READ in C2 of MAIN to read the U(I,J), etc. dependent variables. After the solution is printed in C4 of MAIN, the dependent variable arrays are re-initialized for the next swirl loop by another series of unformatted reads from disk storage. Also, as discussed in Section 3, alphanumeric headings are read in CO of MAIN using an A format field.

System specification. Minor variants of the sample grid system of Fig. 4 can be derived simply by appropriate modifications being made to the grid section of C1 of MAIN. Appropriate choice of the integers NI, NJ, ISTEP, JSTEP and JMAX(I) together with RLARGE (=D/2) ALTOT (= total length), EPSX (the gradual expansion rate in the axial direction) and Y(J) defines completely the axisymmetric geometry with INDCOS = 2. Assigning true or false to INCALU etc. activates the calls to subroutine CALCU etc. during the subsequent iteration cycle to update the U-velocity field. They also determine whether printing is required. Clearly, true settings will generally be the ones to use for all the dependent variables. Specification is also required for

fluid properties, including Prandtl/Schmidt numbers and all material constants in SI units.

Boundary conditions. Cl of MAIN specifies boundary values of all the dependent variables. Hence specification of UIN etc. are required for the main inlet. Most inlet profiles of the turbulent flow are then taken to be uniform in C2 of MAIN and the user can easily amend this if desired. Employed here is the <a href="main">swirl</a> number <a href="main">block</a> SWNB or <a href="main">vane</a> <a href="main">angle</a> <a href="main">block</a> VANB</a> <a href="main">according</a> to the value of NSBR (<a href="main">number</a> <a href="main">block</a> SWNB</a> or <a href="main">vane</a> <a href="main">angle</a> <a href="main">block</a> VANB</a> <a href="main">according</a> <a href="main">to the value of NSBR (<a href="main">number</a> for <a href="main">solid</a> <a href="main">body</a> <a href="main">rotation</a>). The specification</a> <a href="main">NSBR = 1</a> <a href="main">activates</a> SWNB, which gives solid body rotation from a swirl generator, and <a href="main">NSBR = 0</a> <a href="main">activates</a> SWNB for a flat swirl velocity profile from <a href="main">swirl</a> vanes. In either case, the desired inlet values of swirl velocity</a> W are <a href="main">assigned</a> appropriately.

Initial field values of all the dependent variables are specified in C2 of INIT and C2 of MAIN. The user will be content to leave these alone, for as soon as the iteration process is underway, these estimates are improved. Only occasionally in some cases will they be too inaccurate to permit a smooth iterative process to continue from their values - in such cases more realistic values closer to the true solution and/or underrelaxation must be specified.

<u>Turbulence specification</u>. Minor adjustments to the turbulence model already in the program can be simply achieved by altering the turbulence constants part of Cl of MAIN and C2 of PROPS for the viscosity calculation. If one desired to make a computation for laminar flow, VIS must be filled with appropriate values in the D0 100 loop of PROPS. Also, the logical variables INCALK and INCALD could be specified as false to suppress the calculation of k and  $\varepsilon$  and the complexity in PROMOD for velocities near wall boundaries would be removed. When a different turbulence model is required, of course, C2 of PROPS must reflect this. Should a nonisotropic

or direct turbulent stress specification model be required, more farreaching changes would be required to the diffusion term calculations in all the CALC subroutines, possibly with other CALC routines for solving stress equations. It is here that current knowledge is uncertain and much current research activity is being directed toward more realistic turbulence models.

# 4.2 <u>Iteration and Accuracy</u>

Iteration control. The iteration process is monitored by comparing the sum of the absolute values of residual source of mass in the filed, RESORM, with a preset value, SORMAX, representing <a href="maximum source">maximum source</a>. Similarly for other variables U, V, W, etc. iteration is terminated for a particular problem when the largest residual source is less than SORMAX, or <a href="maximum number of iterations">number of iterations</a> NITER is greater than the <a href="maximum number of iterations">maximum number of iterations</a> MAXIT to be allowed. By analogy a divergence criterion can also be included if required, so as to prematurely terminate a computation giving results which appear not to be converging.

Fortran variables which are used to influence the iteration behavior are NSWPU etc. (representing <u>number</u> of update <u>sweeps</u> for  $\underline{U}$  etc.) and URFU etc., (representing <u>underrelaxation for  $\underline{U}$  etc.</u>). If divergence is found, the remedy often lies in increasing the former (especially NSWPP for pressure) and reducing the latter. However, the accompanying listing includes reasonable values which have been found convenient to use. They are automatically re-assigned in the iteration process according to the inlet swirl strength and number of iterations made toward convergence, as inspection of the listing reveals.

Output. At every iteration, RESORM etc. are printed out along with monitored values of variables at the location specified by IMON and JMON. Full field prints presently after 100 iterations and increments of 50 thereafter. Full field prints are obtained for each dependent variable with a true logical variable (like INCALU for U-veloctiy) by way of a call to subroutine PRINT. The user, of course, is entirely free to make any output he wishes at each iteration stage in C3 of MAIN and to make a field print of any 2-D array via a call to PRINT. This structure is a flexible one which can be utilized to advantage.

If IWRITE = .TRUE. has been specified in CO of MAIN, the unformatted writing of all output data onto disk storage is activated. This output requires the proper job control "card" to allocate the logical unit number of the WRITE statement to the disk storage data file which is to receive the data. First, the X(I) and then the Y(J) [=R(J)] arrays are written to disk storage allocated to logical unit 11, as seen in the initial output portion of MAIN, C2. Also, located here is the writing of XUND(I), nondimensional XU(I), to disk storage allocated to logical unit 14.

Upon completion of the solution process for each swirl loop each field variable is nondimensionalized and printed (if NONDIM = .TRUE.) subsequent to the printing of dimensional variables. Then, the following dependent variable arrays are written onto disk (logical unit 11): U(I,J), V(I,J), W(I,J), P(I,J), TE(I,J), ED(I,J), VIS(I,J) and STFN(I,J). Immediately following is the WRITE of YSTLND(I,K) to disk (logical unit 14), where YSTLND(I,K) contains the dimensionless radial coordinate corresponding to each dimensionless axial coordinate XUND(I) along each K streamline. These arrays are subsequently used in obtaining CALCOMP streamline plots.

Independence of grid size. A computation may be considered to be accurate if alterations in the grid size produce no significant changes in the values of dependent variables, or the fluxes, at the points in the flow or its boundary which are interesting to the user of the program. Such alterations are obtained by changing the values of NI and NJ ( $\underline{n}$ umber of grid intervals in  $\underline{I}$  and  $\underline{J}$  (i.e. X and Y) directions) along with EPSX and Y(J). Specification of these quantities is made in Cl of MAIN. Of course, large values of NI and NJ increase the computer time significantly, so smallest values should be used that are consistent with acceptable accuracy. There is no way but trial to establish what these values are, but a 23 x 21 or 35 x 21 grid is probably sufficient, as available by simple choice in the delivered code.

Comparison with exact or experimental values. Further tests of accuracy can be made by setting the geometry and boundary conditions of the program to correspond to a problem for which exact solutions or experimental results are available. For example, the inlet step could be dispensed with and standard pipe flow results. In either case the presence of swirl and turbulence is optional. Hence comparison of the predictions of the program for this degenerate case with exact or experimental results can provide valuable insight into the accuracy with which the differential equations are being solved.

'<u>Trouble-shooting</u>' - It is possible to mention only a few of the remedies which can be employed when the program, in the course of being adapted to a new problem, generates computations that are evidently faulty.

To prevent divergence, the source terms should be formulated so that -SP is always positive for each  $\varphi$  variable. This keeps the point P dominant in its finite difference form with its N, S, E and W neighbors and aids the

stability of the iteration process. The forms shown in Table 2 enjoy this characteristic.

Lack of conservation of properties which ought to be conserved is often the result of incompatible specification of boundary conditions and fluid properties, for example. One has to take extreme care. It is not possible to say much more in general than that inadvertently introduced incompatibilities are among the most common causes of error.

### 4.3 The Sample Computation

The sample computation code listing (Appendix E) and the results given in the microfiche supplement are concerned with the inert turbulent flow in an idealized combustion chamber. An air flow (constant density  $_{\rho}$  = 1.211 kg/m³ and molecular viscosity  $_{\mu}$  = 1.8x10<sup>-5</sup> kg/ms) enters a 45 deg. expansion ( $_{\alpha}$  = 45 deg.) from an inlet pipe (radius d/2 = 0.03125 m) to a large pipe (radius D/2 = 0.0625 m). The total length of the flow domain is 0.5 m so as to be sufficient to enclose any expected recirculation zones. Computer runs through a range of seven inlet swirl vane angles  $_{\varphi}$ (= arctan  $_{\psi}$ (= arctan  $_{\psi}$ (= arctan vin/uin) equal to 0, 45,55,60,65,68 and 70 deg. are given, although serious production runs with the larger swirl strengths are made with the total length further extended to about 0.8 m in order to cover a larger domain associated with a longer central recirculation zone. A maximum of 200 iterations for each swirl strength is allowed, with the solutions for each value of  $_{\varphi}$  being used as the initial starting values for the next higher value of  $_{\varphi}$ .

The flow domain is covered by a 23 x 21 mesh system (NI = 23 for the x-direction, NJ = 21 for the r-direction). The sidewall angle of  $\alpha$  = 45 deg. is accommodated by way of four steps each of three cells high in the radial direction. The specification is

```
ISTEP = 2

JSTEP = 8

JMAX(1) = 8

JMAX(2) = 11

JMAX(3) = 14

JMAX(4) = 17

JMAX(I) = 20 (I = 5,6,...,21)
```

In the x-direction a uniformly expanding grid up to x=0.375 m at I=20 is specified via EPSX = 1.11, then equidistant addition grid lines are specified up to x=0.5 m at NI = 23. This grid is appropriate for sidewall angles  $\alpha=45$  and 90 deg., though with  $\alpha=70$  deg. a uniformly expanding grid up to x=0.375 m at I = 30 is specified via EPSX = 1.102, then equidistant additional grid lines are specified up to x=0.55 m at NI = 35. In the r-direction the 21 grid lines are clustered near the expansion corner, centerline and north wall since additional refinement is required in regions with expected large gradients. The choice of x-grid is determined by setting IFINE to be true or false, giving fine or coarse grid system, respectively. Both grids are arranged

- (i) to give good resolution in strategic locations near the inlet,exit, projecting corners and front and back stagnation points,
- (ii) to give corresponding axial locations at which to compare predictions with present and previous measurements.

Finally, the choice of logical variables in Chapter 0 of MAIN is self-explanatory giving rather detailed output but not reading from or writing to any disk storage locations.

When the user wishes to compute a problem with a sidewall angle  $\alpha$  different from 45 deg. [as in the listing supplied in Appendix E] he has

to specify the x and r [ $\equiv$  y] grid line locations and JMAX(I) for each I. Many variants of the flow domain of Fig. 5 discussed in Section 2.3 can thus be investigated. Auxiliary computations lead to the required specification. For example, other values of  $\alpha$  are obtained by modifying the x-grid spacing near the inlet, which depends on NI, EPSX and ALTOT, and comparing it with the corresponding r-grid spacing near the expansion corner. That is, XU(3) - XU(2) is compared with YV(JSTEP+2) - YV(JSTEP+1) to get the aspect ratio by the expansion corner. When a multi-cell step is envisioned a greater range of YV values are considered. Corresponding values of  $\alpha$  can be tabulated with various combinations of NI and EPSX, and the user can then judiciously choose an appropriate combination with JMAX(I) values for his needs.

Another parameter frequently requiring different values is swirl strength. The program is set up via LFS and LFSMAX to sequentially calculate through a range of seven swirl vane angles. These angles are specified in a DATA statement for the array VANB which is activated if NSBR = 0. If NSBR = 1 the swirl number for consecutive swirl numbers to be investigated is specified via a DATA statement for the array SWNB.

### 5. CLOSURE

The STARPIC computer program has been developed to predict swirling recirculating inert turbulent flows in axisymmetric combustion chambers. The technique involves a staggered grid system for axial and radial velocities, a line relaxation procedure for efficient solution of the equations, a two-equation k -  $\epsilon$  turbulence model, a stairstep boundary representation of the expansion flow, and realistic accommodation of swirl effects. Predictions of this type allow some results to be obtained more cheaply, quickly, and correctly than currently possible by the almost exclusive use of experimental means. Further development and application is providing a valuable supplementary technique for designers of practical combustion equipment.

This report has dealt with the computational problem and shown how the mathematical basis and computational scheme may be translated into a computer program. A flow chart, Fortran 4 listing, notes about various subroutines and a user's guide are supplied as an aid to prospective users of the code.

### 6. REFERENCES

- Lilley, D. G., Flowfield Modeling in Pratical Combustors: A Review,
   Journal of Energy, Vol. 3, July-Aug. 1979, pp. 193-210.
- 2. Lilley, D. G., Prospects for Computer Modeling in Ramjet Combustors, AIAA Paper No. 80-1189, Hartford, CT, June 30-July 2, 1980.
- Syred, N. and Beer, J. M., Combustion in Swirling Flows: A Review,
   Combustion and Flame, Vol. 23, 1974, pp. 143-201.
- 4. Lilley, D. G., Swirl Flows in Combustion: A Review, AIAA Journal, Vol. 15, No. 8, August 1977, pp. 1063-1078.
- 5. Beer, J. M. and Chigier, N. A., Combustion Aerodynamics, Applied Science, London and Halstead-Wiley, New York, 1972.
- 6. Gupta, A. K., Lilley, D. G. and Syred, N., Swirl Flows, Abacus Press, Tunbridge Wells, England, 1981.
- 7. Rhode, D. L., Lilley, D. G. and McLaughlin, D. K., On the Prediction of Swirling Flowfields Found in Axisymmetric Combustor Geometries. ASME Symposium on Fluid Mechanics of Combustion Systems, held in Boulder, Colorado, June 22-24, 1981.
- 8. Gerstein, M. (ed), Fundamentals of Gas Turbine Combustion, NASA-CP2087, 1979. Workshop held at NASA Lewis Research Center, Cleveland,
  OH, Feb. 6-7, 1979.
- 9. Murthy, S. N. B., Summary Report DOD Colloquium on Gas Turbine Combustor Modeling. Project SQUID Technical Report PU-R1-79, School of Mech. Engr., Purdue University [for ONR], Nov. 1979.
- 10. Lefebvre, A. H. (ed), Gas Turbine Combustor Design Problems, Hemisphere-McGraw-Hill, New York, 1980.
- 11. Launder, B. E. and Spalding, D. B., Mathematical Models of Turbulence, Academic Press, London, England, 1972.

- 12. Launder, B. E. and Spalding, D. B., The Numerical Computation of Turbulent Flows, Comp. Methods in Appl. Mech. and Engrg., Vol. 3, March 1974, pp. 269-289.
- Roache, P. J., Computational Fluid Dynamics, Hermosa, Albuquerque, NM,
   1972.
- 14. Chow, C.-Y., An Introduction to Computational Fluid Mechanics, Wiley, New York, NY, 1979.
- 15. Patankar, S. V., Numerical Heat Transfer and Fluid Flow, Hemisphere-McGraw-Hill, New York, 1980.
- 16. Gosman, A. D., Pun, W. M., Runchal, A. K., Spalding, D. B., and Wolfshtein, M. W., Heat and Mass Transfer in Recirculating Flows, Academic Press, London, England, 1969.
- 17. Gosman, A. D., and Pun, W. M., Calculation of Recirculating Flows, Rept.

  No. HTS/74/12, 1974, Dept. of Mechanical Engineering, Imperial

  College, London, England.
- 18. Gosman, A. D. and Ideriah, F. J. K., TEACH-2E: A General Computer Program for Two-Dimensional, Turbulent, Recirculating Flows. Report,

  Dept. of Mech. Eng., Imperial College, London, June 1976.
- 19. Lilley, D. G., Primitive Pressure-Velocity Code for the Computation of Strongly Swirling Flows, AIAA Journal, Vol. 14, June 1976, pp. 749-756.
- 20. Khalil, E. E., Spalding, D. B. and Whitelaw, J. H., The Calculation of Local Flow Properties in Two-Dimensional Furnaces, Int. J. Heat

  Mass Trans., Vol. 18, 1975, pp. 775-791.
- 21. Novick, A. S., Miles, G. A., and Lilley, D. G., Numerical Simulation of Combustor Flowfields: A Primitive Variable Design Capability, J. of Energy, Vol. 3, No. 2, March-April, 1979, pp. 95-105.

- 22. Wuerer, J. E. and Samuelsen, G. S., Predictive Modeling of Backmixed Combustor Flows: Mass and Momentum Transport, AIAA Paper 79-0215, New Orleans, LA., Jan. 15-17, 1979.
- 23. Habib, M. A. and Whitelaw, J. H., Velocity Characteristics of Confined Coaxial Jets With and Without Swirl, ASME Paper No. 79-WA/FE-21, New York, Dec. 2-7, 1979.
- 24. El Banhawy, Y. and Whitelaw, J. H., Calculation of the Flow Properties of a Confined Kerosene-Spray Flame, AIAA J., Vil. 18, No. 2, Dec. 1980, pp. 1503-1510.
- 25. Srinivasan, R. and Mongia, H. C., Numerical Computations of Swirling Recirculating Flows, Final Report, NASA-CR-165196, Sept. 1980.
- 26. Patankar, S. V. and Spalding, D. B., A Computer Model for Three-Demensional Flow in Furnaces, 14th Symp. (Int.) on Comb., The Comb. Inst., Pittsburgh, Pa., 1973, pp. 605-614.
- 27. Serag-Eldin, M. A. and Spalding, D. B., Computations of Three-Dimensional Gas-Turbine Combustion Chamber Flows, Trans. ASME J. of Eng. for Power, Vol. 101, July 1979, pp. 326-336.
- 28. Mongia, H. C. and Reynolds, R. S., Combustor Design Criteria Validation
  Vol. III User's Manual, Report USARTL-TR-78-55C, U.S. Army Res and
  Tech. Lab., Ft. Eustis, VA, Feb. 1979. [See also Vols. I and II].
- 29. Swithenbank, J., Turan, A. and Felton, P. G., Three-Dimensional Two-Phase Mathematical Modeling of Gas Turbine Combustors, in Gas Turbine Combustor Design Problems (Lefebvre, A. H. ed.), Hemisphere-McGraw-Hill, New York, 1980, pp. 249-314.
- 30. Spalding, D. B., A Novel Finite Difference Formulation of Differential Expressions Involving Both First and Second Derivatives, Int. J. Num. Meth. in Eng., Vol. 4, 1972, pp. 551-559.

- 31. Weske, D. R. and Sturov, G. Ye, Experimental Study of Turbulent Swirled Flows in a Cylindrical Tube, Fluid Mechanics Soviets Research, Vol. 3, No. 1, Jan.-Feb., 1974, pp. 77-82.
- 32. Blackshall, R. G. and Landis, F., The Boundary-Layer Velocity Distribution in Turbulent Swirling Pipe Flow, Journal Basic Engr., ASME

  Trans., Dec. 1969, pp. 728-733.
- 33. Date, A. W., Prediction of Fully-Developed Flow in a Tube Containing
  A Twisted Tape, Int. Jl. Heat Mass Transfer, Vol. 17, pp. 845-859.
- 34. Spalding, D. B., GENMIX A General Computer Program for Two-Dimensional Parabolic Phenomena. Pergamon Press, Oxford, England, 1977.

### 7. NOMENCLATURE

```
Α
                           Cell face area, Eq. (8)
a
                           Coupling coefficient, Eq. (11)
C
                           Contribution to cell surface integral, Eq. (10)
C,U,V
                           Control cell volumes for \phi, u, v, Fig. 3
D
                           Chamber diameter, Fig. 1
d
                           Nozzle diameter, Fig. 1
Ε
                           Constant in law of wall, Eq. (24)
                           Underrelaxation parameter, Eq. (42)
G
                           k - generation term, Eq. (4)
I,J
                           Mesh point, Fig. 2
k
                           Kinetic energy of turbulence, Eq. (1)
m
net
                          Net outflow of mass from cell, Eq. (9)
Рe
                           Cell Peclet number = \rho u \delta / \Gamma, Eq. (10)
р
                          Time-mean pressure, Eq. (1)
R
                           Residual source, Eq. (44)
S
                           Source term (with subscript), Eq. (1)
S_p, S_{II}
                          Components of linearized source term, Eq. (8)
                          Magnitude of total velocity vector, Eq. (24)
v = (u, v, w)
                          Time-mean velocity (in x,r,\theta directions), Eq. (1)
x,r,\theta
                          Axial, radial, circumferential polar
                          co-ordinates, Eq. (1)
                          Distance normal to a wall, Eq. (25)
У
Γ
                          Turbulent exchange coefficient, Eq. (1)
α
                          Side-wall angle, Fig. 1
Γ
                          Exchange coefficient, Eq. (7)
```

δχ	Axial distance between two neighboring mesh points, Fig. 4
ε	Turbulence energy dissipation rate, Eq. (1)
κ	Constant in log law, Eq. (24)
μ	Effective viscosity, Eq. (5)
ρ	Time-mean density, Eq. (1)
σ	Prandtl-Schmidt number, Eq. (6)
τ	Wall shear stress, Eq. (25)
ф	Swirl vane angle, Fig. l dependent variable, Eq. (1)
ψ	Stream function, Eq. (7)
Superscripts	
old	Last iterate value, Eq. (9)
*	Preliminary u, v and p field based on estimated pressure field p*, Eqs. (12)-(15)
•	Correction value to u*,v*,p* to get u,v,p, Eqs. (12)-(15)
Subscripts	
in	Inlet, Fig. 1
l.	Laminar value, Eq. (5)
n,s,e,w	North, south, east, west faces of cell, Eq. (8)
P,N,S,E,W	Point, north, south, east, west neighbors, Fig. 2
t	Tota1, Eq. (25)

•

# APPENDIX A DERIVATION OF THE HYBRID DIFFERENCING SCHEME

In the discussion of Section 2.2, it was remarked that a hybrid differencing scheme is used in representing the combined effects of convection and diffusion at cell boundaries. It possesses certain advantages over the well-known central and upstream differencing schemes, and it is convenient to provide here sufficient derivation, in the context of the present 2-D axisymmetric flow problem. The reasons and choices are aided by comparison of possible finite difference representations with the exact solution of a simplified 1-D convection and diffusion problem, whose solution values and flux calculations therefrom provides useful guidance.

Consider the transport across one face of a control volume, for example the western face of area  $A_W$  normal to the x-direction which lies midway between the gridpoints W and P distant  $\delta x$  apart, as shown earlier in Fig. 4. The contribution  $C_W$  of the convection and diffusion terms of Eq. (1) to the surface integral for the western face is

$$C_{\mathbf{W}} = \left[\rho u \phi - \Gamma_{\phi} \frac{\partial \phi}{\partial \mathbf{x}}\right]_{\mathbf{W}} A_{\mathbf{W}}$$
 (A1)

and the task is to derive a finite difference expression to represent the right hand side realistically in terms of  $\varphi$  and  $\Gamma_\varphi$  values at W and P using appropriate differencing. The choice will be aided by comparison with the exact solution of

$$\rho u \phi - \Gamma_{\phi} \frac{\partial \phi}{\partial x} = 0 \tag{A2}$$

in the interval W  $\leq$  x  $\leq$  P, taken without loss of generality to be  $0 \leq$  x  $\leq$   $\delta$ x, where  $\Gamma_{\varphi}$  =  $(\Gamma_{\varphi})_{W}$  = constant and  $\rho$  and u are presumed to be constant known values evaluated at x =  $\delta$ x/2. Solving this one-dimensional

Eq. (A2) subject to the two grid values

$$x = 0$$
  $\phi = \phi_W$  (A3)  $x = \delta x$   $\phi = \phi_D$ 

yields the solution

$$\phi = \phi_{W} + (\phi_{P} - \phi_{W}) \left[ \frac{e^{Pe \times /\delta x} - 1}{e^{Pe} - 1} \right]$$
(A4)

where the cell Peclet number has been defined by

$$Pe = \rho u \, \delta x / \Gamma_{\phi} \tag{A5}$$

which is evaluated at x =  $\delta x/2$ , i.e. at the western face of the cell around P. The exact solution, Eq. (A4), is portrayed in Fig. 12 where inspection shows that the value of  $\phi$  always lies within the extreme values of  $\phi_W$  and  $\phi_P$ . When Pe becomes very large and positive, because of axial velocity u being very large and from left to right in Fig. 3, the  $\phi$ -x curve is nearly horizontal and nearly equal to  $\phi_W$  at all points, with a steep rise to the value  $\Phi_P$  as x approaches  $\delta x$  (i.e. near P). Conversely when Pe is very large and negative, because of axial velocity u being very large and from right to left for example, the  $\phi$ -x curve is nearly equal to  $\phi_P$  at all points with the steep part near x = 0 (i.e. near W). When Pe is near to zero in value, the linear interpolation straight line is close to the exact solution.

The present task is to look at the net transfer of  $\varphi$  across the midplane at  $x=\delta x/2$  and to deduce a satisfactory finite difference analogue of the differential equation Eq. (A2) in terms of  $\varphi_W$  and  $\varphi_P$ . The flux of  $\varphi$  across the mid-plane at  $x=\delta x/2$  is

$$Q_{\delta x/2} = \left[\rho u \phi - \Gamma_{\phi} \frac{\partial \phi}{\partial x}\right]_{x = \delta x/2} \tag{A6}$$




Fig. 12.  $\varphi$  versus x curves for different values of the cell Peclet number Pe (assuming  $\varphi_W$  <  $\varphi_p).$ 

and upon substituting the exact solution for  $\phi$  and  $\frac{\partial \phi}{\partial x}$  at  $x = \delta x/2$  using Eq. (A4) yields (see Appendix B)

$$Q_{\delta x/2} = (\rho u)_{\delta x/2} \left\{ \frac{\phi_{W} e^{Pe} - \phi_{P}}{e^{Pe} - 1} \right\}$$

$$= (\rho u)_{\delta x/2} \left\{ \frac{\phi_{W} e^{Pe}}{e^{Pe} - 1} - \frac{\phi_{P} e^{-Pe}}{1 - e^{-Pe}} \right\}$$
(A7)

Three limits of this expression can be examined:

$$Pe \rightarrow + \infty$$
  $Q_{\delta x/2} \rightarrow (\rho u)_{\delta x/2} \cdot \phi_W$  (A8)

$$Pe \rightarrow -\infty \qquad Q_{\delta x/2} \rightarrow (\rho u)_{\delta x/2} \cdot \phi_{P}$$
 (A9)

$$|Pe| \rightarrow 0$$
  $Q_{\delta x/2} \rightarrow (\rho u)_{\delta x/2}$   $\left\{ \phi_{W} \frac{1 + Pe + ---}{Pe (1+Pe/2 + ---)} - \phi_{P} \frac{1 - Pe + ---}{Pe (1-Pe/2 + ---)} \right\}$  (A10)

$$= (\rho u)_{\delta x/2} (\phi_W + \phi_P)/2 - \Gamma_{\delta x/2} \frac{\phi_P - \phi_W}{\delta x}$$
 (A11)

where terms of order  $Pe^2$  and higher have been omitted from the last expression. Rearrangement and substitution of  $\Gamma_{\varphi}$ ,  $\delta x/2$  /  $\delta x$  for  $(\rho u)_{\delta x/2}$  / Pe has been made to obtain the final form of Eq. (All). This last equation is equivalent to central differencing of the diffusion part (in square brackets) of Eq. (Al). The first two limits of Eqs. (A8) and (A9) are the upstream convection dominated limits where diffusion terms are negligible. In computing it is necessary to use a finite difference expression for the flux passing the surface for the western face contribution

$$c_{W} = Q_{\delta \times /2} \cdot A_{W}$$
 (A12)

which exhibits these three limiting cases. The hybrid scheme recommended and used in Refs. 17-23 exhibits these properties via the use of

$$C_{W} = \begin{cases} (\rho u)_{W} A_{W} (\phi_{W} + \phi_{P}) / 2 - (\Gamma_{\phi})_{W} A_{W} (\phi_{P} - \phi_{W}) / \delta x \text{ for } |Pe| < 2 \\ (\rho u)_{W} A_{W} \phi_{W} \text{ for } Pe \ge 2 \\ (\rho u)_{W} A_{W} \phi_{P} \text{ for } Pe \le -2 \end{cases}$$
(A13)

where Pe =  $(\rho u)_W^{}$   $\delta x/(\Gamma_\phi^{})_W^{}$  is the cell Peclet number calculated at w. This hybrid scheme is denoted by HS.

Figure 13 shows the nondimensional flux passing the mid-plane at  $x - \delta x/2$  versus Peclet number Pe. Four lines are shown representing the exact solution ES, the hybrid scheme HS, the central difference scheme CDS and the upwind difference scheme UDS. These lines show the overall superiority of the HS over the CDS and UDS approaches, for the particular case considered in Appendix C. However, the result is quite general. These different schemes and the superiority of the hybrid scheme recommended and used in this work are fully discussed in Appendix C.




Fig. 13. Comparison of exact flux passing through western face with other approaches, as a function of Peclet number (ES, CDS, UDS, AND HS are described in Appendix C).

# APPENDIX B DERIVATION OF EQ. (A7) FROM EQ. (A6)

Equation (A4) gives  $\phi$  and  $\frac{\partial \phi}{\partial x}$  evaluated at  $x = \partial x/2$  as

$$\phi_{\delta x/2} = \phi_W + (\phi_P - \phi_W) \frac{e^{Pe/2} - 1}{e^{Pe} - 1}$$
 (B1)

and

$$\frac{\partial \phi}{\partial x} \Big|_{\delta x/2} = (\phi_{p} - \phi_{W}) \cdot \frac{1}{e^{Pe} - 1} \cdot \frac{Pe}{\delta x} \cdot e^{Pe/2}$$
(B2)

Substitution into Eq. (A6) gives, where  $\rho u = (\rho u)_{\delta x/2}$ :

$$\begin{split} Q_{\delta x/2} &= \rho u \quad \left\{ \varphi_W + (\varphi_P - \varphi_W) \; \frac{e^{Pe/2} - 1}{e^{Pe} - 1} \right\} \\ &- \Gamma_{\varphi} \; \left\{ (\varphi_P - \varphi_W) \; \frac{1}{e^{Pe} - 1} \; \cdot \; \frac{Pe}{\delta x} \cdot e^{Pe/2} \right\} \\ &= \rho u \; \varphi_W \left\{ 1 \; - \; \frac{e^{Pe/2} - 1}{e^{Pe} - 1} \; + \; \frac{e^{Pe/2}}{e^{Pe} - 1} \right\} \\ &+ \rho u \; \varphi_P \; \left\{ \frac{e^{Pe/2} - 1}{e^{Pe} - 1} \; - \; \frac{e^{Pe/2}}{e^{Pe} - 1} \right\} \end{split} \tag{B3}$$

on substituting for  $\Gamma_{\!\varphi}$  in terms of the Peclet number Pe =  $\rho u \delta x/\Gamma_{\!\varphi}.$  continuing

$$Q_{\delta x/2} = \rho u \phi_{W} \left\{ \frac{e^{Pe} - 1 + 1}{e^{Pe} - 1} \right\} + \rho u \phi_{P} \left\{ \frac{-1}{e^{Pe} - 1} \right\}$$

$$= (\rho u)_{\delta x/2} \left\{ \phi_{W} \frac{e^{Pe}}{e^{Pe} - 1} - \phi_{P} \frac{1}{e^{Pe} - 1} \right\}$$
(B4)

which is equivalent to Eq. (A7).

#### APPENDIX C THE SUPERIORITY OF THE HYBRID DIFFERENCING SCHEME

Here the concern is with exhibiting possible finite difference analogues of Eq. (A7) which expresses the exact solution for the flux  $Q = Q_{\delta x/2}$  passing the mid-plane  $x = \delta x/2$ , as a function of local density and axial velocity evaluated at this point  $\rho u = (\rho u)_{\delta x/2}$ , the local Peclet number Pe and the  $\phi$ -values at W and P. Three limiting cases for  $Pe \to +\infty$ ,  $Pe \to -\infty$  and  $|Pe| \to 0$  were given in Eqs. (A8) - (A11), the first two being upstream convection dominated and the last one being equivalent to simple averaging for the convection term and central differencing for the diffusion term.

In computing it is advantageous to use a finite difference analogue of Eq. (A2) which gives the best fit for this flux Q over a range of  $\rho$ , u,  $\Gamma$  and  $\delta x$  likely to be encountered, as expressed via the Peclet number Pe. The suffix  $\phi$  on  $\Gamma$  is omitted from here onward to avoid confusion. Nonsubscripted variables are evaluated at  $x = \delta x/2$ . The three popular practices, and the exact solution, are:

(i) CDS - the central difference scheme. For all Pe numbers, use

$$Q = \rho u \left( \phi_{\mathbf{p}} + \phi_{\mathbf{M}} \right) / 2 - \Gamma \left( \phi_{\mathbf{p}} - \phi_{\mathbf{M}} \right) / \delta x \tag{C1}$$

(ii) UDS - the upstream difference scheme. For all Pe numbers, use

$$Q = \begin{cases} \rho u \phi_{W} - \Gamma(\phi_{P} - \phi_{W})/\delta x & (u > 0) \\ \rho u \phi_{P} - \Gamma(\phi_{P} - \phi_{W})/\delta x & (u < 0) \end{cases}$$
 (C2)

(iv) ES - the exact solution. According to Pe number, use (see Eq. (A7)):

$$Q = \rho u \left\{ \frac{\phi_W e^{Pe}}{e^{Pe} - 1} - \phi_P \frac{e^{-Pe}}{1 - e^{-Pe}} \right\}$$
 (C4)

We wish to determine which of the CDS, UDS or HS is generally the best to use as an approximation to ES, over a range of Pe numbers. Nondimensionalizing the fluxes via

$$\hat{Q} = Q \cdot \frac{\delta X}{\Gamma} \cdot \frac{1}{\phi_{D} - \phi_{W}}$$
 (C5)

gives the following forms (using Pe =  $\rho u \delta x/\Gamma_{p}$  when required):

(i) CDS 
$$\hat{Q} = \frac{1}{2} \cdot Pe \cdot \frac{\Phi_P + \Phi_W}{\Phi_P - \Phi_W} - 1$$
 (C6)

(ii) UDS
$$\hat{Q} = \begin{cases}
Pe \cdot \frac{\varphi_W}{\varphi_P - \varphi_W} - 1 & (u > 0) \\
Pe \cdot \frac{\varphi_P}{\varphi_P - \varphi_W} - 1 & (u < 0)
\end{cases}$$
(C7)

(iii) HS
$$\hat{Q} = \begin{cases}
\frac{1}{2} \cdot \text{Pe.} & \frac{\phi_p + \phi_W}{\phi_p - \phi_W} - 1 & (|\text{Pe}| < 2) \\
\text{Pe.} & \frac{\phi_W}{\phi_p - \phi_W} & (\text{Pe} \ge 2, u > 0) \\
\text{Pe.} & \frac{\phi_p}{\phi_p - \phi_W} & (\text{Pe} \le 2, u < 0)
\end{cases}$$
(C8)

(iv) ES
$$\hat{Q} = Pe \begin{cases} \frac{\Phi_W e^{Pe}}{e^{Pe} - 1} - \frac{\Phi_P e^{-Pe}}{1 - e^{-Pe}} \end{cases}$$
(C9)

It is useful to examine limiting cases of the ES, in a manner similar to that used in obtaining Eqs. (A8) - (All). Now they are

$$\hat{Q} \rightarrow \begin{cases}
-1 & (|PE| \rightarrow 0) \\
Pe \cdot \frac{\phi_{W}}{\phi_{P} - \phi_{W}} & (Pe \rightarrow + \infty) \\
Pe \cdot \frac{\phi_{P}}{\phi_{P} - \phi_{W}} & (Pe \rightarrow - \infty)
\end{cases}$$
(C10)

In order to discriminate between the CDS, UDS and HS approaches to approximating the ES, we plot  $\hat{Q}$  versus Pe. The plot depends, of course, on the values of  $\varphi_p$  and  $\varphi_W$ . To illustrate the point, and without loss of generality of the result, let us take  $\varphi_W = 0$  and  $\varphi_p = 1$ . For this case the  $\hat{Q}$  versus Pe relationships to plot are:

(i) CDS 
$$\hat{Q} = \frac{1}{2} Pe - 1$$
 (C11)

(ii) UDS 
$$\hat{Q} = \begin{cases} -1 & (u > 0) \\ Pe - 1 & (u < 0) \end{cases}$$
 (C12)

(iii) HS
$$\hat{Q} = \begin{cases} \frac{1}{2} \text{ Pe } -1 \text{ (}|\text{Pe}| < 0) \\ 0 & \text{(Pe } \geq 2, \text{ u } > 0) \\ \text{Pe} & \text{(Pe } \leq -2, \text{ u } < 0) \end{cases}$$
(C13)

(iv) ES
$$\hat{Q} = -Pe \cdot \frac{e^{-Pe}}{1 - e^{-Pe}}$$
(C14)

The three limiting cases of the ES are also

$$\hat{Q} \rightarrow \begin{cases}
-1 & (|Pe| \rightarrow 0) \\
0 & (Pe \rightarrow + \infty) \\
-Pe & (Pe \rightarrow - \infty)
\end{cases}$$
(C15)

In Fig. 13 are plotted four lines labelled CDS, UDS, HS and ES, each of which represents  $\hat{\mathbb{Q}}$  as a function of Pe. That marked ES represents the exact solution and its three limiting cases are clearly seen. When |Pe| is small, ES tends to -1; this is the value appropriate to  $\hat{\mathbb{Q}}$  because of diffusion alone. When Pe is very large and positive,  $\hat{\mathbb{Q}}$  tends to 0; when Pe is very large in magnitude, but negative,  $\hat{\mathbb{Q}}$  tends to be equal to -Pe. With the CDS approach,  $\hat{\mathbb{Q}}$  tends to  $\frac{1}{2}$ Pe instead of zero when Pe is large and positive, and at the other extreme it tends to  $\frac{1}{2}$ Pe instead of Pe. These disagreements are quite severe. And, of course, the finite difference equation coefficients obtained with the CDS approach when |Pe| > 2 are such as to encourage divergence during an iterative solution procedure. The UDS approach of the other hand, has errors which are larger than the CDS approach for moderate values of Pe, but when |Pe| is large the UDS solution is more exact than the CDS one.

The HS approach combines the advantages of the CDS and UDS ideas and its corresponding straight lines are marked on the figure. Evidently this prescription is somewhat more accurate, overall, than either of its associated predecessors. It clearly tends to the asymptotes of 0 and -Pe, as Pe tends to  $+\infty$  and  $-\infty$  respectively (making it superior to the UDS for large values of |Pe|), and is equivalent to the CDS approach where the latter may be usefully employed when |Pe| < 2. The HS approach also happens to keep the finite difference coefficients within bounds which

ensure convergence of the iterative scheme for solving the resulting set of algebraic equations. Hence the recommendation and current use of the hybrid differencing scheme as given by Eq. (A13), and quoted earlier as Eq. (10).

### APPENDIX D FORTRAN SYMBOL LIST

A(J) Coefficient of recurrence relation AE(I,J)Coefficient of combined convective/diffusive flux through east-wall of control volume AL1 X-coordinate of inlet boundary of flow domain AL2 X-coordinate of outlet boundary of flow domain ALAMDA Length scale factor at inlet of flow domain ALPHA Inlet sloping wall expansion angle ALTOT Total length of pipe of larger diameter AN(I,J)Coefficient of combined convective/diffusive flux through north-wall of control volume AP(I,J)Sum of coefficients of combined convective/diffusive fluxes through all four walls of control volume AREAEW Area of east/west wall of control volume AREAN Area of north-wall of control volume AREAS Area of south-wall of control volume ARDEN Area of east/west cell-wall times density of fluid ARDENT Sum of all east/wall ARDEN at a cross-section AS(I,J)Coefficient of combined convective/diffusive flux through south-wall of control volume AW(I,J)Coefficient of combined convective/diffusive flux through west-wall of control volume B(J) Coefficient of recurrence formulae C(J)Coefficient of recurrence relation C1 Constant of turbulence model (=1.44) C2 Constant of turbulence model (=1.92)

Von Karman constant (=0.4187)

CAPPA

CD = Constant of turbulence model (=1.0)

CDTERM = CMU \* \* 0.25

CE = Coefficient of convective flux through east-wall of control

volume

CMU = Constant of turbulence model (=0.09)

CN = Coefficient of convective flux through north-wall of control

volume

CP = Maximum of zero and net outflow (SMP) from control volume

CPO = CP

CS = Coefficient of convective flux through south-wall of control

volume

CW = Coefficient of convective flux through west-wall of control

volume

D(J) = Coefficient of recurrence formulae

DE = Coefficient of diffusive flux through east-wall of control

volume

DEN(I,J) = Density of fluid

DENSIT = Density of fluid at inlet of the calculation domain

DITERM = Coefficient of volume integral of energy dissipation rate

in vicinity of walls

DN = Coefficient of diffusive flux through north-wall of control

volume

DS = Coefficient of diffusive flux through south-wall of control

volume

DU(I,K) = Coefficient of velocity-correction term for U velocity

DUDXE =  $\partial u/\partial x$  at eastern face of U-cell

DUDXW =  $\partial u/\partial x$  at western face of U-cell

DUDX =  $\partial u/\partial x$  at main grid node (I,J)

```
DUDY = \partial u/\partial y at main grid node (I,J)
```

DUDYE =  $\partial u/\partial y$  at mid-point of east wall of V-cell

DUDYW =  $\partial u/\partial y$  at mid-point of west wall of V-cell

DVDX =  $\partial v/\partial x$  at main grid node (I,J)

DVDXN =  $\partial v/\partial x$  at mid-point of north wall of U-cell

DVDXS =  $\partial v/\partial x$  at mid-point of south wall of U-cell

DVDY =  $\partial v/\partial y$  at main grid node (I,J)

DVDYN =  $\frac{\partial v}{\partial y}$  at mid-point of north wall of V-cell

DVDYS =  $\partial v/\partial y$  at mid-point of south wall of V-cell

DW = Coefficient of diffusive flux through west wall of control

volume

DWDX =  $\partial W/\partial x$  at main grid node (I,J)

DWDY =  $\partial W/\partial y$  at main grid node (I,J)

DXEP(I) = X(I+1)-X(I)

DXEPU(I) = XU(I+1)-XU(I)

DXPW(I) = X(I)-X(I-I)

DYNP(J) = Y(J+1)-Y(J)

DYNPV(J) = YV(J+1)-YV(J)

DYPS(J) = Y(J)-Y(J-1)

DYPSV(J) = YV(J)-YV(J-1)

ED(I,J) = Energy dissipation rate,  $\varepsilon$ 

EDIN = Energy dissipation rate at inlet of flow domain  $(\varepsilon_{in})$ 

ELOG = Constant of P-function for heat transfer at walls (=9.793)

EPSX = Grid expansion factor in axial direction

FACTOR = Area ratio for setting initial u-velocity field

FLOW = Mass flow rate at a cross-section based on calculated velocity

FLOWIN = Total mass flow rate entering pipes

GE = Mass flux through east-wall of cell

GEN(I,J) = Generation of turbulence by shear from mean flow

GENCOU = Part of generation term modified in terms of wall shear stress

GENRES = Total unmodified generation of turbulence (GEN(I,J)) less

 $\mu_{+}(\partial v/\partial x)^{2}$ .

GN = Mass flux through north-wall of cell

GNW = Mass flux through north-wall of u-cell

GP = Mass flux at location of velocity

GREAT = A very large value  $(10^{30})$ 

GS = Mass flux through south-wall of cell

GSW = Mass flux through south-wall of u-cell

HEDA = Heading 'KPLUS = TE \* RHO/TAUN'

HEDB = Heading 'LENGTH SCALE/PIPE RADIUS'

HEDD = Heading 'ENERGY DISSIPATION'

HEDDK = Heading 'DIMENSIONLESS TURBULENCE ENERGY'

HEDDP = Heading 'DIMENSIONLESS PRESSURE'

HEDDSL = Heading 'DIMENSIONLESS STREAMLINE COORDS'

HEDDU = Heading 'DIMENSIONLESS U VELOCITY'

HEDDV = Heading 'DIMENSIONLESS V VELOCITY'

HEDDVS = Heading 'DIMENSIONLESS EFF. VISCOSITY'

HEDDW = Heading 'DIMENSIONLESS W VELOCITY'

HEDK = Heading 'TURBULENCE ENERGY'

HEDM = Heading 'VISCOSITY'

HEDP = Heading 'PRESSURE'

HEDSF = Heading 'DIMENSIONLESS STREAM FUNCTION'

HEDSL = Heading 'RADIAL COORDINATE OF STREAMLINES'

HEDT = Heading 'TEMPERATURE'

HEDU = Heading 'U VELOCITY'

HEDV = Heading 'V VELOCITY'

I = Index for dependent variables, and co-ordinates

IFINE = Logical parameter for fine x-direction grid spacing

IMON = I-index of monitoring location

INCALA = Additional (unused) logical parameter for selection of

dependent variables

INCALB = Additional (unused) logical parameter for selection of

dependent variables

INCALD = Logical parameter for solution of  $\epsilon$ -equation

INCALK = Logical parameter for solution of k-equation

INCALM = Additional (unused) logical parameter for selection of

dependent variables

INCALP = Logical parameter for solution of P'-equation

INCALS = Logical parameter for calculation of stream function

INCALU = Logical parameter for solution of U-equation

INCALV = Logical parameter for solution of V-equation

INCALW = Logical parameter for solution of W-equation

INDCOS = Control index for definition of co-ordinate system

(= 1 for plane flows; = 2 for axisymmetric flows)

INITAL = Logical parameter to print initial field estimates

INPLOT = Logical parameter to produce line printer streamline plots

IREAD = Logical parameter to read initial field values from allocated

disk storage

IWRITE = Logical parameter to write solution field values to allocated

disk storage

INPRO = Logical parameter for updating of fluid properties

IPREF = I-index of location where pressure is fixed

IPRINT = If equal to NITER, activates printing of residual sums and
monitor values of field variables

ISTEP = I-index of entrance plane, within calculation domain

ISTM1 = ISTEP-1

ISTP1 = ISTEP+1

IT = I-index of maximum dimension of dependent variables

J = Index for dependent variables, and co-ordinate

JMAX(I) = Maximum value of j-index within flow domain

JMON = J-index of monitoring location

JPREF = J-index of location where pressure is fixed

JPRINT = If equal to NITER, activates printing of field variable values

JSTEP = J-index of horizontal plane next to wall of, and within,

smaller pipe

JSTM1 = JSTEP-1

JSTP1 = JSTEP+1

JT = J-index of maximum dimension of dependent variables

LFS = Index for counting loops for swirl

LFSMAX = Number of swirl loops to be run

MAXIT = Maximum number of iterations to be completed if iteration

sequence is not stopped by test on value of SORCE

NI = Maximum value of I-index

NIMI = NI-I

NITER = Number of iterations completed

NJ = Maximum value of J-index

NJM1 = NJ-1

NJM2 = NJ-2

NONDIM - Activates the calculation and printing of dimensionless solution when specified as true

NSBR = Zero value specifies flat W profile; the value one specifies solid body rotation

NSTLN = Number of streamlines calculated

NSWPD = Number of application of line iteration for  $\epsilon$ -equation

NSWPK = Number of application of line iteration for k-equation

NSWPP = Number of application of line iteration for P'-equation

NSWPU = Number of application of line iteration for U-equation

NSWPW = Number of application of line iteration for W-equation

P(I,J) = Pressure, P

PHI(I,J) = General representation for all dependent variables,  $\phi$ 

PP(I,J) = Pressure-correction, P'

PRANDT = Turbulent Prandtl number

PRED = Constant of turbulence model in  $\epsilon$ -equation,  $\sigma_{\epsilon}$ 

PRTE = Constant of turbulence model in k-equation,  $\sigma_{\epsilon}$ 

PSTAR(I,J)= Dimensionless pressure

R(J) = Radius of main grid node (I,J) from symmetry axis

RCV(J) = Radius of C- and U-cell center

RESOR = Residual source for individual control volume

RESORE = Sum of residual sources within calculation domain for  $\epsilon$ -equation

RSORK = Sum of residual sources within calculation domain for k-equation

RESORM = Sum of mass sources within calculation domain

RESORU = Sum of residual sources within calculation domain for U-equation

RESORV = Sum of residual sources within calculation domain for V-equation

RESORW = Sum of residual sources within calculation domain

RLARGE = Radius of large pipe

RSDRL = RSMALL/RLARGE

RSMALL = Radius of small pipe

RV(J) = Radius of location of V(I,J) from symmetry axis

SEW(I) = 0.5\*(DXEP(I) + DXPW(I))

SEWU(I) = 0.5\*(DXEPU(I) + DXPWU(I))

SMP = Net outflow from control volume

SNS(J) = 0.5\*(DYNP(J) + DYPS(J))

SNSV(J) = 0.5\*(DYNPV(J) + DYPSV(J))

SORCE = Maximum of RESORM, RESORU, RESORW, RESORK

SORMAX = Maximum acceptable value of SORCE for converged solution

SORVOL = GREAT \* VOL

SP(I,J) = Coefficient of linearized source treatment

SPKD(I,J) = -CP, for k- and  $\varepsilon$ -equations

SSC = Shear-stress coefficient

STFN(I,J) = Dimensionless stream function

STVAL(K) = Stream function value of streamlines

SU(I,J) = Coefficient of linearized source treatment

SUKD(I,J) = CPO \* TE(I,J), for k-equation

= CPO \* ED(I,J), for  $\varepsilon$ -equation

SWNB(LFS) = Inlet swirl number speciacation of WINST

SWRLNO = Calculated inlet swirl number

TAUN(I) = Shear stress at north wall-boundary of flow domain

TAURX = North wall shear stress, x-component

TAURW = North wall shear stress,  $\theta$ -component

TAUW(J) = Shear stress at west wall-boundary of flow domain

TAUXR = West wall shear stress, r-component

TAUXW = West wall shear stress,  $\theta$ -component

TE(I,J) = Turbulence energy, k

TESTAR(I,J) = Dimensionless turbulence energy

TEIN = Turbulence energy at inlet of flow domain  $(k_{in})$ 

TMULT = Coefficient of wall shear-stress expression

TURBIN = Turbulence intensity factor at inlet of flow domain

U(I,J) = Component of mean velocity in axial direction (u-velocity)

UEFF = SQRT[U(I,J)\*\*2 + W(I,J)\*\*2]

UIN = U-velocity at inlet of flow domain

UINC = Uniform increment of u-velocity at outlet of flow domain

ULARGE = UIN \* (RSMALL/RLARGE)\*\*2

UMEAN = Mean u-velocity at inlet

URFE = Under-relaxation factor for energy dissipation

URFK = Under-relaxation factor for turbulence energy

URFP = Under-relaxation factor for pressure-correction

URFU = Under-relaxation factor for u-velocity

URFV = Under-relaxation factor for v-velocity

URFVIS = Under-relaxation factor for viscosity

URFW = Under-relaxation factor for w-velocity

USTAR(I,J)= Dimensionless u-velocity

V(I,J) = Component of mean velocity in radial direction (v-velocity)

VANB(LFS) = Swirl vane angle

VAVG = Average v-velocity between nodes (I,J) and (I,J+1)

VDR = V(I,J)/RV(J)

VIS(I,J) = Effective viscosity

VISCOS = Laminar viscosity

VISE = Effective viscosity at mid-point of east-wall of cell

VISOLD = Value of effective viscosity before underrelaxation

VISN = Effective viscosity at mid-point of north-wall of cell

VISS = Effective viscosity at mid-point of south-wall of cell

VISTAR(I,J)= Dimensionless effective viscosity

VISW = Effective viscosity at mid-point of west-wall of cell

VOL = Volume of cell or control-volume

VSTAR(I,J)= Dimensionless v-velocity

W(I,J) = w-velocity

WIN = Inlet w-velocity from swirl vanes

WINST = Inlet w-velocity at JSTEP from solid body rotation swirl

generator

WMONIN = Inlet swirl momentum

WSTAR(I,J)= Dimensionless w-velocity

X(I) = Distance from inlet plane in axial direction

XMONIN = Momentum of fluid at inlet of flow domain

XND(I) = Dimensionless X(I)

XPLUSW(I) = Local Reynolds number based on friction velocity and

distance from west wall-boundary of flow domain

XU(I) = X-coordinate of storage location of U(I,J)

XUDPLT(I) = Dimensionless XU(I) required for line printer streamline

plots

Y(J) = Distance from symmetry axis in radial direction

YND(J) = Dimensionless Y(J)

YPLUSN(J) = Local Reynolds number based on friction velocity and distance

from north wall-boundary of flow domain

YSLOPE = Height of first stairstep along sloping wall

YSLPLT(N,I)= Dimensionless YSTLN(I,K) required for line printer streamline

plots

YSTLN(I,K) = Radial coordinate of points representing streamlines

YSTLND(I,K) = Dimensionless YSTLN(I,K)

YV(J) = Y-coordinate of storage location of V(I,J)

YUND(J) = Dimensionless YV(J)

#### APPENDIX E COMPUTER PROGRAM LISTING

The computer program listing obtained for the sample computation described in Section 4.3 is now given.

```
0000100
C
             SUBROUTINE CONTRO
                                                                                                                                                                         0000200
0000400
                                                                                                                                                                         0000500
С
              A COMPUTER PROGRAM FOR TURBULENT, SWIRLING, RECIRCULATING,
С
                                                                                                                                                                         0000600
                                                                                                                                                                         0000700
С
              FLOW IN COMBUSTOR GEOMETRIES
                                                                                                                                                                         0000800
C
                                                                                                                                                                         0000900
              VERSION OF APRIL, 1981
                                                                                                                                                                         0001000
                                                                                                                                                                         0001100
С
              D L RHODE & D G LILLEY
             MECHANICAL AND AEROSPACE ENGINEERING OKLAHOMA STATE UNIVERSITY
C
                                                                                                                                                                         0001200
                                                                                                                                                                         0001300
                                                                                                                                                                         0001400
C
              STILLWATER, OK
                                                         74078
                                                                                                                                                                         0001500
C
                                                                                                                                                                          0001600
0001800
CHAPTER 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0 0 0 0 0
                                                                                                                                                                         0001900
           DIMENSION HEDU(9), HEDV(9), HEDW(9), HEDP(9), HEDT(9), HEDK(9), HEDD(9), HEDM(9), HEDL(9), VANB(7), SWNB(7), HEDSF(9), HEDSL(9), HEDDU(9), HEDDU(9
                                                                                                                                                                          0002000
                                                                                                                                                                         0002100
                                                                                                                                                                         0002200
            #HEDDP(9), HEDDK(9), HEDDSL(9), HEDDVS(9)
                                                                                                                                                                          0002300
                                                                                                                                                                          0002400
              DIMENSION YAXES(10), SYMB L(10)
                                                                                                                                                                          0002500
              COMMON
           1/UVEL/RESORU, NSWPU, URFU, DXEPU(48), DXPWU(48), SEWU(48)
                                                                                                                                                                         0002600
            1/VVEL/RESORV, NSWPV, URFV, DYNPV(24), DYPSV(24), SNSV(24)
                                                                                                                                                                         0002700
           */NVEL/ RESORW, NSWPW, URFW
1/PCOR/RESORM,NSWPP,URFP,DU(48,24),DV(48,24),IPREF,JPREF
                                                                                                                                                                         0002800
                                                                                                                                                                         0002900
            1/TEN/RESORK, NSWPK, URFK
            1/TDIS/RESORE, NSWPD, URFE
                                                                                                                                                                          0003100
           **VVARYU(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), 0003200
*ED(48,24),STFN(48,24),YSTLN(48,24),STVAL(24),USTAR(48,24), 0003300
*VSTAR(48,24),WSTAR(48,24),PSTAR(48,24),TESTAR(48,24),YSTLND(48,24)
                                                                                                                                                                         0003500
            #, VISTAR(48,24)
            1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
                                                                                                                                                                         0003600
            1/GEOM/INDCOS,X(48),Y(24),DXEP(48),DXPW(48),DYNP(24),DYPS(24),
1 SNS(24),SEW(48),XU(48),YV(24),R(24),RV(24),
                                                                                                                                                                         0003700
                                                                                                                                                                         0003800
               WFN(24), WFS(24), WFE(48), WFW(48), RCV(24), XND(48), XUND(48),
                                                                                                                                                                         0003900
            #YND(24), YVND(24)
                                                                                                                                                                          0004000
                                                                                                                                                                          0004100
            1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
                                                                                                                                                                         0004200
            1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                                                                                                                         0004300
            2 RSMALL,RLARGE,AL1,AL2,JSTEP,ISTEP,JSTP1,JSTM1,ISTP1,ISTM1
1/TURB/GEN(48,24),CD,CMU,C1,C2,CAPPA,ELOG,PRED,PRTE
1/WALLF/YPLUSN(48),XPLUSW(24),TAUN(48),TAUW(24)
                                                                                                                                                                          0004400
                                                                                                                                                                          0004500
                                                                                                                                                                          0004600
            Ī/COĒĒ/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24), 0004700
                            SP(48,24)
                                                                                                                                                                          0004800
            I/PLOTT/NSTIN,NPLTLN,NPTS,YSLPLT(10,48),XUDPLT(48),INPLOT
  LOGICAL INCALU,INCALV,INCALW,INCALP,INPRO,INCALK,INCALD,INCALM,
*INCALA,INCALB,INCALS,INPLOT,IWRITE,NONDIM,IREAD,INLET,
                                                                                                                                                                          0004900
                                                                                                                                                                         0005000
                                                                                                                                                                          0005100
                                                                                                                                                                          0005200
            *INITAL, IFINE
                   --ALL PRIMARY USER INPUTS ARE LOCATED HERE
                                                                                                                                                                          0005300
            DATA VANB /0.,45.,55.,60.,65.,68.,70./
#,SWNB/0.,.5,1.0,1.25,1.50,1.75,2.0/
DATA XAXIS /3HXI /
                                                                                                                                                                          0005400
                                                                                                                                                                          0005500
                                                                                                                                                                          0005600
DATA YAXES /3H 00,3H 02,3H 04,3H 06,3H 08,3H 10, 0005700  
#3H 06,3H 07,3H 08,3H 09/ 0005800  
DATA SYMB L /1H0,1H2,1H4,1H6,1H8,1H1,1H6,1H7,1H8,1H9/ 0005900  
C-----DELETE UNDERFLOW ERROR MESSAGES, CALL TRAPS WHEN USING WATFIV 0006000
```

```
C-----CALL TRAPS(1,1,4000)

CALL ERRSET(208,256,-1,1,0,0)

C----SET INPLOT=.TRUE. ONLY FOR STREAMLINE LINE-PRINTER PLOT
                                                                                   0006100
                                                                                   0006200
                                                                                   0006300
INPLOT=.TRUE.
C----SET IWRITE=.TRUE. ONLY FOR WRITING SOLN. ON DATA FILES
                                                                                   0006400
                                                                                   0006500
IWRITE=.FALSE.
C-----SET NONDIM=.TRUE. ONLY FOR PRINTING DIMENSIONLESS SOLN.
                                                                                   0006600
                                                                                   0006700
NONDIM=.TRUE.

C----SET IREAD=.TRUE. ONLY FOR READING INITIAL GUESS OF SOLN.

C------ FROM DATA FILES
                                                                                   0006800
                                                                                   0006900
                                                                                   0007000
                                                                                   0007100
     IREAD=.FALSE
C----SET INITAL=.TRUE. ONLY FOR PRINTING INITIAL GUESS OF SOLN.
                                                                                   0007200
                                                                                   0007300
     INITAL=.TRUE
C----SET IFINE=.TRUE. ONLY FOR FINE GRID IN X-DIRECTION IFINE=.FALSE.
                                                                                   0007400
                                                                                   0007500
       IF(.NOT. IREAD) GO TO 150 READ(12) X
                                                                                   0007600
                                                                                   0007700
                                                                                   0007800
       READ(12) Y
                                                                                   0007900
  150 CONTINUE
                                                                                   0008000
       NSTLN=11
                                                                                   0008100
       NPLTLN=6
                                                                                   0008200
       MAXLN=10
                                                                                   0008300
       NITER=0
                                                                                   0008400
       JPRINT=NITER+300
                                                                                   0008500
       IPRINT=NITER+1
                                                                                   0008600
       LFS=1
                                                                                   0008700
       LFSMAX=7
                                                                                   0008800
       NSBR=0
                                                                                   0008900
       MAXIT=NITER+200
C-----SEE STATEMENT 304 FOR MAXIT SPEC. FOR FURTHER SWIRL CASES
                                                                                   0009000
                                                                                   0009100
       DENSIT=1.211
                                                                                   0009200
       IT=48
                                                                                   0009300
       JT=24
                                                                                   0009400
       GREAT=1.E30
                                                                                   0009500
       NSWPU=4
                                                                                   0009600
       NSWPV=3
                                                                                   0009700
       NSWPW=3
                                                                                   0009800
       NSWPP=5
                                                                                   0009900
       NSNPK=3
                                                                                   0010000
       NSWPD=3
       READ(5,10) HEDU, HEDV, HEDW, HEDP, HEDT, HEDK, HEDD, HEDM, HEDL,
                                                                                   0010100
                                                                                   0010200
      $HEDSF, HEDSL, HEDDU, HEDDV, HEDDW, HEDDP, HEDDK, HEDDVS
                                                                                   0010300
  010 FORMAT(9A4)
                                                                                   0010400
CHAPTER 1 1 1 1 1 PARAMETERS AND CONTROL INDICES 1 1 1 1 1 0010500
                                                                                   0010600
                                                                                   0010700
    -----GRID
                                                                                   0010800
       ISTEP=2
                                                                                   0010900
       JSTEP=8
                                                                                   0011000
       INDCOS=2
                                                                                   0011100
       NJ=21
                                                                                   0011200
       NJM1=NJ-1
                                                                                   0011300
       ISTP1=ISTEP+1
                                                                                   0011400
       ISTM1=ISTEP-1
                                                                                   0011500
       JSTP1=JSTEP+1
                                                                                   0011600
       JSTM1=JSTEP-1
       RLARGE=.0625
ALTOT=.375
                                                                                   0011700
                                                                                   0011800
IF(IFINE) GO TO 120
C----COARSE MESH GRID LINES IN X-DIRECTION
                                                                                   0011900
                                                                                   0012000
```

```
0012100
       NI=20
                                                                                       0012200
       NIM1=NI-1
                                                                                       0012300
       EPSX=1.11
       IF(EPSX-1.) 13,12,13
SUMX=0.5*EPSX**(NI-4)+(EPSX**(NI-3)-1.)/(EPSX-1.)+0.5
                                                                                       0012400
                                                                                       0012500
13
                                                                                       0012600
       GO TO 15
                                                                                       0012700
12
       CONTINUE
                                                                                       0012800
       SUMX=NIM1-1
                                                                                       0012900
       DX=ALTOT/SUMX
15
                                                                                       0013000
       X(1)=-.5*DX
X(2)=-X(1)
                                                                                       0013100
                                                                                       0013200
       DO 100 I=3,NIM1
X(1)=X(I-1)+DX
                                                                                       0013300
                                                                                       0013400
  100 DX=EPSX*DX
                                                                                       0013500
       X(NI)=X(NIM1)+(X(NIM1)-X(NI-2))
       X(21)=X(20)+(X(20)-X(19))
X(22)=X(21)+(X(20)-X(19))
                                                                                       0013600
                                                                                        0013700
                                                                                        0013800
       X(23)=X(22)+(X(20)-X(19))
                                                                                        0013900
       NI=23
                                                                                        0014000
       NIM1=NI-1
                                                                                        0014100
       ALTOT=(X(22)+X(23))/2.
                                                                                        0014200
       AL1=0.5*(X(ISTEP)+X(ISTM1))
                                                                                        0014300
       AL2=ALTOT-AL1
                                                                                        0014400
       ----FINE MESH GRID LINES IN X-DIRECTION IF(.NOT. IFINE) GO TO 130
                                                                                        0014500
                                                                                       0014600
  120 NI=30
                                                                                        0014700
       NIM1=NI-1
                                                                                        0014800
       EPSX=1.102
                                                                                        0014900
       IF(EPSX-1.) 17,16,17
       SUMX=0.5*EPSX**(NI-4)+(EPSX**(NI-3)-1.)/(EPSX-1.)+0.5
                                                                                        0015000
17
                                                                                        0015100
       GO TO 18
                                                                                        0015200
       CONTINUE
16
                                                                                        0015300
       SUMX=NIM1-1
                                                                                        0015400
       DX=ALTOT/SUMX
18
                                                                                        0015500
       X(1) = -.5 \times DX
                                                                                        0015600
       X(2) = -X(1)
                                                                                        0015700
       DO 170 I=3, NIM1
X(I)=X(I-1)+DX
                                                                                        0015800
                                                                                        0015900
   170 DX=EPSX*DX
                                                                                        0016000
       X(NI)=X(NIM1)+(X(NIM1)-X(NI-2))
  DO 180 L=31,35
180 X(L)=X(L-1)+(X(NI)-X(NIM1))
                                                                                        0016100
                                                                                        0016200
                                                                                        0016300
       NI=35
                                                                                        0016400
       NIM1=NI-1
                                                                                        0016500
       ALTOT=(X(NIM1)+X(NI))/2.
                                                                                        0016600
       AL1=0.5*(X(ISTEP)+X(ISTM1))
AL2=ALTOT-AL1
                                                                                        0016700
C----SPECIFY RADIAL HEIGHT(NO. OF J-CELLS) OF COMBUSTOR C---- WALL FOR EACH I GRID LINE
                                                                                        0016800
                                                                                        0016900
                                                                                        0017000
  130 CONTINUE
                                                                                        0017100
       JMAX(1)=JSTEP
                                                                                        0017200
        JMAXP1(1)=JMAX(1)+1
                                                                                        0017300
       DO 160 I=2, NI
JMAX(I)=JMAX(I-1)+3
                                                                                        0017400
        IF(JMAX(I-1) .EQ. NJM1) JMAX(I)=JMAX(I-1)
                                                                                        0017500
                                                                                        0017600
   160 JMAXP1(I)=JMAX(I)+1
                                                                                        0017700
        ----GRID LINES IN Y-DIRECTION
       Y(1)=-1.5625E-3
Y(2)=1.5625E-3
                                                                                        0017800
                                                                                        0017900
                                                                                        0018000
       Y(3)=5.625E-3
```

```
Y(4)=1.0625E-2
                                                                                0018100
       Y(5)=1.625E-2
                                                                                0018200
       Y(6)=2.1875E-2
                                                                                0018300
      Y(7)=2.6875E-2
Y(8)=3.03125E-2
Y(9)=3.21875E-2
                                                                                0018400
                                                                                 0018500
                                                                                0018600
      Y(10)=3.4375E-2
Y(11)=3.71875E-2
                                                                                0018700
                                                                                0018800
       Y(12)=4.09375E-2
                                                                                0018900
      Y(13)=4.328125E-2
Y(14)=4.5625E-2
Y(15)=4.8125E-2
                                                                                0019000
                                                                                0019100
                                                                                0019200
       Y(16)=5.078125E-2
                                                                                0019300
      Y(17)=5.34375E-2
Y(18)=5.59375E-2
Y(19)=5.9375E-2
                                                                                0019400
                                                                                0019500
                                                                                0019600
      Y(20)=6.1875E-2
                                                                                0019700
       Y(21)=6.3125E-2
                                                                                0019800
      RSMALL=0.5*(Y(JSTEP)+Y(JSTP1))
                                                                                0019900
C-----DEPENDENT VARIABLE SELECTION
                                                                                0020000
      INCALU=.TRUE.
INCALV=.TRUE.
                                                                                0020100
                                                                                0020200
      INCALW=.TRUE.
                                                                                0020300
      INCALP=.TRUE.
                                                                                0020400
       INCALK=.TRUE.
                                                                                0020500
      INCALD=.TRUE.
                                                                                0020600
      INPRO=.TRUE.
INCALS=.TRUE
                                                                                0020700
                                                                                0020800
C----FLUID PROPERTIES
                                                                                0020900
C----TURBULENCE CONSTANTS
                                                                                0021000
0021100
      CMU=0.09
      CD=1.00
                                                                                0021200
      CI=1.44
                                                                                0021300
      C2=1.92
                                                                                0021400
      CAPPA=.4187
                                                                                0021500
      ELOG=9.793
                                                                                0021600
      PRED=CAPPA*CAPPA/(C2-C1)/(CMU**.5)
                                                                                0021700
      PRTE=1.0
                                                                                0021800
C----BOUNDARY VALUES
                                                                                0021900
      UIN=30.
                                                                                0022000
      ULARGE=UIN*(RSMALL/RLARGE)**2
                                                                                0022100
      TURBIN=.03
                                                                                0022200
      TEIN=TURBIN*UIN**2
                                                                                0022300
      ALAMDA=0.005
                                                                                0022400
0022500
      EDIN=TEIN**1.5/(ALAMDA*RLARGE)
      VISCOS=1.8E-5
                                                                                0022600
C----PRESSURE CALCULATION
                                                                                0022700
      IPREF=2
                                                                                0022800
      JPREF=2
                                                                                0022900
C----PROGRAM CONTROL AND MONITOR
                                                                                0023000
      IMON=NIM1
                                                                                0023100
      JMON=8
                                                                                0023200
      SORMAX=.004
                                                                                0023300
                                                                                0023400
      R 2 2 CALL INIT
CHAPTER
               0023600
  -----NONDIMENSIONALIZE X & Y VARIABLES FOR NONDIMENSIONAL OUTPUT
                                                                                0023700
      DO 50 I=1,NI
                                                                                0023800
      XND(I)=X(I)/(2.*RLARGE)
                                                                                0023900
   50 XUND(I)=XU(I)/(2.*RLARGE)
                                                                                0024000
```

```
DO 60 J=1,NJ
YND(J)=Y(J)/(2.*RLARGE)
                                                                                 0024100
                                                                                 0024200
                                                                                 0024300
   60 YVND(J)=YV(J)/(2.*RLARGE)
                                                                                 0024400
     ----INITIALISE VARIABLE FIELDS
                                                                                 0024500
      FLOWIN=0.0
                                                                                 0024600
      ARDEN=0.0
                                                                                 0024700
      ARDENT=0.
                                                                                 0024800
      XMONIN=0.
                                                                                 0024900
      WMONIN=0.0
                                                                                 0025000
      ANGMOM=0.
                                                                                 0025100
C
                                                                                 0025200
C----INLET SWIRL VELOCITY PROFILE
                                                                                 0025300
C
                                                                                 0025400
             USE SOLID BODY ROTATION MODEL
C----W,
                                                                                 0025500
      WINST=2.*SWNB(LFS)/(1.+SWNB(LFS))*UIN
  DO 206 J=2,JSTEP
206 W(1,J)=WINST*R(J)/R(JSTEP)
                                                                                 0025600
                                                                                 0025700
0025800
                                                                                 0025900
                                                                                 0026000
                                                                                 0026100
                                                                                 0026200
                                                                                 0026300
  DO 207 J=2,JSTEP
207 W(1,J)=WIN
                                                                                 0026400
                                                                                 0026500
  208 CONTINUE
C------INITIALIZE U-, TE-, ED-, & W-FIELDS DO 200 J=2, JSTEP
                                                                                 0026600
                                                                                 0026700
                                                                                 0026800
      U(2,J)=UIN
                                                                                 0026900
       TE(1,J)=TEIN
                                                                                 0027000
       ED(1,J)=EDIN
                                                                                 0027100
       ARDEN=0.5*(DEN(1,J)+DEN(2,J))*RCV(J)*SNS(J)
      XMONIN=XMONIN+ARDEN*U(2,J)*U(2,J)
                                                                                 0027200
      WMONIN=WMONIN+ARDEN*U(2,J)*W(1,J)
ANGMOM=ANGMOM+ARDEN*U(2,J)*W(1,J)*R(J)
                                                                                 0027300
                                                                                 0027400
                                                                                 0027500
       ARDENT=ARDENT+ARDEN
                                                                                 0027600
  200 FLOWIN=FLOWIN+ARDEN*U(2,J)
                                                                                 0027700
       UMEAN=FLOWIN/ARDENT
       SWRLNO=ANGMOM/(XMONIN*RSMALL)
                                                                                 0027800
      IF(W(1,JSTEP) .EQ. 0.) WMONIN=1.
DO 202 I=2,NI
IJ=JMAXP1(I-1)
                                                                                 0027900
                                                                                 0028000
                                                                                 0028100
       FACTOR=(YV(JSTP1)*RV(JSTP1))/(YV(IJ)*RV(IJ))
                                                                                 0028200
                                                                                 0028300
       JJ=JMAX(I-1)
                                                                                 0028400
      DO 202 J=2,JJ
U(I,J)=UIN*FACTOR
                                                                                 0028500
                                                                                 0028600
202
       CONTINUE
                                                                                 0028700
      IF(NSBR .EQ. 0) GO TO 219
DO 209 I=2,NI
                                                                                 0028800
                                                                                 0028900
                                                                                 0029000
       (I)XAML=LL
       DO 209 J=2,JJ
WINST=2.*SWNB(LFS)/(1.+SWNB(LFS))*U(I,2)
                                                                                 0029100
                                                                                 0029200
                                                                                 0029300
       W(I,J)=WINST*R(J)/R(JJ)
       TE(I,J)=TEIN
                                                                                 0029400
  ED(I,J)=EDIN
209 CONTINUE
                                                                                 0029500
                                                                                 0029600
                                                                                 0029700
       GO TO 221
                                                                                 0029800
С
                                                                                 0029900
219
       CONTINUE
                                                                                 0030000
       DO 220 I=2,NI
```

```
JJ=JMAX(I)
                                                                                            0030100
       DO 220 J=2,JJ
TE(I,J)=TEIN
                                                                                            0030200
                                                                                            0030300
       ED(I,J)=EDIN
                                                                                            0030400
  220 CONTINUE
                                                                                            0030500
C
                                                                                            0030600
  221 CONTINUE
                                                                                            0030700
       DO 203 I=2, NIM1
                                                                                            0030800
  203 YPLUSH(I)=11.0
                                                                                            0030900
       DO 204 J=JSTEP,NJ
XPLUSW(J)=11.0
                                                                                            0031000
                                                                                            0031100
  204 IF(J.EQ.JSTEP) XPLUSW(J)= 0.0
                                                                                            0031200
       URFVIS=.7
                                                                                            0031300
CALL PROPS
C----INITIAL OUTPUT
                                                                                            0031400
                                                                                            0031500
       WRITE(6,211)
                                                                                            0031600
       IK=JMAXP1(ISTEP)
                                                                                            0031700
       YSLOPE=YV(IK)-YV(JSTP1)
                                                                                            0031800
       IF(JMAX(ISTEP) .LT. NJM1) ALPHA=ATAN(YSLOPE/SEWU(2))*180./3.14159
IF(JSTEP .LT. NJM1) .AND. (JMAX(ISTEP) .EQ. NJM1)) ALPHA=90.
                                                                                            0031900
                                                                                            0032000
       WRITE(6,225) ALPHA
WRITE(6,235) RSMALL
                                                                                            0032100
                                                                                            0032200
       WRITE(6,240) RLARGE
WRITE(6,245) ALTOT
RE=UIN*RSMALL*2.0*DENSIT/VISCOS
                                                                                            0032300
                                                                                            0032400
                                                                                            0032500
       WRITE(6,250) RE
WRITE(6,255) VISCOS
                                                                                            0032600
                                                                                            0032700
       RSDRL=RSMALL/RLARGE
                                                                                            0032800
  WRITE(6,260) DENSIT
295 CONTINUE
                                                                                            0032900
                                                                                            0033000
       IF(.NOT. IWRITE) GO TO 297
                                                                                            0033100
       WRITE(11) X
                                                                                            0033200
       WRITE(11) Y
                                                                                            0033300
       WRITE(14) XUND
                                                                                            0033400
  297 CONTINUE
                                                                                            0033500
       IF(.NOT. IREAD) GO TO 298
                                                                                            0033600
       READ(12) U
                                                                                            0033700
       READ(12) V
                                                                                            0033800
       READ(12) W
                                                                                            0033900
       READ(12) P
                                                                                            0034000
       READ(12) TE
                                                                                            0034100
       READ(12) ED
                                                                                            0034200
       READ(12) VIS
                                                                                            0034300
       READ(12) STFN
                                                                                            0034400
  298 CONTINUE
                                                                                            0034500
       IF(.NOT. INITAL) GO TO 299
IF(INCALU) CALL PRINT(1,1,NI,NJ,IT,JT,XU,Y,U,HEDU)
                                                                                            0034600
                                                                                            0034700
       IF(INCALV) CALL PRINT(1,1,NI,NJ,IT,JT,X,YV,V,HEDV)
IF(INCALW) CALL PRINT(1, 1, NI, NJ, IT, JT, X, Y, W, HEDW)
IF(INCALK) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,TE,HEDK)
                                                                                            0034800
                                                                                            0034900
                                                                                            0035000
       IF(INCALD) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,ED,HEDD)
                                                                                            0035100
  299 CONTINUE
                                                                                            0035200
       RESORU=.005
                                                                                            0035300
       URFP=1
                                                                                            0035400
       RESORV=.005
                                                                                            0035500
       RESORW=.005
                                                                                            0035600
                                                                                            0035700
CHAPTER 3 3 3 3 3 3 3 ITERATION LOOP 3 3 3 3 3 3 3 3
                                                                                            0035800
                                                                                            0035900
       WRITE(6,310) IMON, JMON
                                                                                            0036000
```

```
0036100
  300 NITER=NITER+1
                                                                                                                        0036200
  DO 330 I=2,NIM1
DO 330 J=2,NJM1
330 PP(I,J)=0.
                                                                                                                        0036300
                                                                                                                        0036400
                                                                                                                        0036500
         IF(LFS .GE. 3) GO TO 425
                                                                                                                        0036600
         URFU=.5
                                                                                                                        0036700
         URFV=.5
                                                                                                                        0036800
         URFW=.6
                                                                                                                        0036900
         URFK=.7
                                                                                                                        0037000
         URFE=.7
URFVIS=.7
                                                                                                                        0037100
  IF(LFS .LT. 3) GO TO 430 425 CONTINUE
                                                                                                                        0037200
                                                                                                                        0037300
         ----INCREASE UNDERRELAXATION FACTORS AS CONVERGENCE NEARS
                                                                                                                        0037400
         URFU=.15+(FLOAT(NITER))*((.35-.15)/40.)
IF(URFU .GT. .35) URFU=.35
URFV=.20+(FLOAT(NITER))*((.25-.20)/40.)
                                                                                                                        0037500
                                                                                                                        0037600
                                                                                                                        0037700
                                                                                                                        0037800
         IF(URFV .GT. .25) URFV=.25
                                                                                                                        0037900
         URFW=.50+(FLOAT(NITER))*((.60-.50)/40.)
                                                                                                                        0038000
         IF(URFW .GT. .60) URFW=.60
         URFK=.70
URFE=.70
                                                                                                                        0038100
                                                                                                                        0038200
                                                                                                                        0038300
         URFVIS=.70
IF((RESORV .LT. .08) .AND. (RESORU .LT. .10)) URFU=.40
IF((RESORV .LT. .06) .AND. (RESORU .LT. .08)) URFU=.45
IF((RESORK .LT. .10E-1) .AND. (RESORE .LT. .10E+10)) URFE=.75
IF((RESORK .LT. .4E-2) .AND. (RESORE .LT. .5E+9)) URFE=.80
IF(RESORU .LT. SORMAX) URFU=.20
IF(RESORV .LT. SORMAX) URFV=.20
IF(RESORW .LT. SORMAX) URFW=.25
IF(RESORK .LT. .10E-2) URFK=.60
IF(RESORE .LT. .10E+8) URFE=.55
CONTINUE
         URFVIS=.70
                                                                                                                        0038400
                                                                                                                        0038500
                                                                                                                        0038600
                                                                                                                        0038700
                                                                                                                        0038800
                                                                                                                        0038900
                                                                                                                        0039000
                                                                                                                        0039100
                                                                                                                        0039200
                                                                                                                        0039300
   430 CONTINUE
                                                                                                                        0039400
C----- UPDATE MAIN DEPENDENT VARIABLES
                                                                                                                        0039500
         IF(INCALU) CALL CALCUIF(INCALV) CALL CALCV
                                                                                                                        0039600
         IF(INCALP) CALL CALCP
IF(INCALW) CALL CALCW
                                                                                                                        0039700
                                                                                                                        0039800
         IF(INCALK) CALL CALCTE
IF(INCALD) CALL CALCED
-----UPDATE FLUID PROPERITIES
                                                                                                                        0039900
                                                                                                                        0040000
                                                                                                                        0040100
IF(INPRO) CALL PROPS
C----INTERMEDIATE OUTPUT
                                                                                                                        0040200
                                                                                                                        0040300
                                                                                                                        0040400
         RESORM=RESORM/FLOWIN
                                                                                                                        0040500
         RESORU=RESORU/XMONIN
                                                                                                                        0040600
         RESORV=RESORV/XMONIN
                                                                                                                        0040700
         RESORW=RESORW/WMONIN
         RESORK=RESORK/(.5*FLOWIN*UMEAN*UMEAN)
IF(NITER .NE. IPRINT) GO TO 301
IPRINT=IPRINT+1
                                                                                                                        0040800
                                                                                                                        0040900
                                                                                                                        0041000
         WRITE(6,311) NITER, RESORU, RESORV, RESORW, RESORM, RESORK,
                                                                                                                        0041100
        *RESORE,U(IMON, JMON), V(IMON, JMON), W(IMON, JMON), P(IMON, NJM1),
                                                                                                                        0041200
                                                                                                                        0041300
        *ED(IMON,NJM1)
         IF(INCALU) CALL PRINT(1,1,NI,NJ,IT,JT,XU,Y,U,HEDU)
IF(INCALU) CALL PRINT(1,1,NI,NJ,IT,JT,XU,Y,U,HEDU)
IF(INCALV) CALL PRINT(1,1,NI,NJ,IT,JT,X,YV,V,HEDV)
IF(INCALW) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,W,HEDW)
                                                                                                                        0041400
                                                                                                                        0041500
                                                                                                                        0041600
                                                                                                                        0041700
                                                                                                                        0041800
         IF(INCALP) CALL PRINT(1,1,N1,NJ,IT,JT,X,Y,P,HEDP)
IF(INCALD) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,ED,HEDD)
                                                                                                                        0041900
                                                                                                                        0042000
          JPRINT=JPRINT+25
```

```
WRITE(6,310) IMON, JMON
                                                                                                                         0042100
   301 CONTINUE
                                                                                                                         0042200
C----TERMINATION TESTS
                                                                                                                         0042300
          SORCE=AMAX1(RESORM, RESORU, RESORV, RESORW, RESORK)
                                                                                                                         0042400
   IF(NITER.GE.MAXIT) GO TO 302

303 IF(NITER .GE. 150 .AND. SORCE .GE. 3.0) GO TO 302
    IF(SORCE.GT.SORMAX .OR. NITER .LT. 20) GO TO 300
                                                                                                                         0042500
                                                                                                                         0042600
                                                                                                                         0042700
   302 CONTINUE
                                                                                                                         0042800
          IF(NITER .GE. 150 .AND. SORCE .GE. 3.0) WRITE(6,960)
                                                                                                                         0042900
                                                                                                                         0043000
CHAPTER 4 4 4 4 4 4 FINAL OPERATIONS AND OUTPUT 4 4
                                                                                                                      4 0043100
                                                                                                                         0043200
   440 CONTINUE
                                                                                                                         0043300
C-----NONDIMENSIONALIZE PROBLEM SOLN.
                                                                                                                         0043400
         IF(.NOT. NONDIM) GO TO 700 DO 600 I=1,NI
                                                                                                                         0043500
                                                                                                                         0043600
          DO 600 J=1,NJ
                                                                                                                         0043700
         USTAR(I,J)=U(I,J)/UIN
                                                                                                                         0043800
          VSTAR(I,J)=V(I,J)/UIN
                                                                                                                         0043900
         WSTAR(I,J)=W(I,J)/UIN
PSTAR(I,J)=P(I,J)/(DENSIT*(UIN**2)/2.)
                                                                                                                         0044000
                                                                                                                         0044100
          TESTAR(I, J)=TE(I, J)/(UIN*UIN)
                                                                                                                         0044200
          SP(I,J)=0.0
                                                                                                                         0044300
          IF(ED(I,J) .GT. 1.E-15) SP(I,J)=TE(I,J)**1.5/ED(I,J)/RLARGE
                                                                                                                         0044400
          VISTAR(I, J)=VIS(I, J)/VISCOS
                                                                                                                         0044500
   600 CONTINUE
                                                                                                                         0044600
   700 CONTINUE
                                                                                                                         0044700
         IF(INCALS) CALL STRMFN
                                                                                                                         0044800
         WRITE(6,312)
                                                                                                                         0044900
         WRITE(6,312)
WRITE(6,410) LFS,NSBR,SWNB(LFS),VANB(LFS),SWRLNO,UMEAN,FLOWIN
IF(INCALU) CALL PRINT(1,1,NI,NJ,IT,JT,XU,Y,U,HEDU)
IF(INCALV) CALL PRINT(1,1,NI,NJ,IT,JT,X,YV,V,HEDV)
IF(INCALW) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,P,HEDP)
IF(INCALP) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,PP,HEDP)
IF(INCALP) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,PP,HEDP)
IF(INCALK) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,TE,HEDK)
IF(INCALD) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,FD,HEDD)
                                                                                                                         0045000
                                                                                                                         0045100
                                                                                                                         0045200
                                                                                                                         0045300
                                                                                                                         0045400
                                                                                                                         0045500
                                                                                                                         0045600
         IF(INCALD) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,ED,HEDD)
IF(INCALS) CALL PRINT(1,1,NI,NJ,IT,JT,XU,Y,STFN,HEDSF)
                                                                                                                         0045700
                                                                                                                         0045800
         IF(INCALS) CALL PRINT(1,1,NI,NSTLN,IT,JT,XU,STVAL,YSTLN,HEDSL)
                                                                                                                         0045900
         IF(.NOT. NONDIM) GO TO 750
         IF(.NOT. NONDIM) GO TO 750

IF(INCALU) CALL PRINT(1,1,NI,NJ,IT,JT,XUND,YND,USTAR,HEDDU) 0046100

IF(INCALV) CALL PRINT(1,1,NI,NJ,IT,JT,XND,YVND,VSTAR,HEDDV) 0046200

IF(INCALW) CALL PRINT(1,1,NI,NJ,IT,JT,XND,YND,WSTAR,HEDDW) 0046300

IF(INCALS) CALL PRINT(1,1,NI,NSTLN,IT,JT,XUND,STVAL,YSTLND,HEDDSL) 0046500

IF(INCALP) CALL PRINT(1,1,NI,NJ,IT,JT,XND,YND,PSTAR,HEDDP) 0046500

IF(INCALK) CALL PRINT(1,1,NI,NJ,IT,JT,XND,YND,TESTAR,HEDDK) 0046700

IF(INCALK) CALL PRINT(1,1,NI,NJ,IT,JT,X,Y,SP,HEDL) 0046800
                                                                                                                         0046000
         IF(INCALK) CALL PRINT(1,1,NI,NJ,IT,JT,XND,YND,VISTAR,HEDDVS)
                                                                                                                         0046800
   750 CONTINUE
                                                                                                                         0046900
         IF(.NOT. IWRITE) GO TO 702
                                                                                                                         0047000
         WRITE(11) U
                                                                                                                         0047100
         WRITE(11) V
                                                                                                                         0047200
         WRITE(11) W
                                                                                                                         0047300
         WRITE(11) P
                                                                                                                         0047400
         WRITE(11) TE
                                                                                                                         0047500
         WRITE(11) ED
                                                                                                                         0047600
         WRITE(11) VIS
                                                                                                                        0047700
         WRITE(11) STFN
                                                                                                                        0047800
         WRITE(14) YSTLND
                                                                                                                        0047900
  702 CONTINUE
                                                                                                                        0048000
```

```
C-----CALCULATION OF SHEAR-STRESS COEFFICIENT ALONG LARGE DUCT WALL 0048100
       WRITE(6,402)
                                                                                        0048200
                                                                                         0048300
       DO 401 I=2,NIM1
       SSC=ABS(TAUN(I))/(.5*DENSIT*UIN*UIN)
                                                                                         0048400
                                                                                         0048500
       WRITE(6,403) I,XND(I),SSC
                                                                                         0048600
  401 CONTINUE
                                                                                         0048700
      WRITE(6,312)
C----PLOT DIMENSIONLESS STREAMLINES
                                                                                         0048800
                                                                                         0048900
      LARGE=0
       IF(INPLOT .AND. INCALS) CALL PLOT (XUDPLT, IT, NPTS, XAXIS, YSLPLT,
                                                                                         0049000
                                                                                         0049100
      #MAXLN, NPLTLN, YAXES, SYMB L, LARGE)
                                                                                         0049200
       LARGE=1
IF(INPLOT .AND. INCALS) CALL PLOT (XUDPLT, IT, NPTS, XAXIS, YSLPLT, #MAXLN, NPLTLN, YAXES, SYMB L, LARGE)

C-----RESET INITIAL CONDITIONS FOR ANOTHER SWIRL CASE
                                                                                         0049300
                                                                                         0049400
                                                                                         0049500
       IF(LFS .GE. LFSMAX) GO TO 409
LFS=LFS+1
                                                                                         0049600
                                                                                         0049700
                                                                                         0049800
       NITER=0
                                                                                         0049900
       JPRINT=NITER+300
                                                                                         0050000
       IPRINT=NITER+1
  304 IF(LFS .GE. 3) MAXIT=NITER+200
IF(NSBR .EQ. 0) GO TO 405
WINST=2.*SWNB(LFS)/(1.+SWNB(LFS))*UIN
                                                                                         0050100
                                                                                         0050200
                                                                                         0050300
                                                                                         0050400
       DO 406 J=2, JSTEP
                                                                                         0050500
   406 W(1,J)=WINST*R(J)/R(JSTEP)
                                                                                         0050600
       GO TO 408
                                                                                         0050700
   405 WIN=UIN*TAN(VANB(LFS)*3.14159/180.)
   DO 407 J=2, JSTEP
407 W(1, J)=WIN
                                                                                         0050800
                                                                                         0050900
                                                                                         0051000
   408 FLOWIN=0.
                                                                                         0051100
       ARDEN=0.
                                                                                         0051200
       ARDENT=0.
                                                                                         0051300
       XMONIN=0.
                                                                                         0051400
       ANGMOM=0.
WMONIN=0.
C-----READ INITIAL GUESS OF NEXT SWIRL PROBLEM FROM
C-----PREVIOUS SOLN. OF SIMILAR PROBLEM
IF(.NOT. IREAD) GO TO 445
                                                                                         0051500
                                                                                         0051600
                                                                                         0051700
                                                                                         0051800
                                                                                         0051900
        READ(12) U
                                                                                         0052000
       READ(12) V
                                                                                         0052100
        READ(12) W
                                                                                         0052200
        READ(12) P
                                                                                         0052300
        READ(12) TE
                                                                                         0052400
        READ(12) ED
                                                                                         0052500
       READ(12) VIS
READ(12) STFN
                                                                                         0052600
                                                                                         0052700
   445 CONTINUE
                                                                                         0052800
                  J=2,JSTEP
        DO 490
        ARDEN=0.5*(DEN(1,J)+DEN(2,J))*RCV(J)*SNS(J)
                                                                                         0052900
                                                                                         0053000
        XMONIN=XMONIN+ARDEN*U(2,J)*U(2,J)
                                                                                         0053100
        WMONIN=WMONIN+ARDEN*U(2,J)*W(1,J)
                                                                                         0053200
        ANGMOM=ANGMOM+ARDEN*U(2,J)*W(1,J)*R(J)
                                                                                         0053300
        ARDENT=ARDENT+ARDEN
                                                                                         0053400
   490 FLOWIN=FLOWIN+ARDEN*U(2,J)
                                                                                         0053500
        UMEAN=FLOWIN/ARDENT
                                                                                         0053600
        SWRLNO=ANGMOM/(XMONIN*RSMALL)
        IF(W(1,JSTEP) .EQ. 0.) WMONIN=1.
WRITE(6,310) IMON,JMON
                                                                                         0053700
                                                                                         0053800
                                                                                         0053900
        GO TO 300
                                                                                         0054000
   409 CONTINUE
```

```
0054100
C-----FORMAT STATEMENTS
    211 FORMAT STATEMENTS

211 FORMAT(1H1,T37,'AXISYMMETRIC,ISOTHERMAL, GT COMBUSTOR FLOWFIELD SI 0.054300

#MULATION',//,T35,'USING THE STAIRSTEP APPROXIMATION FOR THE SLOPIN 0.054400

#G EXPANSION WALL',//,T53,'AND THE K-E TURBULENCE MODEL') 0.054500

225 FORMAT(///,T40,'EXPANSION ANGLE(DEG.) =',T77,1PE13.3) 0.054600

230 FORMAT(//,T40,'INLET RADIUS(M) =',T77,1PE13.3) 0.054700

235 FORMAT (//,T40,'INLET RADIUS(M) =',T77,1PE13.3) 0.054800

240 FORMAT(//,T40,'COMBUSTOR RADIUS(M) =',T77,1PE13.3) 0.055000

245 FORMAT(//,T40,'LNLET REYNOLDS NO.(USING DIAM.) =',T77,1PE13.3) 0.055000

250 FORMAT(//,T40,'LAMINAR VISCOSITY(KG/M/SEC) =',T77,1PE13.3) 0.055100

250 FORMAT(//,T40,'LAMINAR VISCOSITY(KG/M/SEC) =',T77,1PE13.3) 0.055300

310 FORMAT(13H0ITER I---, 9X,29HABSOLUTE RESIDUAL SOURCE SUMS,9X, 0.055500
                                                                                                                                                                                                         0054200
     310 FORMAT(13H0ITER I---, 9X,29HABSOLUTE RESIDUAL SOURCE SUMS,9X, 111H---I I---,37H FIELD VALUES AT MONITORING LOCATION(,12,1H,,12, *6H) ---I/14H NO UMON,7X,'VMON',7X,'WMON',7X,'MASS',7X,
                                                                                                                                                                                                         0055500
                                                                                                                                                                                                         0055600
                                                                                                                                                                                                         0055700
     3,7X,4HDISP,9X,1HU,9X,1HV,10X,1HW,10X,1HP,10X,1HD/)
311 FORMAT (2X,14,11E11.4)
312 FORMAT (1H0,59(2H- ))
402 FORMAT(///9X,1HI,5X,3HX/D,5X,10HS.S.COEFF.)
                                                                                                                                                                                                         0055800
                                                                                                                                                                                                         0055900
                                                                                                                                                                                                         0056000
                                                                                                                                                                                                         0056100
     403 FORMAT(/5X,I5,2(1PE11.3))
                                                                                                                                                                                                         0056200
     410 FORMAT(//23H SWIRL CASE WITH LFS
                                                                                                                                                                                                         0056300
                                                                                    AND NSBR =, 13//
                                        23H
                                                                                                                                                                                                         0056400
             163H CORRESPONDS IF NSBR = 1 TO SWIRL GENERATOR WITH SWIRL NUMBER = 0.056500 0.56700 0.56700 0.56700 0.56800 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0.56900 0
     950 FORMAT(10X,6F10.5,/,10X,6F10.5,/,10X,4F10.5)
960 FORMAT(15X,' THE SOLN. IS NOT CONVERGING')
                                                                                                                                                                                                        0057000
                                                                                                                                                                                                        0057100
                END
                                                                                                                                                                                                        0057200
                                                                                                                                                                                                        0057300
                                                                                                                                                                                                        0057400
                                                                                                                                                                                                        0057500
                SUBROUTINE INIT
                                                                                                                                                                                                        0057600
0057800
CHAPTER 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0
                                                                                                                                                           0
                                                                                                                                                                    0
                                                                                                                                                                            0
                                                                                                                                                                                    0
                                                                                                                                                                                                        0057900
                                                                                                                                                                                                        0058000
                                                                                                                                                                                                        0058100
             1/UVEL/RESORU, NSWPU, URFU, DXEPU(48), DXPWU(48), SEWU(48)
                                                                                                                                                                                                        0058200
             1/VVEL/RESORV, NSWPV, URFV, DYNPV(24), DYPSV(24), SNSV(24)
                                                                                                                                                                                                        0058300
             */WVEL/ RESORW, NSWPW, URFW
                                                                                                                                                                                                        0058400
             1/PCOR/RESORM, NSWPP, URFP, DU(48,24), DV(48,24), IPREF, JPREF
                                                                                                                                                                                                        0058500
             */VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), *ED(48,24), STFN(48,24), YSTLN(48,24), STVAL(24), USTAR(48,24),
                                                                                                                                                                                                       0058600
                                                                                                                                                                                                        0058700
             *VSTAR(48,24),WSTAR(48,24),PSTAR(48,24),TESTAR(48,24),YSTLND(48,24) 0058800
             #, VISTAR(48,24)
                                                                                                                                                                                                        0058900
             1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
                                                                                                                                                                                                        0059000
             1/GEOM/INDCOS,X(48),Y(24),DXEP(48),DXPW(48),DYNP(24),DYPS(24),
                                                                                                                                                                                                        0059100
                                SNS(24), SEW(48), XU(48), YV(24), R(24), RV(24),
                                                                                                                                                                                                        0059200
                     WFN(24), WFS(24), WFE(48), WFW(48), RCV(24), XND(48), XUND(48),
                                                                                                                                                                                                        0059300
             #YND(24), YVND(24)
                                                                                                                                                                                                        0059400
               COMMON
                                                                                                                                                                                                        0059500
             1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
                                                                                                                                                                                                        0059600
             1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                                                                                                                                                        0059700
                                  RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
                                                                                                                                                                                                        0059800
             1/TURB/GEN(48,24),CD,CMU,C1,C2,CAPPA,ELOG,PRED,PRTE
                                                                                                                                                                                                        0059900
             1/WALLF/YPLUSN(48),XPLUSW(24),TAUN(48),TAUW(24)
                                                                                                                                                                                                        0060000
```

```
1/COEF/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24), 0060100
                                                                                         0060200
              SP(48,24)
      1/PLOTT/NSTLN, NPLTLN, NPTS, YSLPLT(10,48), XUDPLT(48), INPLOT
                                                                                         0060300
                                                                                         0060400
CHAPTER 1 1 1 1 1 CALCULATE GEOMETRICAL QUANTITIES 1 1 1 1 1
                                                                                         0060500
                                                                                         0060600
                                                                                         0060700
       DO 100 J=1, NJ
R(J)=Y(J)
                                                                                         0060800
                                                                                         0060900
  100 IF(INDCOS.EQ.1)R(J)=1.0
                                                                                         0061000
       DXPW(1)=0.0
                                                                                         0061100
       DXEP(NI)=0.0
       DO 101 I=1, NIM1
DXEP(I)=X(I+1)-X(I)
                                                                                         0061200
                                                                                         0061300
                                                                                         0061400
  101 DXPW(I+1)=DXEP(I)
                                                                                         0061500
       DYPS(1)=0.0
                                                                                         0061600
       DYMP(NJ)=0.0
       DO 102 J=1, NJM1
DYNP(J)=Y(J+1)-Y(J)
                                                                                         0061700
                                                                                         0061800
                                                                                         0061900
  102 DYPS(J+1)=DYNP(J)
                                                                                         0062000
       SEW(1)=0.0
                                                                                         0062100
       SEW(NI)=0.0
  DO 103 I=2,NIM1
103 SEW(I)=0.5*(DXEP(I)+DXPW(I))
                                                                                         0062200
                                                                                         0062300
                                                                                         0062400
       SNS(1)=0.0
                                                                                         0062500
  SNS(NJ)=0.0
DO 104 J=2,NJM1
104 SNS(J)=0.5*(DYNP(J)+DYPS(J))
                                                                                         0062600
                                                                                         0062700
                                                                                         0062800
       XU(1) = 0.0
                                                                                         0062900
  DO 105 I=2,NI
105 XU(I)=0.5*(X(I)+X(I-1))
                                                                                         0063000
                                                                                         0063100
       DXPWU(1)=0.0
                                                                                         0063200
       DXPWU(2)=0.0
                                                                                         0063300
       DXEPU(1)=0.0
                                                                                         0063400
       DXEPU(NI)=0.0
                                                                                         0063500
       DO 106 I=2, NIM1
                                                                                         0063600
       DXEPU(I)=XU(I+1)-XU(I)
                                                                                         0063700
  106 DXPWU(I+1)=DXEPU(I)
       SEWU(1)=0.0
                                                                                         0063800
                                                                                         0063900
       DO 107 I=2,NI
                                                                                         0064000
  107 SEWU(I)=X(I)-X(I-1)
       DO 111 I=2,NIM1
WFE(I)=SEWU(I+1)/(SEWU(I+1)+SEWU(I))
IF(I .LE. 2) GO TO 111
WFW(I)=SEWU(I-1)/(SEWU(I-1)+SEWU(I))
                                                                                         0064100
                                                                                         0064200
                                                                                         0064300
                                                                                         0064400
                                                                                         0064500
                                                                                         0064600
  111 CONTINUE
                                                                                         0064700
       YV(1) = 0.0
                                                                                         0064800
       RV(1) = 0.0
                                                                                         0064900
       DO 108 J=2,NJ
                                                                                         0065000
        RV(J)=0.5*(R(J)+R(J-1))
                                                                                         0065100
  108 \text{ YV(J)} = 0.5 \times (Y(J) + Y(J-1))
                                                                                         0065200
       RCV(1)=R(1)
                                                                                         0065300
       RCV(NJ) = R(NJ)
                                                                                         0065400
   DO 113 J=2,NJM1
113 RCV(J)=0.5*(RV(J+1)+RV(J))
                                                                                         0065500
                                                                                         0065600
       DYPSV(1)=0.0
                                                                                         0065700
       DYPSV(2)=0.0
                                                                                         0065800
       DYMPV(NJ)=0.0
                                                                                         0065900
       DO 109 J=2, NJM1
DYNPV(J)=YV(J+1)-YV(J)
                                                                                         0066000
```

```
109 DYPSV(J+1)=DYNPV(J)
                                                                                     0066100
       SNSV(1)=0.0
                                                                                     0066200
       DO 110 J=2,NJ
                                                                                     0066300
  110 SNSV(J)=Y(J)-Y(J-1)
                                                                                     0066400
      ----V-VELOCITIES WEIGHTING FACTORS
                                                                                     0066500
      D0 112 J=3,NJM1
WFN(J)=SNSV(J+1)/(SNSV(J+1)+SNSV(J))
                                                                                     0066600
                                                                                     0066700
       WFS(J)=SNSV(J-1)/(SNSV(J-1)+SNSV(J))
                                                                                     0066800
  112 CONTINUE
                                                                                     0066900
                                                                                     0067000
CHAPTER 2 2 2 2 2 2 SET VARIABLES TO ZERO 2 2 2 2 2
                                                                                     0067100
                                                                                     0067200
       DO 200 I=1,NI
                                                                                     0067300
       TAUN(I)=1.0
                                                                                     0067400
       DO 200 J=1,NJ
                                                                                     0067500
       TAUW(J)=1.0
                                                                                     0067600
       U(I,J)=0.0
                                                                                     0067700
       0.0 = (L, I)V
                                                                                     0067800
       W(I,J)=0.
                                                                                     0067900
       P(I,J)=0.0
                                                                                     0068000
       PP(I,J)=0.0
                                                                                     0068100
       TE(I,J)=0.0
                                                                                     0068200
       ED(I,J)=0.0
DEN(I,J)=DENSIT
                                                                                     0068300
                                                                                     0068400
       VIS(I,J)=VISCOS
                                                                                     0068500
       DU(I,J)=0.0
                                                                                     0068600
       DV(I,J)=0.0
                                                                                     0068700
       SU(I,J)=0.0
SP(I,J)=0.0
                                                                                     0068800
                                                                                    0068900
       STFN(I,J)=0.
                                                                                     0069000
200
       CONTINUE
                                                                                    0069100
      DO 300 I=1, NI
DO 300 J=1, NSTLN
YSTLN(I, J)=0.
                                                                                    0069200
                                                                                    0069300
                                                                                    0069400
       YSTLND(I,J)=0.
                                                                                    0069500
       STVAL(J)=0.
                                                                                    0069600
  300 CONTINUE
                                                                                    0069700
       DO 400 N=1, NPLTLN
DO 400 I=1, NI
                                                                                    0069800
                                                                                    0069900
       YŠLPLT(N,Ī)=0.
                                                                                    0070000
  400 CONTINUE
                                                                                    0070100
       RETURN
                                                                                    0070200
       END
                                                                                    0070300
                                                                                    0070400
                                                                                    0070500
C
                                                                                    0070600
       SUBROUTINE PROPS
                                                                                    0070700
0070800
                                                                                    0070900
CHAPTER 0 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0 0 0 0 0
                                                                                    0071000
                                                                                    0071100
       COMMON
                                                                                    0071200
     1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
                                                                                    0071300
     */VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), 0071400
*ED(48,24), STFN(48,24), YSTLN(48,24), STVAL(24), USTAR(48,24), 0071500
*VSTAR(48,24), WSTAR(48,24), PSTAR(48,24), TESTAR(48,24), YSTLND(48,24) 0071600
      #, VISTAR(48,24)
                                                                                    0071700
     1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
                                                                                    0071800
      1/TURB/GEN(48,24),CD,CMU,C1,C2,CAPPA,ELOG,PRED,PRTE
                                                                                    0071900
C
                                                                                    0072000
```

```
CHAPTER
                  1
                         VISCOSITY
                                      1
                                           1
                                                                                    0072100
               1
                                                                                    0072200
                                                                                    0072300
      DO 100 I=2, NIM1
      DO 100 J=2, NJM1
                                                                                    0072400
      VISOLD=VIS(I,J)
                                                                                    0072500
      IF(ED(I,J).EQ.0.) GO TO 102
                                                                                    0072600
      VIS(I,J)=DEN(I,J)*TE(I,J)**2*CMU/ED(I,J)+VISCOS
                                                                                    0072700
                                                                                    0072800
      GD
          TO 101
                                                                                    0072900
  102 VIS(I,J)=VISCOS
     -----UNDER-RELAX VISCOSITY
                                                                                    0073000
  1 VIS(I,J)=URFVIS*VIS(I,J)+(1.-URFVIS)*VISOLD
100 CONTINUE
                                                                                    0073100
101
                                                                                    0073200
      RETURN
                                                                                    0073300
                                                                                    0073400
      END
С
                                                                                    0073500
                                                                                    0073600
C
                                                                                    0073700
                                                                                    0073800
      SUBROUTINE CALCU
0074000
CHAPTER 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0 0 0 0 0
                                                                                    0074100
                                                                                    0074200
                                                                                    0074300
      COMMON
     1/UVEL/RESORU, NSWPU, URFU, DXEPU(48), DXPWU(48), SEWU(48)
                                                                                    0074400
                                                                                    0074500
     1/VVEL/RESORV, NSWPV, URFV, DYNPV(24), DYPSV(24), SNSV(24)
     1/PCOR/RESORM, NSWPP, URFP, DU(48, 24), DV(48, 24), IPREF, JPREF
                                                                                    0074600
     */VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), 0074700
*ED(48,24), STFN(48,24), YSTLN(48,24), STVAL(24), USTAR(48,24), 0074800
*VSTAR(48,24), WSTAR(48,24), PSTAR(48,24), TESTAR(48,24), YSTLND(48,24) 0074900
                                                                                    0075000
     #, VISTAR(48,24)
                                                                                    0075100
     1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
     1/GEOM/INDCOS,X(48),Y(24),DXEP(48),DXPW(48),DYNP(24),DYPS(24),
                                                                                    0075200
        SNS(24), SEW(48), XU(48), YV(24), R(24), RV(24), WFN(24), WFS(24), WFE(48), WFW(48), RCV(24), XND(48), XUND(48),
                                                                                    0075300
                                                                                    0075400
                                                                                    0075500
     #YND(24), YVND(24)
                                                                                    0075600
      COMMON
                                                                                    0075700
     1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
     1/COEF/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24), 0075800
                                                                                    0075900
             SP(48,24)
     1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                                    0076000
              RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
                                                                                    0076100
                                                                                    0076200
CHAPTER
        1 1 1 1 1 1 ASSEMBLY OF COEFFICIENTS 1 1 1 1 1 1 0076300
                                                                                    0076400
                                                                                    0076500
      DO 100 I=3, NIM1
                                                                                    0076600
      DO 101 J=2,NJM1
C-----COMPUTE AREAS AND VOLUME
                                                                                    0076700
      AREAN=RV(J+1)*SEWU(I)
                                                                                    0076800
       AREAS=RV(J)*SEWU(I)
                                                                                    0076900
      AREAEW=RCV(J)*SNS(J)
                                                                                    0077000
VOL=RCV(J)*SEWU(I)*SNS(J)
C----CALCULATE CONVECTION COEFFICIENTS
                                                                                    0077100
                                                                                    0077200
       GN=0.5*(DEN(I,J+1)+DEN(I,J))*V(I,J+1)
                                                                                    0077300
       GNW=0.5*(DEN(I-1,J)+DEN(I-1,J+1))*V(I-1,J+1)
                                                                                    0077400
      GS=0.5*(DEN(I,J-1)+DEN(I,J))*V(I,J)
GSW=0.5*(DEN(I-1,J)+DEN(I-1,J-1))*V(I-1,J)
                                                                                    0077500
                                                                                    0077600
      GE=DEN(I,J)*(U(I+1,J)*(1.0-WFE(I))+U(I,J)*WFE(I))
GW=DEN(I-1,J)*(U(I-1,J)*(1.0-WFW(I))+U(I,J)*WFW(I))
                                                                                    0077700
                                                                                    0077800
       CN=0.5*(GN+GNW)*AREAN
                                                                                    0077900
                                                                                    0078000
      CS=0.5*(GS+GSW)*AREAS
```

```
CE=GE*AREAEW
                                                                                           0078100
      CW=GW*AREAEW
                                                                                           0078200
      ----CALCULATE DIFFUSION COEFFICIENTS
                                                                                           0078300
       VISN=0.25*(VIS(I,J)+VIS(I,J+1)+VIS(I-1,J)+VIS(I-1,J+1))
VISS=0.25*(VIS(I,J)+VIS(I,J-1)+VIS(I-1,J)+VIS(I-1,J-1))
DH=VISN*AREAN/DYNP(J)
                                                                                           0078400
                                                                                           0078500
                                                                                           0078600
       DS=VISS*AREAS/DYPS(J)
                                                                                           0078700
       DE=VIS(I,J)*AREAEW/DXEPU(I)
                                                                                           0078800
       DW=VIS(I-1,J)*AREAEW/DXPWU(I)
                                                                                           0078900
C-----CALCULATE COEFFICIENTS OF SOURCE TERMS
                                                                                           0079000
       SMP=CN-CS+CE-CW
                                                                                           0079100
       CP=AMAX1(0.0,SMP)
                                                                                           0079200
      CPO=CP
                                                                                           0079300
C----ASSEMBLE MAIN COEFFICIENTS
AN(I,J)=AMAX1(ABS(0.5*CN),DN)-0.5*CN
                                                                                           0079400
                                                                                           0079500
       AS(I,J) = AMAX1(ABS(0.5*CS),DS)+0.5*CS
                                                                                           0079600
       DE=AMAX1(DE,-WFE(I)*CE,(1.0-WFE(I))*CE)
DW=AMAX1(DW,WFW(I)*CW,-(1.0-WFW(I))*CW)
                                                                                           0079700
                                                                                           0079800
       AE(I,J)=DE-(1.0-WFE(I))*CE
AW(I,J)=DW+(1.-WFW(I))*CW
                                                                                           0079900
                                                                                           002000
       DU(I,J)=AREAEW
                                                                                           0080100
       DUDXE=(U(I+1,J)-U(I,J))/DXEPU(I)
DUDXW=(U(I,J)-U(I-1,J))/DXPWU(I)
                                                                                           0080200
                                                                                           0080300
       SORCE1=(DUDXE*VIS(I,J)-DUDXW*VIS(I-1,J))/SEWU(I)
DVDXH=(V(I,J+1)-V(I-1,J+1))/SEWU(I)
                                                                                           0080400
                                                                                           0080500
       DVDXS=(V(I,J)-V(I-1,J))/SEWU(I)
                                                                                           0080600
       SORCE2=(RV(J+1)*VISN*DVDXN-RV(J)*VISS*DVDXS)/(RCV(J)*DYNPV(J))
                                                                                           0080700
       SU(I,J)=CPO\times U(I,J)+DU(I,J)\times (P(I-1,J)-P(I,J))
                                                                                           0080800
       SU(I,J)=SU(I,J)+(SORCE1+SORCE2)*VOL
                                                                                           0080900
       SP(I,J) = -CP
                                                                                           0081000
  101 CONTINUE
                                                                                           0081100
  100 CONTINUE
                                                                                           0081200
                                                                                           0081300
CHAPTER 2 2 2 2 2 2 PROBLEM MODIFICATIONS 2 2 2 2 2 2 2 0081400
C
                                                                                           0081500
       CALL PROMOD (2)
                                                                                           0081600
                                                                                           0081700
CHAPTER 3 FINAL COEFF. ASSEMBLY AND RESIDUAL SOURCE CALCULATION 3 3
                                                                                          0081800
                                                                                           0081900
       RESORU=0.0
                                                                                           0082000
       DO 300 I=3, NIM1
DO 301 J=2, NJM1
                                                                                          0082100
                                                                                          0082200
       AP(I,J)=AN(I,J)+AS(I,J)+AE(I,J)+AW(I,J)-SP(I,J)
DU(I,J)=DU(I,J)\AP(I,J)
RESOR=AN(I,J)*U(I,J+1)+AS(I,J)*U(I,J-1)+AE(I,J)*U(I+1,J)
                                                                                          0082300
                                                                                          0082400
                                                                                          0082500
       +AW(I,J)*U(I-1,J)-AP(I,J)*U(I,J)+SU(I,J)
VOL=RCV(J)*SEWU(I)*SNS(J)
                                                                                          0082600
                                                                                          0082700
       SORVOL=GREAT*VOL
                                                                                          0082800
       IF(-SP(I,J).GT.0.5*SORVOL) RESOR=RESOR/SORVOL
RESORU=RESORU+ABS(RESOR)
                                                                                          0082900
                                                                                          0083000
C-----UNDER-RELAXATION
                                                                                          0083100
       AP(I,J)=AP(I,J)/URFU
                                                                                          0083200
       SU(I,J)=SU(I,J)+(1.-URFU)*AP(I,J)*U(I,J)
                                                                                          0083300
       DU(I,J)=DU(I,J)*URFU
                                                                                          0083400
  301 CONTINUE
                                                                                          0083500
  300 CONTINUE
                                                                                          0083600
                                                                                          0083700
CHAPTER 4 4 4 SOLUTION OF DIFFERENCE EQUATION 4 4
                                                                                          0083800
                                                                                          0083900
       DO 400 N=1, NSWPU
                                                                                          0084000
```

```
0084100
  400 CALL LISOLV(3,2,NI,JMAX,IT,JT,U,2)
                                                                                        0084200
       RETURN
                                                                                        0084300
       END
                                                                                        0084400
                                                                                        0084500
                                                                                        0084600
С
                                                                                        0084700
       SUBROUTINE CALCV
0084900
                                                                                Λ
                                                                                        0085000
         0 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0 0
                                                                            n
CHAPTER
                                                                                        0085100
                                                                                        0085200
       COMMON
      1/UVEL/RESORU, NSWPU, URFU, DXEPU(48), DXPWU(48), SEWU(48)
                                                                                        0085300
      1/VVEL/RESURV, NSWPV, URFV, DYNPV(24), DYPSV(24), SNSV(24)
1/PCOR/RESURM, NSWPP, URFP, DU(48,24), DV(48,24), IPREF, JPREF

*/VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24),

*ED(48,24), STFN(48,24), YSTLN(48,24), STLN(48,24), TESTAB(48,24),

**USTAB(48,24), USTAB(48,24), DSTAB(48,24), O085700
      *VSTAR(48,24), WSTAR(48,24), PSTAR(48,24), TESTAR(48,24), YSTLND(48,24)
                                                                                        0085800
                                                                                        0085900
      #, VISTAR(48,24)
                                                                                        0086000
      1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
      0086100
                                                                                        0086200
         WFN(24),WFS(24),WFE(48),WFW(48),RCV(24),XND(48),XUND(48),
                                                                                        0086300
                                                                                        0086400
      #YND(24), YVND(24)
                                                                                        0086500
       COMMON
                                                                                        0086600
      1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
      1/COEF/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24), 0086700
              SP(48,24)
                                                                                        0086800
                                                                                        0086900
      1/KASE T1/UIN,TEIN,EDIN,FLOWIN,ALAMDA,
                RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
                                                                                        0087000
                                                                                        0087100
CHAPTER 1 1 1 1 1 1 ASSEMBLY OF COEFFICIENTS 1 1 1 1 1 1 0087200
                                                                                        0087300
                                                                                        0087400
       DO 100 I=2, NIM1
                                                                                        0087500
       DO 101 J=3, NJM1
                                                                                        0087600
C----COMPUTE AREAS AND VOLUME
                                                                                        0087700
       AREAN=R(J)*SEW(I)
       AREAS=R(J-1)*SEW(I)
                                                                                        0087800
                                                                                        0087900
       AREAEW=RV(J)*SNSV(J)
                                                                                        0088000
       VOL=RV(J)*SEW(I)*SHSV(J)
C-----CALCULATE CONVECTION COEFFICIENTS
                                                                                        0088100
       GN=DEN(I,J)*(V(I,J+1)*(1.0-WFN(J))+V(I,J)*WFN(J))
GS=DEN(I,J-1)*(V(I,J-1)*(1.0-WFS(J))+V(I,J)*WFS(J))
GE=0.5*(DEN(I+1,J)+DEN(I,J))*U(I+1,J)
                                                                                        0088200
                                                                                        0088300
                                                                                        0088400
                                                                                        0088500
       GSE=0.5*(DEN(I,J-1)+DEN(I+1,J-1))*U(I+1,J-1)
                                                                                        0088600
        GW=0.5*(DEN(I,J)+DEN(I-1,J))*U(I,J)
                                                                                        0088700
       GSW=0.5*(DEN(I,J-1)+DEN(I-1,J-1))*U(I,J-1)
                                                                                        በበጸጸጸበበ
        CN=GN*AREAN
                                                                                        0088900
        CS=GS*AREAS
       CE=0.5*(GE+GSE)*AREAEW
                                                                                        0089000
CW=0.5*(GW+GSW)*AREAEW
C-----CALCULATE DIFFUSION COEFFICIENTS
VISE=0.25*(VIS(I,J)+VIS(I+1,J)+VIS(I,J-1)+VIS(I+1,J-1))
VISW=0.25*(VIS(I,J)+VIS(I-1,J)+VIS(I,J-1)+VIS(I-1,J-1))
DN=VIS(I,J)*AREAN/DYNPV(J)
DS=VIS(I,J)*APEAS/DYPS(L)
                                                                                        0089100
                                                                                        0089200
                                                                                        0089300
                                                                                        0089400
                                                                                        0089500
                                                                                        0089600
        DS=VIS(I,J-1)*AREAS/DYPSV(J)
        DE=VISE*AREAEW/DXEP(I)
                                                                                        0089700
                                                                                        0089800
       DW=VISW*AREAEW/DXPW(I)
                                                                                        0089900
         --- CALCULATE COEFFICIENTS OF SOURCE TERMS
                                                                                        0090000
       SMP=CN-CS+CE-CW
```

```
CP=AMAX1(0.0,SMP)
                                                                                              0090100
       CPO=CP
                                                                                              0090200
C----ASSEMBLE MAIN COEFFICIENTS
DN=AMAX1(DN,-WFN(J)*CN,(1.0-WFN(J))*CN)
DS=AMAX1(DS,WFS(J)*CS,-(1.0-WFS(J))*CS)
                                                                                              0090300
                                                                                              0090400
                                                                                              0090500
        AN(I,J)=DN-(1.0-WFN(J))*CN
                                                                                              0090600
       AS(I,J)=DS+(1.0-WFS(J))*CS
AE(I,J)=AMAX1(ABS(0.5*CE),DE)-0.5*CE
AW(I,J)=AMAX1(ABS(0.5*CW),DW)+0.5*CW
                                                                                              0090700
                                                                                              0090800
                                                                                              0090900
        DV(I,J)=0.5*(AREAN+AREAS)
                                                                                              0091000
        DUDYE=(U(I+1,J)-U(I+1,J-1))/SNSV(J)
                                                                                              0091100
       DUDYW=(U(I,J)-U(I,J-1)/SNSV(J)

SORCE1=(DUDYE*VISE-DUDYW*VISW)/DXEPU(I)

DVDYN=(V(I,J+1)-V(I,J))/DYNPV(J)

DVDYS=(V(I,J)-V(I,J-1))/DYPSV(J)

SORCE2=(VIS(I,J)*RCV(J)*DVDYN-VIS(I,J-1)*RCV(J-1)*DVDYS)
                                                                                              0091200
                                                                                              0091300
                                                                                              0091400
                                                                                             0091500
                                                                                             0091600
         /(RV(J)*SNSV(J))
                                                                                              0091700
       SU(I,J)=CPO*V(I,J)+DV(I,J)*(P(I,J-1)-P(I,J))
SU(I,J)=SU(I,J)+(SORCE1+SORCE2)*VOL
                                                                                             0091800
                                                                                             0091900
        SP(I,J) = -CP
                                                                                             0092000
        IF(INDCOS .EQ. 1) GO TO 101
                                                                                             0092100
       SU(I,J)=SU(I,J)+VOL*((DEN(I,J)+DEN(I,J-1))*(W(I,J)+W(I,J-1)
                                                                                             0092200
      #)**2)/(8.*RV(J))
                                                                                             0092300
        SP(I,J)=SP(I,J)-(VIS(I,J)+VIS(I,J-1))\times VOL/RV(J)\times 2
                                                                                             0092400
  101 CONTINUE
                                                                                             0092500
  100 CONTINUE
                                                                                             0092600
                                                                                             0092700
CHAPTER 2 2 2 2 2 2 PROBLEM MODIFICATIONS 2 2 2 2 2 2 2 0092800
                                                                                             0092900
       CALL PROMOD (3)
                                                                                             0093000
                                                                                             0093100
CHAPTER 3 FINAL COEFF. ASSEMBLY AND RESIDUAL SOURCE CALCULATION 3 3
                                                                                             0093200
                                                                                             0093300
       RESORV=0.0
                                                                                             0093400
       DO 300 I=2,NIM1
DO 301 J=3,NJM1
                                                                                             0093500
                                                                                             0093600
       AP(I,J)=AN(I,J)+AS(I,J)+AE(I,J)+AW(I,J)-SP(I,J)
                                                                                             0093700
       DV(I,J)=DV(I,J)/AP(I,J)

RESOR=AN(I,J)*V(I,J+1)+AS(I,J)*V(I,J-1)+AE(I,J)*V(I+1,J)

+AU(I,J)*V(I-1,J)-AP(I,J)*V(I,J)+SU(I,J)
                                                                                             0093800
                                                                                             0093900
                                                                                             0094000
       VOL=RV(J)*SEW(I)*SNSV(J)
                                                                                             0094100
       SORVOL=GREAT*VOL
                                                                                             0094200
       IF(-SP(I,J).GT.0.5*SORVOL) RESOR=RESOR/SORVOL
RESORV=RESORV+ABS(RESOR)
                                                                                             0094300
                                                                                             0094400
C-----UNDER-RELAXATION
                                                                                             0094500
       AP(I,J)=AP(I,J)/URFV
                                                                                             0094600
       SU(I,J)=SU(I,J)+(1.-URFV)*AP(I,J)*V(I,J)
                                                                                             0094700
       DV(I,J)=DV(I,J)*URFV
                                                                                             0094800
  301 CONTINUE
                                                                                             0094900
  300 CONTINUE
                                                                                             0095000
                                                                                             0095100
CHAPTER 4 4 4 SOLUTION OF DIFFERENCE EQUATION 4 4 4 4 4 4
                                                                                             0095200
                                                                                             0095300
       DO 400 N=1, NSWPV
                                                                                             0095400
  400 CALL LISOLV(2,3,NI,JMAX,IT,JT,V,3)
                                                                                             0095500
       RETURN
                                                                                             0095600
       FND
                                                                                             0095700
                                                                                             0095800
                                                                                             0095900
                                                                                             0096000
```

```
0096100
      SUBROUTINE CALCW
CV*********************************
                                                                                   0096200
                                                                                    0096300
                                                                                    0096400
                                O PRELIMINARIES O
                                                         0
                                                             0 0
                                                                    Ω
                                                                       n
                                                                          Ω
CHAPTER
            0 0 0 0 0
                             0
                                                                                    0096500
C
      COMMON
                                                                                    0096600
     1/UVEL/RESORU, NSWPU, URFU, DXEPU(48), DXPWU(48), SEWU(48)
                                                                                    0096700
     1/VVEL/RESORV, NSWPV, URFV, DYNPV(24), DYPSV(24), SNSV(24)
                                                                                    0096800
                                                                                    0096900
     */WVEL/ RESORW, NSWPW, URFW
     1/TEN/RESORK, NSWPK, URFK
                                                                                    0097000
                                                                                    0097100
     1/TDIS/RESORE, NSWPD, URFE
     */VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), 0097200
*ED(48,24),STFN(48,24),YSTLN(48,24),STVAL(24),USTAR(48,24), 0097300
     *VSTAR(48,24), WSTAR(48,24), PSTAR(48,24), TESTAR(48,24), YSTLND(48,24)
                                                                                   0097400
                                                                                    0097500
     #, VISTAR(48,24)
     1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
                                                                                    0097600
     I/GEOM/INDCOS,X(48),Y(24),DXEP(48),DXPW(48),DYNP(24),DYPS(24),
I SNS(24),SEW(48),XU(48),YV(24),R(24),RV(24),
                                                                                    0097700
                                                                                    0097800
         WFN(24),WFS(24),WFE(48),WFW(48),RCV(24),XND(48),XUND(48),
                                                                                    0097900
                                                                                    0008000
      #YND(24), YVND(24)
                                                                                    0098100
      COMMON
     1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                                    0098200
                                                                                    0098300
     2 RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
1/TURB/GEN(48,24), CD, CMU, C1, C2, CAPPA, ELOG, PRED, PRTE
                                                                                    0098400
                                                                                    0098500
                                                                                    0098600
     1/WALLF/YPLUSN(48), XPLUSW(24), TAUN(48), TAUW(24)
     1/COEF/AP(48,24),AN(48,24),AS(48,24),AÉ(48,24),AW(48,24),SU(48,24), 0098700
1 SP(48,24) 0098800
C----IF NO SWIRL, RETURN TO MAIN
                                                                                    0098900
                                                                                    0099000
      IF(W(1,3) .LE. 0.) GO TO 500
                                                                                    0099100
                                                                                    0099200
CHAPTER 1 1 1 1 1 1 1 1 ASSEMBLY OF COEFFICIENTS 1 1 1 1 1 1 1
                                                                                    0099300
C
      DO 100 I=2, NIM1
DO 101 J=2, NJM1
                                                                                    0099400
                                                                                    0099500
                                                                                    0099600
C
                                                                                    0099700
        COMPUTE AREAS AND VOLUME
Č
                                                                                    0099800
                                                                                    0099900
      AREAN=RV(J+1)*SEW(I)
                                                                                    0100000
      AREAS=RV(J)*SEW(I)
                                                                                    0100100
       AREAEW=RCV(J)*SNS(J)
                                                                                    0100200
       VOL=RCV(J)*SHS(J)*SEW(I)
                                                                                    0100300
                                                                                    0100400
   -----CALCULATE CONVECTION COEFFICIENTS
C.
                                                                                    0100500
                                                                                    0100600
       GN=0.5*(DEN(I,J)+DEN(I,J+1))*V(I,J+1)
                                                                                    0100700
       GS=0.5*(DEN(I,J)+DEN(I,J-1))*V(I,J)
       GE=0.5*(DEN(I,J)+DEN(I+1,J))*U(I+1,J)
                                                                                    0100800
                                                                                    0100900
       GW=0.5*(DEN(I,J)+DEN(I-1,J))*U(I,J)
                                                                                    0101000
       CN=GN*ARFAN
                                                                                    0101100
       CS=GS*AREAS
                                                                                    0101200
       CE=GE*AREAEW
                                                                                    0101300
       CW=GW*AREAEW
                                                                                    0101400
                                                                                    0101500
   -----CALCULATE DIFFUSION COEFFICIENTS
C-
                                                                                    0101600
                                                                                    0101700
       VISN=0.5*(VIS(I,J)+VIS(I,J+1))
                                                                                    0101800
       VISS=0.5*(VIS(I,J)+VIS(I,J-1))
       VISE=0.5*(VIS(I,J)+VIS(I+1,J))
                                                                                    0101900
       VISW=0.5*(VIS(I,J)+VIS(I-1,J))
                                                                                    0102000
```

```
0102100
      DN=VISN*AREAN/DYNP(J)
      DS=VISS*AREAS/DYPS(J)
                                                                                 0102200
      DE=VISE*AREAEW/DXEP(I)
                                                                                 0102300
      DW=VISW*AREAEW/DXPW(I)
                                                                                 0102400
                                                                                 0102500
C
  -----SOURCE TERMS
                                                                                 0102600
                                                                                 0102700
      SMP=CN-CS+CE-CW
                                                                                 0102800
      CP=AMAX1(0., SMP)
                                                                                 0102900
                                                                                 0103000
      CPO=CP
                                                                                 0103100
   -----ASSEMBLE MAIN COEFFICIENTS
                                                                                 0103200
                                                                                 0103300
      AN(I,J)=AMAX1(ABS(0.5*CN),DN)-0.5*CN
                                                                                 0103400
      AS(I,J)=AMAX1(ABS(0.5*CS),DS)+0.5*CS
                                                                                 0103500
      AE(I,J) = AMAX1(ABS(0.5*CE),DE)-0.5*CE
                                                                                 0103600
                                                                                 0103700
      AW(I,J)=AMAX1(ABS(0.5*CW),DW)+0.5*CW
      DV=0.5*(AREAN+AREAS)
                                                                                 0103800
      VAVG=0.5 \times (V(I,J+1)+V(I,J))
                                                                                 0103900
      SU(I,J)=CPO*W(I,J)
                                                                                 0104000
      IF(INDCOS .EQ. 1) GO TO 101
SORCE1=-DEN(I,J)*VAVG*W(I,J) /RCV(J)
                                                                                 0104100
                                                                                 0104200
      SORCE2=-(VISH*RV(J+1)-VISS*RV(J)) *W(I,J)/(DYNPV(J)*
                                                                                 0104300
     #RCV(J)*RCV(J))
                                                                                 0104400
      SU(I,J)=SU(I,J)+(SORCE1+SORCE2)*VOL
                                                                                 0104500
      SP(I,J)=-CP
                                                                                 0104600
                                                                                 0104700
  101 CONTINUE
                                                                                 0104800
100
      CONTINUE
                                                                                 0104900
CHAPTER 2 2 2 2 2 PROBLEM MODIFICATIONS 2 2 2 2 2 2 2 2 2 2 2
                                                                                 0105000
                                                                                 0105100
С
                                                                                 0105200
      CALL PROMOD (8)
                                                                                 0105300
CHAPTER 3 3 FINAL COEFFICIENT ASSEMBLY AND RESIDUAL SOURCE CALCULATION
                                                                                 0105400
                                                                                 0105500
                                                                                 0105600
      RESORW=0.
      DO 300 I=2, NIM1
DO 301 J=2,NJM1
AP(I,J)=AN(I,J)+AS(I,J)+AE(I,J)+AW(I,J)-SP(I,J)
                                                                                 0105700
                                                                                 0105800
                                                                                 0105900
      RESOR = AN(I,J) \times W(I,J+1) + AS(I,J) \times W(I,J-1) + AE(I,J) \times W(I+1,J)
                                                                                 0106000
        +AW(I,J)*W(I-1,J)-AP(I,J)*W(I,J)+SU(I,J)
                                                                                 0106100
      VOL=RCV(J)*SNS(J)*SEW(I)
                                                                                 0106200
      SORVOL=GREAT*VOL
                                                                                 0106300
      IF(-SP(I,J) .GT. 0.5*SORVOL) RESOR=RESOR/SORVOL
IF(J .LE. 2) RESOR=0.
                                                                                 0106400
                                                                                 0106500
      RESORW=RESORW+ABS(RESOR)
                                                                                 0106600
                                                                                 0106700
C
                                                                                 0106800
C-----UNDER RELAXATION
                                                                                 0106900
C
                                                                                 0107000
      AP(I,J)=AP(I,J)/URFW
      SU(1,J)=SU(1,J)+(1.-URFW)*AP(I,J)*W(I,J)
CONTINUE
                                                                                 0107100
                                                                                 0107200
301
                                                                                 0107300
      CONTINUE
300
                                                                                 0107400
CHAPTER 4 4 4 SOLUTION OF DIFFERENCE EQUATIONS 4 4 4 4 4 4 4 4
                                                                                 0107500
                                                                                 0107600
                                                                                 0107700
      DO 400 N=1, NSWPW
  O CALL LISOLV(2, 2, NI, JMAX, IT, JT, W,8)
500 CONTINUE
                                                                                 0107800
400
                                                                                 0107900
                                                                                 0108000
      RETURN
```

```
END
                                                                                 0108100
C
                                                                                 0108200
                                                                                 0108300
С
                                                                                 0108400
      SUBROUTINE CALCP
                                                                                 0108500
0108700
CHAPTER 0 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0
                                                                  0
                                                                      0
                                                                         n
                                                                                 0108800
                                                                                 0108900
                                                                                 0109000
     1/PCOR/RESORM, NSWPP, URFP, DU(48,24), DV(48,24), IPREF, JPREF
                                                                                 0109100
     */VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), *ED(48,24), STFN(48,24), YSTLN(48,24), STVAL(24), USTAR(48,24),
                                                                                 0109200
                                                                                 0109300
     *VSTAR(48,24),WSTAR(48,24),PSTAR(48,24),TESTAR(48,24),YSTLND(48,24)
                                                                                 0109400
     #, VISTAR(48,24)
                                                                                  0109500
     1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
                                                                                 0109600
     1/GEOM/INDCOS,X(48),Y(24),DXEP(48),DXPW(48),DYNP(24),DYPS(24),
1 SNS(24),SEW(48),XU(48),YV(24),R(24),RV(24),
# WFN(24),WFS(24),WFE(48),WFW(48),RCV(24),XND(48),XUND(48),
                                                                                 0109700
                                                                                 0109800
                                                                                 0109900
                                                                                 0110000
     #YND(24), YVND(24)
      COMMON
                                                                                 0110100
     1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
                                                                                 0110200
     1/COEF/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24),
                                                                                 0110300
             SP(48,24)
                                                                                 0110400
     1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                                 0110500
              RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
                                                                                 0110600
      RESORM=0.0
                                                                                 0110700
                                                                                 0110800
CHAPTER 1 1 1 1 1 1 ASSEMBLY OF COEFFICIENTS 1 1 1 1 1 1
                                                                               1 0110900
                                                                                 0111000
       DO 100 I=2, NIM1
                                                                                 0111100
      DO 101 J=2, NJM1
                                                                                  0111200
       ----COMPUTE AREAS AND VOLUME
                                                                                 0111300
      AREAN=RV(J+1)*SEW(I)
                                                                                 0111400
      AREAS=RV(J)*SEW(I)
                                                                                 0111500
       AREAEW=RCV(J)*SNS(J)
                                                                                 0111600
      VOL=RCV(J)*SNS(J)*SEW(I)
                                                                                  0111700
      ----CALCULATE COEFFICIENTS
DENN=0.5*(DEN(I,J)+DEN(I,J+1))
                                                                                 0111800
                                                                                 0111900
      DENS=0.5*(DEN(I,J)+DEN(I,J-1))
                                                                                 0112000
      DEHE=0.5*(DEN(I,J)+DEN(I+1,J))
                                                                                 0112100
      DENW=0.5*(DEN(I,J)+DEN(I-1,J))
                                                                                 0112200
      AN(I,J)=DENN*AREAN*DV(I,J+1)
                                                                                 0112300
      AS(I,J)=DENS*AREAS*DV(I,J)
AE(I,J)=DENE*AREAEN*DU(I+1,J)
                                                                                 0112400
                                                                                 0112500
      AW(I,J)=DENW*AREAEW*DU(I,J)
                                                                                 0112600
C-----CALCULATE SOURCE TERMS
                                                                                 0112700
      CN=DEHN*V(I,J+1)*AREAN
                                                                                 0112800
      CS=DENS*V(I,J)*AREAS
                                                                                 0112900
      CE=DENE*U(I+1,J)*AREAEW
CW=DENN*U(I,J)*AREAEW
                                                                                 0113000
                                                                                 0113100
      SIIP = CH-CS+CE-CW
                                                                                 0113200
      SP(I,J)=0.0
                                                                                 0113300
      SU(I,J) = -SMP
                                                                                 0113400
       --- COMPUTE SUM OF ABSOLUTE MASS SOURCES
                                                                                 0113500
      RESORM=RESORM+ABS(SMP)
                                                                                 0113600
  101 CONTINUE
                                                                                 0113700
  100 CONTINUE
                                                                                 0113800
                                                                                 0113900
CHAPTER 2 2 2 2 2 2 PROBLEM MODIFICATIONS 2 2 2 2 2 2
                                                                               2 0114000
```

```
C
                                                                                                                                                            0114100
                                                                                                                                                            0114200
            CALL PROMOD (4)
                                                                                                                                                            0114300
C
CHAPTER 3 3 3 3 FINAL COEFFICIENT ASSEMBLY 3 3 3 3 3
                                                                                                                                                           0114400
                                                                                                                                                            0114500
                                                                                                                                                            0114600
             DO 300 I=2, NIM1
    DO 301 J=2,NJM1
301 AP(I,J)=AN(I,J)+AS(I,J)+AE(I,J)+AW(I,J)-SP(I,J)
                                                                                                                                                            0114700
                                                                                                                                                            0114800
                                                                                                                                                            0114900
    300 CONTINUE
                                                                                                                                                            0115000
CHAPTER 4 4 4 4 4 SOLUTION OF DIFFERENCE EQUATIONS
                                                                                                                                 4
                                                                                                                                                            0115100
                                                                                                                                                            0115200
                                                                                                                                                            0115300
             DO 400 N=1, NSWPP
                                                                                                                                                            0115400
    400 CALL LISOLV(2,2,NI,JMAX,IT,JT,PP,4)
                                                                                                                                                            0115500
CHAPTER 5 5 5 5 CORRECT VELOCITIES AND PRESSURE 5 5
                                                                                                                                     5
                                                                                                                                          5 5
                                                                                                                              5
                                                                                                                                                            0115600
                                                                                                                                                            0115700
                                                                                                                                                            0115800
           ----VELOCITIES
                                                                                                                                                            0115900
            DO 503 I=2,NIM1
                                                                                                                                                            0116000
             (I)XAML=LL
                                                                                                                                                            0116100
             DO 501 J=3,JJ
             V(I,J)=V(I,J)+DV(I,J)*(PP(I,J-1)-PP(I,J))
                                                                                                                                                            0116200
                                                                                                                                                            0116300
    501 CONTINUE
                                                                                                                                                            0116400
             JJ = JMAX(I-1)
                                                                                                                                                            0116500
             DO 502 J=2,JJ
             IF(I .NE. 2) U(I,J)=U(I,J)+DU(I,J)*(PP(I-1,J)-PP(I,J))
                                                                                                                                                            0116600
                                                                                                                                                            0116700
     502 CONTINUE
                                                                                                                                                            0116800
     503 CONTINUE
C-----PRESSURES (WITH PROVISION FOR UNDER-RELAXATION)
PPREF=PP(IPREF, JPREF)
                                                                                                                                                            0116900
                                                                                                                                                            0117000
                                                                                                                                                            0117100
             DO 506 I=2, NIM1
                                                                                                                                                            0117200
              (I)XAML=LL
             DO 508 J=2,JJ
                                                                                                                                                            0117300
             P(I,J)=P(I,J)+URFP*(PP(I,J)-PPREF)
                                                                                                                                                            0117400
                                                                                                                                                            0117500
C----PP IS ZEROED AT TOP OF CHAPTER 3, MAIN
                                                                                                                                                            0117600
     508 CONTINUE
                                                                                                                                                            0117700
     506 CONTINUE
                                                                                                                                                            0117800
             RETURN
                                                                                                                                                            0117900
             END
                                                                                                                                                            0118000
 C
                                                                                                                                                            0118100
 c-
                                                                                                                                                            0118200
 C
                                                                                                                                                            0118300
             SUBROUTINE CALCTE
 0118500
 C
 CHAPTER 0 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0
                                                                                                                        0
                                                                                                                               0
                                                                                                                                      0
                                                                                                                                            0
                                                                                                                                                            0118600
                                                                                                                                                            0118700
                                                                                                                                                            0118800
             COMMON
           1/TEN/RESORK, NSWPK, URFK
                                                                                                                                                            0118900
           */VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), *ED(48,24), STFN(48,24), YSTLN(48,24), STVAL(24), USTAR(48,24), *CONTROL (24), USTAR(48,24), 
                                                                                                                                                           0119000
                                                                                                                                                            0119100
            *VSTAR(48,24),WSTAR(48,24),PSTAR(48,24),TESTAR(48,24),YSTLND(48,24)
                                                                                                                                                           0119200
                                                                                                                                                            0119300
            #, VISTAR(48,24)
            1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
                                                                                                                                                            0119400
            1/GEOM/INDCOS,X(48),Y(24),DXEP(48),DXPW(48),DYNP(24),DYPS(24),
                                                                                                                                                            0119500
                 SNS(24), SEW(48), XU(48), YV(24), R(24), RV(24), WFN(24), WFS(24), WFE(48), WFW(48), RCV(24), XND(48), XUND(48),
                                                                                                                                                            0119600
                                                                                                                                                            0119700
                                                                                                                                                            0119800
            #YND(24), YVND(24)
                                                                                                                                                            0119900
             COMMON
            1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
                                                                                                                                                            0120000
```

```
1/COEF/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24), 0120100
                SP(48,24)
                                                                                                 0120200
       1/TURB/GEN(48,24),CD,CMU,C1,C2,CAPPA,ELOG,PRED,PRTE
                                                                                                 0120300
       1/WALLF/YPLUSN(48), XPLUSW(24), TAUN(48), TAUW(24)
                                                                                                 0120400
       1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                                                 0120500
                 RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
                                                                                                 0120600
       1/SUSP/SUKD(48,24),SPKD(48,24)
                                                                                                 0120700
                                                                                                 0120800
CHAPTER 1 1 1 1 1 1 ASSEMBLY OF COEFFICIENTS 1 1 1 1 1 1
                                                                                                 0120900
                                                                                                 0121000
        PRTE=1.0
                                                                                                 0121100
        DO 100 I=2, NIM1
                                                                                                 0121200
DO 101 J=2,NJM1
C----COMPUTE AREAS AND VOLUME
                                                                                                 0121300
                                                                                                 0121400
        AREAN=RV(J+1)*SEW(I)
                                                                                                 0121500
        AREAS=RV(J)*SEW(I)
                                                                                                 0121600
        AREAEW=RCV(J)*SNS(J)
                                                                                                 0121700
VOL=RCV(J)*SNS(J)*SEW(I)
C----CALCULATE CONVECTION COEFFICIENTS
                                                                                                 0121800
                                                                                                 0121900
        GN=0.5*(DEN(I,J)+DEN(I,J+1))*V(I,J+1)
GS=0.5*(DEN(I,J)+DEN(I,J-1))*V(I,J)
GE=0.5*(DEN(I,J)+DEN(I+1,J))*U(I+1,J)
                                                                                                 0122000
                                                                                                 0122100
                                                                                                 0122200
        GW=0.5*(DEN(I,J)+DEN(I-1,J))*U(I,J)
                                                                                                 0122300
        CN=GN*AREAN
                                                                                                 0122400
        CS=GS*AREAS
                                                                                                 0122500
        CE=GE*AREAEW
                                                                                                 0122600
        CW=GW*AREAEW
                                                                                                 0122700
CW=GW*AKEAEW

C------CALCULATE DIFFUSION COEFFICIENTS

GAMN=0.5*(VIS(I,J)+VIS(I,J+1))/PRTE

GAMS=0.5*(VIS(I,J)+VIS(I+1,J))/PRTE

GAME=0.5*(VIS(I,J)+VIS(I+1,J))/PRTE

GAMW=0.5*(VIS(I,J)+VIS(I-1,J))/PRTE

DN=GAMW*AREAN/DYNP(J)
                                                                                                 0122800
                                                                                                 0122900
                                                                                                 0123000
                                                                                                 0123100
                                                                                                 0123200
                                                                                                 0123300
        DS=GAMS*AREAS/DYPS(J)
                                                                                                 0123400
        DE=GAME*AREAEW/DXEP(I)
                                                                                                 0123500
         DW=GAMW*AREAEW/DXPW(I)
                                                                                                 0123600
C----SOURCE TERMS
                                                                                                 0123700
        SMP=CN-CS+CE-CW
CP=AMAX1(0.0,SMP)
                                                                                                 0123800
                                                                                                 0123900
        CPO=CP
                                                                                                 0124000
        DUDX=(U(I+1,J)-U(I,J))/SEW(I)
DVDY=(V(I,J+1)-V(I,J))/SNS(J)
                                                                                                0124100
                                                                                                0124200
        DUDY=((U(I,J)+U(I+1,J)+U(I,J+1)+U(I+1,J+1))/4.-(U(I,J)+U(I+1,J)+
                                                                                                0124300
       1U(I,J-1)+U(I+1,J-1))/4.)/SNS(J)
                                                                                                 0124400
        DVDX=((V(I,J)+V(I,J+1)+V(I+1,J)+V(I+1,J+1))/4.-(V(I,J)+V(I,J+1)+V(0124500
       1I-1,J)+V(I-1,J+1))/4.)/SEW(I)
DWDY=(W(I,J+1)-W(I,J-1))/(DYNP(J)+DYPS(J))-W(I,J)/R(J)
                                                                                                0124600
                                                                                                0124700
        DWDX=(W(I+1,J)-W(I-1,J))/(DXPW(I)+DXEP(I))
                                                                                                0124800
       GEN(I,J)=(2.*(DUDX**2+DVDY**2)+(DUDY+DVDX)**2)*VIS(I,J)
IF(INDCOS .EQ. 2) GEN(I,J)=GEN(I,J)+VIS(I,J)*(DWDY**2+DWDX**2)
IF(RV(J) .EQ. 0.) GO TO 110
VDR=V(I,J)/RV(J)
                                                                                                0124900
                                                                                                0125000
                                                                                                0125100
                                                                                                0125200
       IF(INDCOS .EQ. 2) GEN(I,J)=GEN(I,J)+VIS(I,J)*.5*
#(VDR+V(I,J+1)/RV(J+1))**2
                                                                                                0125300
                                                                                                0125400
  GO TO 120
110 IF(INDCOS .EQ. 2) GEN(I,J)=GEN(I,J)+VIS(I,J)*
                                                                                                0125500
                                                                                                0125600
      #0.5*(V(I,J+1)/RV(J+1))**2
                                                                                                0125700
  120 CONTINUE
                                                                                                0125800
         ---ASSEMBLE MAIN COEFFICIENTS
                                                                                                0125900
        AN(I,J) = AMAX1(ABS(0.5 \times CN),DN) - 0.5 \times CN
                                                                                                0126000
```

```
AS(I,J)=AMAX1(ABS(0.5*CS),DS)+0.5*CS
AE(I,J)=AMAX1(ABS(0.5*CE),DE)-0.5*CE
                                                                               0126100
                                                                               0126200
      AW(I,J)=AMAX1(ABS(0.5*CW),DW)+0.5*CW
                                                                               0126300
      SU(I,J)=CPO*TE(I,J)
                                                                               0126400
      SUKD(I,J)=SU(I,J)
                                                                               0126500
      SU(I,J)=SU(I,J)+GEN(I,J)*VOL
                                                                               0126600
      SP(I,J) = -CP
                                                                               0126700
      SPKD(I,J)=SP(I,J)
                                                                               0126800
      SP(I,J)=SP(I,J)-CD*CMU*DEN(I,J)**2*TE(I,J)*VOL/VIS(I,J)
                                                                               0126900
  101 CONTINUE
                                                                               0127000
  100 CONTINUE
                                                                               0127100
                                                                               0127200
CHAPTER 2 2 2 2 2 2 PROBLEM MODIFICATIONS 2 2 2 2 2
                                                                               0127300
C
                                                                               0127400
      CALL PROMOD (6)
                                                                               0127500
                                                                               0127600
CHAPTER 3 FINAL COEFFICIENT ASSEMBLY AND RESIDUAL SOURCE CALCULATION 3
                                                                               0127700
                                                                               0127800
      RESORK=0.0
                                                                               0127900
      DO 300 I=2, NIM1
DO 301 J=2, NJM1
                                                                               0128000
                                                                               0128100
      AP(I,J)=AN(I,J)+AS(I,J)+AE(I,J)+AW(I,J)-SP(I,J)
RESOR=AN(I,J)*TE(I,J+1)+AS(I,J)*TE(I,J-1)+AE(I,J)*TE(I+1,J)
                                                                               0128200
                                                                               0128300
            +AW(I,J)*TE(I-1,J)-AP(I,J)*TE(I,J)+SU(I,J)
                                                                               0128400
      VOL=RCV(J)*SNS(J)*SEW(I)
                                                                               0128500
      SORVOL=GREAT*VOL
                                                                               0128600
      IF(-SP(I,J).GT.0.5*SORVOL) RESOR=RESOR/SORVOL
RESORK=RESORK+ABS(RESOR)
                                                                               0128700
                                                                               0128800
C-----UNDER-RELAXATION
                                                                               0128900
      AP(I,J)=AP(I,J)/URFK
                                                                               0129000
      SU(I,J)=SU(I,J)+(1.-URFK)*AP(I,J)*TE(I,J)
                                                                              0129100
  301 CONTINUE
                                                                               0129200
  300 CONTINUE
                                                                               0129300
                                                                               0129400
                                                                              0129500
CHAPTER 4 4 4 4 4 SOLUTION OF DIFFERENCE EQUATIONS
                                                                    4
                                                              4
                                                                 4
                                                                               0129600
      DO 400 N=1, NSWPK
                                                                               0129700
  400 CALL LISOLV(2,2,NI,JMAX,IT,JT,TE,6)
                                                                               0129800
      RETURN
                                                                               0129900
                                                                               0130000
      END
C
                                                                              0130100
C-
                                                                               0130200
C
                                                                               0130300
      SUBROUTINE CALCED
                                                                              0130400
0130600
CHAPTER 0
           0 0 0 0 0 0 0 PRELIMINARIES 0
                                                      0
                                                         0
                                                                   Ω
                                                                       Ω
                                                                              0130700
                                                                              0130800
      COMMON
                                                                              0130900
     1/TDIS/RESORE, NSWPD, URFE
                                                                              0131000
     1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
                                                                              0131100
     1/GEOM/INDCOS,X(48),Y(24),DXEP(48),DXPW(48),DYNP(24),DYPS(24),
                                                                              0131200
        SNS(24),SEW(48),XU(48),YV(24),R(24),RV(24),
WFN(24),WFS(24),WFE(48),WFW(48),RCV(24),XND(48),XUND(48),
                                                                              0131300
                                                                              0131400
     #YND(24), YVND(24)
                                                                              0131500
     1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
                                                                              0131600
     1/COEF/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24),
                                                                              0131700
            SP(48,24)
                                                                              0131800
                      V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), 0131900
                                                                              0132000
     *ED(48,24),STFN(48,24),YSTLN(48,24),STVAL(24),USTAR(48,24),
```

```
*VSTAR(48,24),WSTAR(48,24),PSTAR(48,24),TESTAR(48,24),YSTLND(48,24) 0132100
     #, VISTAR(48,24)
                                                                              0132200
      COMMON
                                                                              0132300
                                                                              0132400
     1/TURB/GEN(48,24),CD,CMU,C1,C2,CAPPA,ELOG,PRED,PRTE
     1/WALLF/YPLUSN(48),XPLUSW(24),TAUN(48),TAUW(24)
                                                                              0132500
     1/SUSP/SUKD(48,24),SPKD(48,24)
                                                                              0132600
     1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                              0132700
             RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
                                                                              0132800
                                                                              0132900
CHAPTER 1 1 1 1 1 1 ASSEMBLY OF COEFFICIENTS 1 1 1 1 1
                                                                              0133000
                                                                              0133100
      DO 100 I=2,NIM1
                                                                              0133200
      (I)XAML=LL
                                                                              0133300
                                                                              0133400
      DO 101 J=2,JJ
C-----COMPUTÉ AREAS AND VOLUME
AREAN=RV(J+1)*SEW(I)
                                                                              0133500
                                                                              0133600
      AREAS=RV(J)*SEW(I)
                                                                              0133700
      AREAEW=RCV(J)*SNS(J)
                                                                              0133800
      VOL=RCV(J)*SNS(J)*SEW(I)
                                                                              0133900
C-----CALCULATE CONVECTION COEFFICIENTS
GN=0.5*(DEN(I,J)+DEN(I,J+1))*V(I,J+1)
                                                                              0134000
                                                                              0134100
                                                                              0134200
      GS=0.5*(DEN(I,J)+DEN(I,J-1))*V(I,J)
      GE=0.5*(DEN(I,J)+DEN(I+1,J))*U(I+1,J)
                                                                              0134300
      GW=0.5*(DEN(I,J)+DEN(I-1,J))*U(I,J)
                                                                              0134400
      CN=GN*AREAN
                                                                              0134500
                                                                              0134600
      CS=GS*AREAS
      CE=GE*AREAEW
                                                                              0134700
                                                                              0134800
      CW=GW*AREAEW
                                                                              0134900
C-----CALCULATE DIFFUSION COEFFICIENTS
      GAMN=0.5*(VIS(I,J)+VIS(I,J-1))/PRED
GAMS=0.5*(VIS(I,J)+VIS(I,J-1))/PRED
                                                                              0135000
                                                                              0135100
      GAME=0.5*(VIS(I,J)+VIS(I+1,J))/PRED
                                                                              0135200
                                                                              0135300
      GAMW=0.5*(VIS(I,J)+VIS(I-1,J))/PRED
                                                                              0135400
      DN=GAMN*AREAN/DYNP(J)
                                                                              0135500
      DS=GAMS*AREAS/DYPS(J)
      DE=GAME*AREAEW/DXEP(I)
                                                                              0135600
                                                                              0135700
       DW=GAMW*AREAEW/DXPW(I)
                                                                              0135800
C----SOURCE TERMS
      SMP=CN-CS+CE-CW
                                                                              0135900
      CP=AMAX1(0.0,SMP)
                                                                              0136000
                                                                              0136100
      CPO=CP
C----ASSEMBLE MAIN COEFFICIENTS
                                                                              0136200
      AN(I,J)=AMAX1(ABS(0.5*CN),DN)-0.5*CN
                                                                              0136300
                                                                              0136400
      AS(I,J)=AMAX1(ABS(0.5*CS),DS)+0.5*CS
                                                                              0136500
      AE(I,J)=AMAX1(ABS(0.5*CE),DE)-0.5*CE
      AW(I,J)=AMAX1(ABS(0.5*CW),DW)+0.5*CW
                                                                              0136600
      SU(I,J)=CPO*ED(I,J)
SUKD(I,J)=SU(I,J)
                                                                              0136700
                                                                              0136800
      SU(I,J)=SU(I,J)+C1*CMU*GEN(I,J)*VOL*DEN(I,J)*TE(I,J)/VIS(I,J)
                                                                              0136900
                                                                              0137000
      SP(I,J) = -CP
      SPKD(I,J)=SP(I,J)
                                                                              0137100
      SP(I,J)=SP(I,J)-C2*DEN(I,J)*ED(I,J)*VOL/TE(I,J)
                                                                              0137200
                                                                              0137300
  101 CONTINUE
                                                                              0137400
  100 CONTINUE
                                                                              0137500
CHAPTER 2 2 2 2 2 PROBLEM MODIFICATIONS 2 2 2 2
                                                                  2
                                                                              0137600
                                                                              0137700
                                                                              0137800
      CALL PROMOD (7)
                                                                              0137900
CHAPTER 3 FINAL COEFFICIENT ASSEMBLY AND RESIDUAL SOURCE CALCULATION 3
                                                                              0138000
```

```
C
                                                                        0138100
      RESORE=0.0
                                                                        0138200
      DO 300 I=2,NIM1
DO 301 J=2,NJM1
                                                                        0138300
                                                                        0138400
     0138500
                                                                        0138600
                                                                        0138700
      VOL=RCV(J)*SNS(J)*SEW(I)
                                                                        0138800
      SORVOL=GREAT*VOL
                                                                        0138900
      IF(-SP(I,J).GT.0.5*SORVOL) RESOR=RESOR/SORVOL
                                                                        0139000
      RESORE=RESORE+ABS(RESOR)
                                                                        0139100
C-----UNDER-RELAXATION
                                                                        0139200
      AP(I,J)=AP(I,J)/URFE
                                                                        0139300
      SU(I,J)=SU(I,J)+(1.-URFE)*AP(I,J)*ED(I,J)
                                                                        0139400
  301 CONTINUE
                                                                        0139500
  300 CONTINUE
                                                                        0139600
                                                                        0139700
CHAPTER
       4 4 4 4 4 SOLUTION OF DIFFERENCE EQUATIONS 4
                                                           4 4
                                                                 4
                                                                        0139800
                                                                        0139900
      DO 400 N=1, NSWPD
                                                                        0140000
  400
      CALL LISOLV(2,2,NI,JMAX,IT,JT,ED,7)
                                                                        0140100
      RETURN
                                                                        0140200
      END
                                                                        0140300
C
                                                                        0140400
C
                                                                        0140500
C
                                                                        0140600
      SUBROUTINE LISOLV(ISTART, JSTART, NI, JMAX, IT, JT, PHI, NCHAP)
                                                                        0140700
0140900
CHAPTER 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0
                                                           0 0
                                                                 O
                                                                        0141000
                                                                        0141100
      DIMENSION PHI(IT, JT), A(48), B(48), C(48), D(48), JMAX(IT)
                                                                        0141200
      COMMON
                                                                        0141300
     1/COEF/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24),
                                                                        0141400
            SP(48,24)
     1
                                                                        0141500
     1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                        0141600
            RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
                                                                        0141700
      JSM1=JSTART-1
                                                                        0141800
      NIM1=NI-1
                                                                        0141900
      A(JSM1)=0.0
                                                                        0142000
C----COMMENCE W-E SWEEP
                                                                        0142100
      DO 100 I=ISTART, NIM1
                                                                        0142200
      C(JSM1)=PHI(I,JSM1)
                                                                        0142300
C-----COMMENCE S-N TRAVERSE
                                                                        0142400
      JI=JMAX(I)
                                                                        0142500
IF(NCHAP .EQ. 2) JI=JMAX(I-1)
DO 101 J=JSTART,JI
C----ASSEMBLE TDMA COEFFICIENTS
                                                                        0142600
                                                                        0142700
                                                                        0142800
      A(J) = AN(I, J)
                                                                        0142900
      B(J) = AS(I,J)
                                                                        0143000
      C(J)=AE(I,J)*PHI(I+1,J)+AW(I,J)*PHI(I-1,J)+SU(I,J)
                                                                        0143100
      D(J)=AP(I,J)
                                                                        0143200
C-----CALCULATE COEFFICIENTS OF RECURRENCE FORMULA
                                                                        0143300
      TERM=1./(D(J)-B(J)*A(J-1))
                                                                        0143400
      A(J)=A(J)\times TERM
                                                                        0143500
      C(J)=(C(J)+B(J)*C(J-1))*TERM
                                                                        0143600
 101 CONTINUE
                                                                        0143700
C----OBTAIN NEW PHI)S
                                                                        0143800
      DO 102 JJ=JSTART,JI
                                                                        0143900
      J=JI+1+JSM1-JJ
                                                                        0144000
```

```
0144100
  102 PHI(I,J)=A(J)*PHI(I,J+1)+C(J)
                                                                               0144200
  100 CONTINUE
                                                                               0144300
      RETURN
                                                                               0144400
      END
                                                                                0144500
                                                                               0144600
                                                                               0144700
                                                                               0144800
      SUBROUTINE PRINT(ISTART, JSTART, NI, NJ, IT, JT, X, Y, PHI, HEAD)
0145000
                                                                                0145100
      DIMENSION PHI(IT, JT), X(IT), Y(JT), HEAD(9), STORE(48)
                                                                                0145200
      ISKIP=1
                                                                                0145300
      JSKIP=1
                                                                                0145400
      WRITE(6,110)HEAD
                                                                                0145500
      ISTA=ISTART-12
                                                                                0145600
  100 CONTINUE
                                                                                0145700
      ISTA=ISTA+12
                                                                                0145800
      IEND=ISTA+11
                                                                                0145900
      IF(NI.LT.IEND)IEND=NI
      WRITE(6,111)(I,I=ISTA,IEND,ISKIP)
                                                                                0146000
                                                                                0146100
      WRITE(6,114)(X(I),I=ISTA,IEND,ISKIP)
                                                                                0146200
      WRITE(6,112)
                                                                                0146300
      DO 101 JJ=JSTART, NJ, JSKIP
                                                                                0146400
      J=JSTART+NJ-JJ
      DO 120 I=ISTA, IEND
                                                                                0146500
      A=PHI(I,J)
                                                                                0146600
                                                                                0146700
      IF(ABS(A).LT.1.E-20) A=0.0
                                                                                0146800
      STORE(I)=A
  101 WRITE(6,113)J,Y(J),(STORE(I),I=ISTA,IEND,ISKIP)
                                                                                0146900
      IF(IEND.LT.NI)GO TO 100
                                                                                0147000
                                                                                0147100
      RETURN
  110 FORMAT(1H0,17(2H*-),7X,9A4,7X,17(2H-*))
111 FORMAT(1H0,13H I = ,12,1119)
                                                                                0147200
  110 FORMAT(110,13H
111 FORMAT(1H0,13H
7)
                                                                                0147300
                                                                                0147400
  113 FORMAT(13,0PF8.5,1X,1P12E9.2)
114 FORMAT(11H X = ,F8.5,11F9.5)
                                                                                0147500
                                                                                0147600
                                                                                0147700
      END
                                                                                0147800
C
                                                                                0147900
                                                                                0148000
C
                                                                                0148100
      SUBROUTINE PROMOD (NCHAP)
0148300
C
CHAPTER 0 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0 0 0 0 0
                                                                                0148400
                                                                                0148500
      COMMON
                                                                                0148600
     1/UVEL/RESORU, NSWPU, URFU, DXEPU(48), DXPWU(48), SEWU(48)
                                                                                0148700
     1/VVEL/RESORV, NSWPV, URFV, DYNPV(24), DYPSV(24), SNSV(24)
                                                                                0148800
     */WVEL/ RESORW, NSWPW, URFW 0148900

*/VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), 0149000

*ED(48,24),STFN(48,24),YSTLN(48,24),STVAL(24),USTAR(48,24), 0149100
     *VSTAR(48,24), WSTAR(48,24), PSTAR(48,24), TESTAR(48,24), YSTLND(48,24) 0149200
                                                                                0149300
     #, VISTAR(48,24)
     1/PCOR/RESORM, NSWPP, URFP, DU(48,24), DV(48,24), IPREF, JPREF
                                                                                0149400
                                                                                0149500
     1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
     1/GEOM/INDCOS,X(48),Y(24),DXEP(48),DXPW(48),DYNP(24),DYPS(24),
                                                                                0149600
        SNS(24), SEW(48), XU(48), YV(24), R(24), RV(24), WFN(24), WFS(24), WFE(48), WFW(48), RCV(24), XND(48), XUND(48),
                                                                                0149700
                                                                                0149800
                                                                                0149900
     #YND(24), YVND(24)
                                                                                0150000
      COMMON
```

```
1/FLUPR/URFVIS, VISCOS, DENSIT, PRANDT, DEN(48,24), VIS(48,24)
                                                                                        0150100
      1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                                        0150200
               RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
                                                                                        0150300
      1/SUSP/SUKD(48,24),SPKD(48,24)
1/COEF/AP(48,24),AN(48,24),AS(48,24),AE(48,24),AW(48,24),SU(48,24),O150500
              SP(48,24)
                                                                                        0150600
      1/TURB/GEN(48,24),CD,CMU,C1,C2,CAPPA,ELOG,PRED,PRTE
                                                                                        0150700
      1/WALLF/YPLUSN(48), XPLUSW(24), TAUN(48), TAUW(24)
                                                                                        0150800
IF(NCHAP .EQ. 2) GO TO 1150
IF(JSTEP .EQ. NJM1) GO TO 1150
C----OUT OF RANGE VALUES
DO 1100 I=2,NI
IF(JMAX(I) .EQ. NJM1) GO TO 1150
                                                                                        0150900
                                                                                        0151000
                                                                                        0151100
                                                                                        0151200
                                                                                        0151300
                                                                                        0151400
       JJ=JMAXP1(I)
       DO 1100 J=JJ,NJM1
                                                                                        0151500
 1100 SP(I,J)=-GREAT
                                                                                        0151600
 1150 CONTINUE
                                                                                        0151700
       GO TO (1,2,3,4,5,6,7,8), NCHAP
                                                                                        0151800
C
                                                                                        0151900
C
                                                                                        0152000
                                                                                        0152100
CHAPTER 1 1 1 1 1 1 1 1 1 PROPERTIES 1 1 1 1 1 1 1 1
                                                                                        0152200
                                                                                        0152300
     1 CONTINUE
                                                                                        0152400
    -----NO MODIFICATIONS FOR THIS PROBLEM
                                                                                        0152500
       RETURN
                                                                                       0152600
C
                                                                                        0152700
CHAPTER 2 2 2 2 2 2 2 2 U MOMENTUM 2 2 2 2 2 2
                                                                           2
                                                                                        0152800
                                                                                        0152900
     2 CONTINUE
                                                                                        0153000
      ----OUT OF RANGE VALUES
IF(JSTEP .EQ. NJM1) GO TO 202
DO 200 I=3,NI
                                                                                        0153100
                                                                                        0153200
                                                                                        0153300
       IF(JMAX(I-1) .EQ. NJM1) GO TO 202
                                                                                        0153400
       JJ=JMAXP1(I-1)
                                                                                        0153500
       DO 200 J=JJ,NJM1
SP(I,J)=-GREAT
                                                                                       0153600
                                                                                       0153700
  200 CONTINUE
                                                                                       0153800
  202 CONTINUE
                                                                                       0153900
C----TOP WALL
                                                                                       0154000
       CDTERM=CMU**0.25
                                                                                       0154100
       DO 210 I=3,NIM1
J=JMAX(I-1)
                                                                                       0154200
                                                                                       0154300
       YP=YV(J+1)-Y(J)
                                                                                       0154400
       SQRTK=SQRT(0.5*(TE(I,J)+TE(I-1,J)))
                                                                                       0154500
       DENU=0.5*(DEN(I,J)+DEN(I-1,J))
YPLUSA=0.5*(YPLUSN(I)+YPLUSN(I-1))
                                                                                       0154600
                                                                                       0154700
       IF(YPLUSA.LE.11.63)
       IF(YPLUSA.LE.11.63) GO TO 211
TMULT=DENU*CDTERM*SQRTK*CAPPA/ALOG(ELOG*YPLUSA)
                                                                                       0154800
                                                                                       0154900
       GO TO 212
                                                                                       0155000
  211 TMULT=VISCOS/YP
                                                                                       0155100
                                                                                       0155200
  212 CONTINUE
  205 SP(I,J)=SP(I,J)-TMULT*SEWU(I)*RV(J+1)
                                                                                       0155300
       IF(JMAX(I-1) .NE. JMAX(I)) SP(I,J)=SP(I,J)/2.
                                                                                       0155400
  210 AN(I,J)=0.
                                                                                       0155500
    ----SIDE WALL
IF(JSTEP .EQ. NJM1) GO TO 214
                                                                                       0155600
                                                                                       0155700
       DO 225 I=3,NIM1
IF(JMAX(I-2) .GE. JMAX(I-1)) GO TO 225
                                                                                       0155800
                                                                                       0155900
       JJ=JMAXP1(I-2)
                                                                                       0156000
```

```
0156100
      JI=JMAX(I-1)
                                                                                   0156200
      DO 220 J=JJ,JI
AW(I,J)=0.
                                                                                   0156300
                                                                                   0156400
 220 CONTINUE
                                                                                   0156500
  225 CONTINUE
                                                                                   0156600
      ----SYMMETRY AXIS
                                                                                   0156700
 214 CONTINUE
                                                                                   0156800
      DO 203 I=1,NI
                                                                                   0156900
  203 AS(I,2)=0.
                                                                                    0157000
C----OUTLET
                                                                                    0157100
      ARDENT=0.0
                                                                                    0157200
      FLOW=0.0
      DO 209 J=2,NJM1
ARDEN=0.50*(DEN(NIM1,J)+DEN(NIM1-1,J))*RCV(J)*SNS(J)
                                                                                    0157300
                                                                                    0157400
                                                                                    0157500
      ARDENT=ARDENT+ARDEN
                                                                                    0157600
  209 FLOW=FLOW+ARDEN*U(NIM1,J)
                                                                                    0157700
      UINC=(FLOWIN-FLOW)/ARDENT
                                                                                    0157800
      DO 215 J=2,NJM1
                                                                                    0157900
  215 U(NI,J)=U(NIM1,J)+UINC
                                                                                    0158000
      RETURN
                                                                                    0158100
CHAPTER 3 3 3 3 3 3 3 3 V MOMENTUM 3 3 3 3 3 3 3 3
                                                                                    0158200
                                                                                    0158300
                                                                                    0158400
    3 CONTINUE
                                                                                    0158500
C----SIDE WALL
                                                                                    0158600
      IF(JSTEP .EQ. NJM1) GO TO 314
CDTERM=CMU**0.25
                                                                                    0158700
      DO 325 I=2,NIM1
IF(JMAX(I-1) .GE. JMAX(I)) GO TO 325
JJ=JMAXP1(I-1)
                                                                                    0158800
                                                                                    0158900
                                                                                    0159000
                                                                                    0159100
       JI=JMAX(I)
                                                                                    0159200
      DO 320 J=JJ,JI
                                                                                    0159300
      XP = X(I) - XU(I)
                                                                                    0159400
      SQRTK=SQRT(0.5*(TE(I,J)+TE(I,J-1)))
      DENV=0.5*(DEN(I,J)+DEN(I,J-1))
XPLUSA=0.5*(XPLUSW(J)+XPLUSW(J-1))
IF(XPLUSA.LE.11.63) GO TO 311
                                                                                    0159500
                                                                                    0159600
                                                                                    0159700
       TMULT=DENV*CDTERM*SQRTK*CAPPA/ALOG(ELOG*XPLUSA)
                                                                                    0159800
                                                                                    0159900
  GO TO 312
311 TMULT=VISCOS/XP
                                                                                    0160000
                                                                                    0160100
  312 CONTINUE
  305 SP(I,J)=SP(I,J)-TMULT*SNSV(J)*RV(J)
IF(J .EQ. JMAXP1(I-1)) SP(I,J)=SP(I,J)/2.
                                                                                    0160200
                                                                                    0160300
                                                                                    0160400
  310 AW(I,J)=0.0
320 CONTINUE
                                                                                    0160500
                                                                                    0160600
  325 CONTINUE
                                                                                    0160700
  -----TOP WALL
  314 CONTINUE
                                                                                    0160800
                                                                                    0160900
      DO 313 I=2, NIM1
J=JMAX(I)
                                                                                    0161000
                                                                                    0161100
  313 AN(I,J)=0.
                                                                                    0161200
      RETURN
                                                                                    0161300
CHAPTER 4 4 4 4 4 4 PRESSURE CORRECTION 4 4 4 4
                                                                                    0161400
                                                                                    0161500
C
                                                                                    0161600
    4 CONTINUE
                                                                                    0161700
C----SIDE WALL
                                                                                    0161800
      IF(JSTEP .EQ. NJM1) GO TO 414
                                                                                    0161900
       DO 412 I=2, NIM1
                                                                                    0162000
       IF(JMAX(I-1) .GE. JMAX(I)) GO TO 412
```

```
JJ=JMAXP1(I-1)
                                                                                   0162100
       JI=JMAX(I)
                                                                                   0162200
      DO 410 J=JJ,JI
                                                                                   0162300
  AW(I,J)=0.
410 CONTINUE
                                                                                   0162400
                                                                                   0162500
  412 CONTINUE
                                                                                   0162600
C----TOP WALL
                                                                                   0162700
  414 CONTINUE
                                                                                   0162800
      DO 402 I=2, NIM1
                                                                                   0162900
       J=JMAX(I)
                                                                                   0163000
  402 AN(I,J)=0.0
                                                                                   0163100
      ----SYMMETRY AXIS
                                                                                   0163200
      DO 420 I=2,NIM1
                                                                                   0163300
       AS(I,2)=0.0
                                                                                   0163400
  420 CONTINUE
                                                                                   0163500
       ----OUTLET
                                                                                   0163600
      DO 440 J=2,NJM1
AE(NIM1,J)=0.0
                                                                                   0163700
                                                                                   0163800
  440 CONTINUE
                                                                                   0163900
      RETURN
                                                                                   0164000
                                                                                   0164100
CHAPTER 5 5 5 5 5 5 5 THERMAL ENERGY 5 5 5 5 5 5 5 5 5
                                                                                   0164200
                                                                                   0164300
    5 CONTINUE
                                                                                   0164400
C-----NO MODIFICATIONS FOR THIS PROBLEM
                                                                                   0164500
      RETURN
                                                                                   0164600
                                                                                   0164700
CHAPTER 6 6 6 6 TURBULENT KINETIC ENERGY 6 6 6
                                                                                6 0164800
                                                                 6
                                                                      6
                                                                         6
C
                                                                                   0164900
С
                                                                                   0165000
    6 CONTINUE
                                                                                   0165100
C----TOP WALL
                                                                                   0165200
      CDTERM=CMU**0.25
                                                                                   0165300
      DO 610 I=2,NIM1
                                                                                   0165400
       (I)XAML=L
                                                                                   0165500
       DWDY=(W(I,J+1)-W(I,J-1))/(DYNP(J)+DYPS(J))
                                                                                   0165600
      UAVG=U(I,J)*WFE(I)+(1.-WFE(I))*U(I+1,J)
UEFF=SQRT(UAVG*UAVG + W(I,J)*W(I,J))
                                                                                   0165700
                                                                                   0165800
       YP=YV(J+1)-Y(J)
                                                                                   0165900
       DENU=DEN(I,J)
                                                                                   0166000
                                                                                   0166100
       SQRTK=SQRT(TE(I,J))
       VOL=RCV(J)*SNS(J)*SEW(I)
                                                                                   0166200
       YPLUSN(I)=DENU*SQRTK*CDTERM*YP/VISCOS
                                                                                   0166300
      IF(YPLUSN(I) .LE. 11.63) GO TO 608
TMULT=DENU*CDTERM*SQRTK*CAPPA/ALOG(ELOG*YPLUSN(I))
                                                                                   0166400
                                                                                   0166500
       TAUN(I) = - TMULT * UEFF
                                                                                   0166600
       DITERM=DEN(I,J)*(CMU**.75)*SQRTK*ALOG(ELOG*YPLUSN(I))/(CAPPA*YP)
                                                                                   0166700
  GO TO 609
608 TAURX=-VISCOS*UAVG/YP
                                                                                   0166800
                                                                                   0166900
       TAURW=VISCOS*(-W(I,J)/YP - W(I,J)/Y(J))
                                                                                   0167000
       TAUN(I)=SQRT(TAURX**2+TAURW**2)
                                                                                   0167100
       DITERM=DEN(I,J)*(CMU**.75)*SQRTK*YPLUSN(I)/YP
                                                                                   0167200
  609 DUDY=((U(I,J)+U(I+1,J)+U(I,J+1)+U(I+1,J+1))/4.-(U(I,J)+U(I+1,J)+U(0167300
4I,J-1)+U(I+1,J-1))/4.)/SNS(J)
GENCOU=TAUN(I)**2/VIS(I,J)
0167500
       GENRES=GEN(I,J)-VIS(I,J)*(DUDY**2+(DWDY-W(I,J)/Y(J))**2)
                                                                                  0167600
       GEN(I,J)=GENRES+GENCOU
                                                                                   0167700
       SU(I,J)=GEN(I,J)*VOL+SUKD(I,J)
                                                                                   0167800
       SP(I,J)=-DITERM*VOL+SPKD(I,J)
                                                                                  0167900
       0.0=(L,I)MA
                                                                                   0168000
```

```
610 CONTINUE
                                                                           0168100
      TAUN(NI)=TAUN(NIM1)
                                                                           0168200
                                                                           0168300
C----SIDE WALL
                                                                           0168400
      IF(JSTEP .EQ. NJM1) GO TO 614
      DO 625 I=2,NIM1
                                                                           0168500
      IF(JMAX(I-1) .GE. JMAX(I)) GO TO 625
                                                                           0168600
                                                                           0168700
      JJ=JMAXP1(I-1)
                                                                           0168800
      (I)XAML=IL
                                                                           0168900
      DO 620 J=JJ,JI
      DWDX=(W(I+1,J)-W(I-1,J))/(DXPW(I)+DXEP(I))
                                                                           0169000
      VAVG=V(I,J)*WFN(J)+(1.-WFN(J))*V(I,J+1)
VEFF=SQRT(VAVG*VAVG + W(I,J)*W(I,J))
                                                                           0169100
                                                                           0169200
                                                                           0169300
      XP = X(I) - XU(I)
                                                                           0169400
      DENV=DEN(I,J)
                                                                           0169500
      SQRTK=SQRT(TE(I,J))
                                                                           0169600
      VOL=RCV(J)*SNS(J)*SEW(I)
      XPLUSW(J)=DENV*SQRTK*CDTERM*XP/VISCOS
                                                                           0169700
      IF(XPLUSW(J) .LE. 11.63) GO TO 621
TMULT=DENV*CDTERM*SQRTK*CAPPA/ALOG(ELOG*XPLUSW(J))
                                                                           0169800
                                                                           0169900
                                                                           0170000
      TAUW(J)=-TMULT*VEFF
      DITERM=DEN(I,J)*(CMU**.75)*SQRTK*ALOG(ELOG*XPLUSW(J))/(CAPPA*XP)
                                                                           0170100
                                                                           0170200
      GO TO 622
  621 TAUXR=VISCOS*VAVG/XP
                                                                           0170300
      TAUXW=VISCOS*W(I,J)/XP
                                                                           0170400
      TAUW(J)=SQRT(TAUXR**2+TAUXW**2)
                                                                           0170500
      DITERM=DEN(I,J)*(CMU**.75)*SQRTK*XPLUSW(J)/XP
                                                                           0170600
  0171100
      GEN(I, J) = GENRES+GENCOU
                                                                           0171200
      SU(I,J)=SU(I,J)+SUKD(I,J)+GEN(I,J)*VOL
      SP(I,J)=SP(I,J)+SPKD(I,J)-DITERM*VOL
                                                                           0171300
      0.0=(L,I)WA
                                                                           0171400
                                                                           0171500
  620 CONTINUE
                                                                           0171600
  625 CONTINUE
                                                                           0171700
      (IMUN)WUAT=(LN)WUAT
                                                                           0171800
C----SYMMETRY AXIS
  614 CONTINUE
                                                                           0171900
                                                                           0172000
      J=2
                                                                           0172100
      DO 630 I=2,NIM1
      DUDY=((U(I,J)+U(I+1,J)+U(I,J+1)+U(I+1,J+1))/4.-(U(I,J)+U(I+1,J)+
                                                                           0172200
                                                                           0172300
     3U(I,J-1)+U(I+1,J-1))/4.)/SNS(J)
                                                                           0172400
      VOL=RCV(J)*SNS(J)*SEW(I)
      GEN(I,J)=GEN(I,J)-VIS(I,J)*DUDY**2
                                                                           0172500
                                                                           0172600
      SU(I,J)=SUKD(I,J)+GEN(I,J)*VOL
                                                                           0172700
  630 AS(I,2)=0.0
                                                                           0172800
      ----OUTLET
                                                                           0172900
      DO 640 J=2,NJM1
AE(NIM1,J)=0.0
                                                                           0173000
                                                                           0173100
  640 CONTINUE
                                                                           0173200
      RETURN
                                                                           0173300
CHAPTER 7 7 7 7 7 7 7 7 DISSIPATION 7 7 7 7 7 7 7 7 7
                                                                           0173400
                                                                           0173500
                                                                           0173600
    7 CONTINUE
                                                                           0173700
C----TOP WALL
                                                                           0173800
      DO 710 I=2,NIM1
                                                                           0173900
      J=JMAX(I)
                                                                           0174000
      YP=YV(J+1)-Y(J)
```

```
TERM=(CMU**.75)/(CAPPA*YP)
                                                                                      0174100
       SU(I,J)=GREAT*TERM*TE(I,J)**1.5
                                                                                      0174200
  710 SP(I,J) = -GREAT
                                                                                      0174300
       ----SIDE WALL
IF(JSTEP .EQ. NJM1) GO TO 714
DO 725 I=2,NIM1
                                                                                      0174400
                                                                                      0174500
                                                                                      0174600
       IF(JMAX(I-1) .GE. JMAX(I)) GO TO 725
                                                                                      0174700
       JJ=JMAXP1(I-1)
                                                                                      0174800
       (I)XAML=IL
                                                                                      0174900
       DO 720 J=JJ,JI
                                                                                      0175000
       IF(J .EQ. JMAX(I)) GO TO 720
XP=X(I)-XU(I)
                                                                                      0175100
                                                                                      0175200
       TERM=(CMU**.75)/(CAPPA*XP)
SU(I,J)=GREAT*TERM*TE(I,J)**1.5
                                                                                      0175300
                                                                                      0175400
  SP(I,J)=-GREAT
720 CONTINUE
                                                                                      0175500
                                                                                      0175600
  725 CONTINUE
                                                                                      0175700
C----SYMMETRY AXIS
                                                                                      0175800
  714 CONTINUE
                                                                                      0175900
  DO 730 I=730 AS(I,2)=0.0
                 I=2,NIM1
                                                                                      0176000
                                                                                      0176100
C----OUTLET
                                                                                      0176200
      DO 740 J=2,NJM1
AE(NIM1,J)=0.0
                                                                                      0176300
                                                                                      0176400
  740 CONTINUE
                                                                                      0176500
       RETURN
                                                                                      0176600
                                                                                      0176700
0176800
       SWIRL VELOCITY
                                                                                      0176900
Ċ
                                                                                      0177000
    8 CONTINUE
                                                                                      0177100
C----TOP WALL
                                                                                      0177200
       CDTERM=CMU**0.25
                                                                                      0177300
       DO 810 I=2, NIM1
                                                                                      0177400
       J=JMAX(I)
                                                                                     0177500
       YP = YV(J+1) - Y(J)
                                                                                     0177600
       SQRTK=SQRT(TE(I,J))
                                                                                     0177700
       DENW=DEN(I,J)
                                                                                     0177800
       YPLUSA=YPLUSH(I)
                                                                                     0177900
       IF(YPLUSA .LE. 11.63) GO TO 811
TMULT=DENW*CDTERM*SQRTK*CAPPA/ALOG(ELOG*YPLUSA)-VIS(I,J)/R(J)
                                                                                     0178000
                                                                                     0178100
       GO TO 812
                                                                                     0178200
  811 TMULT=VISCOS/YP
                                                                                     0178300
  812 SP(I,J)=SP(I,J)-TMULT*SEW(I)*RV(J+1)
                                                                                     0178400
  AN(I,J)=0.0
810 CONTINUE
                                                                                     0178500
                                                                                     0178600
C-----SIDE WALL

IF(JSTEP .EQ. NJM1) GO TO 814

DO 855 I=2,NIM1

IF(JMAX(I-1) .GE. JMAX(I)) GO TO 855

JJ=JMAXP1(I-1)
                                                                                     0178700
                                                                                     0178800
                                                                                     0178900
                                                                                     0179000
                                                                                     0179100
       JI=JMAX(I)
                                                                                     0179200
       DO 850 J=JJ, JI
                                                                                     0179300
       XP = X(I) - XU(I)
                                                                                     0179400
       SQRTK=SQRT(TE(I,J))
                                                                                     0179500
       DEHW=DEH(I,J)
                                                                                     0179600
       XPLUSA=XPLUSW(J)
                                                                                     0179700
      IF(XPLUSA .LE. 11.63) GO TO 851
TMULT=DENW*CDTERM*SQRTK*CAPPA/ALOG(ELOG*XPLUSA)
                                                                                     0179800
                                                                                     0179900
       GO TO 852
                                                                                     0180000
```

```
0180100
851
     TMULT=VISCOS/XP
  852 SP(I,J)=SP(I,J)-TMULT*SNS(J)*RCV(J)
                                                                             0180200
                                                                             0180300
      AW(I,J)=0.
                                                                             0180400
  850 CONTINUE
                                                                             0180500
 855 CONTINUE
                                                                             0180600
C--
   -----SYMMETRY AXIS
  814 CONTINUE
                                                                             0180700
   -----FIX W FOR SOLID BODY ROTATION AT J=2 USING W AT J=3
                                                                             0180800
                                                                             0180900
      DO 860 I=2, NIM1
      TERM=W(I,3)*R(2)/R(3)
                                                                             0181000
  SU(I,2)=GREAT*TERM
860 SP(I,2)=-GREAT
                                                                             0181100
                                                                             0181200
                                                                             0181300
      ----OUTLET
C--
      DO 870 J=2,NJM1
                                                                             0181400
                                                                             0181500
      AE(NIMI, J)=0.
870
                                                                             0181600
      RETURN
                                                                             0181700
      END
                                                                             0181800
C
                                                                             0181900
C-
                                                                             0182000
C
                                                                             0182100
      SUBROUTINE STRMFN
0182300
                                                                             0182400
CHAPTER 0 0 0 0 0 0 0 0 PRELIMINARIES 0 0 0 0
                                                                             0182500
                                                                             0182600
     1/VVEL/RESORV, NSWPV, URFV, DYNPV(24), DYPSV(24), SNSV(24)
                                                                             0182700
     */VAR/U(48,24), V(48,24), W(48,24), P(48,24), PP(48,24), TE(48,24), *ED(48,24), STFN(48,24), YSTLN(48,24), STVAL(24), USTAR(48,24),
                                                                             0182800
                                                                             0182900
     *VSTAR(48,24), WSTAR(48,24), PSTAR(48,24), TESTAR(48,24), YSTLND(48,24)
                                                                             0183000
                                                                             0183100
     #, VISTAR(48,24)
     1/ALL/IT, JT, NI, NJ, NIM1, NJM1, GREAT, JMAX(48), JMAXP1(48)
                                                                             0183200
     0183300
                                                                             0183400
        WFN(24), WFS(24), WFE(48), WFW(48), RCV(24), XND(48), XUND(48),
                                                                             0183500
                                                                             0183600
     #YND(24), YVND(24)
     1/KASE T1/UIN, TEIN, EDIN, FLOWIN, ALAMDA,
                                                                             0183700
     2 RSMALL, RLARGE, AL1, AL2, JSTEP, ISTEP, JSTP1, JSTM1, ISTP1, ISTM1
1/PLOTT/NSTLN, NPLTLN, NPTS, YSLPLT(10, 48), XUDPLT(48), INPLOT
                                                                             0183800
                                                                             0183900
                                                                             0184000
      LOGICAL INPLOT
                                                                             0184100
CHAPTER 1 1 1 1 1 CALCULATE STREAM FCN BASED ON VOLUMETRIC FLOW
                                                                             0184200
                                                                             0184300
                                                                             0184400
                                                                             0184500
      Q=UIN*(RSMALL**2)/2.
                                                                             0184600
      DO 400 I=2,NI
                                                                             0184700
      IF(JMAX(I-1) .LT. 5) GO TO 400
      STFN(I,2)=(Y(2)*R(2)*U(I,2)*.5)/Q
                                                                             0184800
      JJ=JMAX(I-1)
                                                                             0184900
                                                                             0185000
      DO 200 J=3,JJ
      STFN(I, J)=STFN(I, J-1)+SNSV(J)*(R(J-1)*U(I, J-1)+R(J)*U(I, J))*.5/Q
                                                                             0185100
                                                                             0185200
  200 CONTINUE
                                                                             0185300
  400 CONTINUE
C
                                                                             0185400
                                                                             0185500
      DO 800 I=2,NI
                                                                             0185600
      IJ=JMAXP1(I-1)
                                                                             0185700
      DO 700 K=1, NSTLN
                                                                             0185800
      AK=K-1
                                                                             0185900
      STVAL(K) = AK * . 1
                                                                             0186000
      JJ=JMAX(I-1)
```

```
DO 600 J=2,JJ
                                                                                     0186100
       IF(STFN(I,J) .GE. STVAL(K)) GO TO 650
                                                                                      0186200
  600 CONTINUE
                                                                                      0186300
       YSTLN(I,K)=RV(IJ)
                                                                                      0186400
  GO TO 670
650 IF(J .EQ. 2) YSTLN(I,K)=0.0
IF(J .EQ. 2) GO TO 670
                                                                                      0186500
                                                                                      0186600
                                                                                      0186700
       SLOPE=(STVAL(K)-STFN(I,J-1))/(STFN(I,J)-STFN(I,J-1))
                                                                                      0186800
       YSTLN(I,K)=Y(J-1)+SLOPE*(Y(J)-Y(J-1))
                                                                                      0186900
  670 CONTINUE
                                                                                      0187000
       YSTLND(I,K)=YSTLN(I,K)/(2.*RLARGE)
                                                                                     0187100
  700 CONTINUE
                                                                                      0187200
  800 CONTINUE
                                                                                      0187300
       IF(.NOT. INPLOT) GO TO 745
                                                                                      0187400
       N = 0
                                                                                      0187500
       DO 730 K=1,11,2
                                                                                      0187600
       N=N+1
                                                                                      0187700
       DO 730 I=1, NIM1
                                                                                      0187800
       YSLPLT(N, I)=YSTLND(I+1,K)
                                                                                      0187900
  730 CONTINUE
                                                                                      0188000
       DO 740 I=1,NIM1
XUDPLT(I)=XUND(I+1)
                                                                                      0188100
                                                                                      0188200
  740 CONTINUE
                                                                                      0188300
  745 NPTS=NIM1
                                                                                      0188400
       RETURN
                                                                                      0188500
       END
                                                                                      0188600
C
                                                                                      0188700
С
                                                                                      0188800
       SUBROUTINE PLOT (X,IDIM,IMAX,XAXIS,Y,JDIM,JMAX,YAXES,SYMB L,LA)
                                                                                     0188900
0189100
C
   SUBROUTINE FOR PLOTTING J CURVES OF Y(J,I) AGAINST X(I).
                                                                                     0189200
C
                                                                                      0189300
   X AND Y ARE ASSUMED TO BE IN ANY RANGE EXCEPT THAT NEGATIVE VALUES * 0189400
   ARE PLOTTED AS ZERO. * 0189500 * AND Y ARE SCALED TO THE RANGE O. TO 1. BY DIVISION BY THE MAXIMA, * 0189600
    WHICH ARE ALSO PRINTED.
                                                                                     0189700
   WHICH ARE ALSO PRINTED.

U189700

IDIM IS THE VARIABLE DIMENSION FOR X.

IMAX IS THE NUMBER OF X VALUES.

XAXIS STORES THE NAME OF THE X-AXIS.

JDIM IS THE VARIABLE DIMENSION FOR Y.

JMAX IS THE NUMBER OF CURVES TO BE PLOTTED, (UP TO 10).

THE ARRAY YAXES(J) STORES THE NAMES OF THE CURVES.

THE ARRAY SYMBOL(J) STORES THE SINGLE CHARACTERS USED FOR PLOTTING. * 0190500
                                                                                     0190500
0190600
      DIMENSION X(IDIM), Y(JDIM, IDIM), YAXES(JDIM), SYMB L(JDIM),
                                                                                     0190700
     1 A(101), YMAX(10)
                                                                                     0190800
      DATA DOT, CROSS, BLANK/1H., 1H+, 1H /
                                                                                     0190900
C----SCALING X ARRAY TO THE RANGE 0 TO 50
                                                                                     0191000
      XMAX=1.E-30
                                                                                     0191100
       DO 1 I=1,IMAX
                                                                                     0191200
        IF(X(I).GT.XMAX) XMAX=X(I)
                                                                                     0191300
    1 CONTINUE
                                                                                     0191400
      DO 2 I=1, IMAX
X(I)=X(I)/XMAX*50.
                                                                                     0191500
                                                                                     0191600
        IF(X(I).LT.0.) X(I)=0.
                                                                                     0191700
    2 CONTINUE
                                                                                     0191800
C----SCALING Y ARRAY TO THE RANGE 0 TO 100
                                                                                     0191900
      DO 3 J=1, JMAX
                                                                                     0192000
```

```
0192100
      YMAX(J)=1.E-30
                                                                               0192200
      DO 4 I=1,IMAX
IF(Y(J,I).GT.YMAX(J)) YMAX(J)=Y(J,I)
                                                                               0192300
                                                                               0192400
    4 CONTINUE
      DO 3 I=1,IMAX
NO Y SCALING
Y(J,I)=Y(J,I)*100.0
                                                                               0192500
                                                                               0192600
C
                                                                               0192700
                                                                               0192800
      IF(LA.EQ.1) Y(J,I)=0.02*Y(J,I)
                                                                               0192900
       IF(Y(J,I).LT.0.) Y(J,I)=0.
                                                                               0193000
    3 CONTINUE
C----IDENTIFYING THE VARIOUS CURVES TO BE PLOTTED
                                                                               0193100
                                                                               0193200
      WRITE(6,103) XAXIS
                                                                               0193300
      WRITE(6,100) (YAXES(I), I=1, JMAX)
      WRITE(6,106) (SYMB L(I),I=1,JMAX) WRITE(6,102) (YMAX(I),I=1,JMAX)
                                                                               0193400
                                                                               0193500
                                                                               0193600
    DO 5 I=1,11
5 A(I)=0.1*
                                                                               0193700
      IF(LA .EQ. 1) WRITE(6,120)
IF(LA .EQ. 0) WRITE(6,115)
                                                                               0193800
                                                                               0193900
WRITE(6,101) (A(1),1=1,11)
C----MAIN LOOP. EACH PASS PRODUCES AN X-CONSTANT LINE.
                                                                               0194000
                                                                               0194100
                                                                               0194200
      DO 40 II=1,51
                                                                               0194300
      I = II
                                                                               0194400
      IF(I.EQ.1.OR.I.EQ.51) GO TO 32
GO TO 33
C----ALLOCATE . OR + AS MARKER ON THE Y-AXIS
                                                                               0194500
                                                                               0194600
   32 DO 30 K=1,101
                                                                               0194700
   30 A(K)=DOT
                                                                               0194800
                                                                               0194900
      DO 31 K=11,101,10
                                                                               0195000
   31 A(K)=CROSS
C-----ALLOCATE . OR + MARK ON THE X-AXIS, ALSO THE APPROPRIATE
                                                                               0195100
                                                                               0195200
                X VALUE
   33 A(1)=DOT
                                                                               0195300
                                                                               0195400
      A(101)=DOT
                                                                               0195500
      K=I-1
                                                                               0195600
   46 K=K-5
                                                                               0195700
      IF(K)48,47,46
                                                                               0195800
   47 A(1)=CROSS
                                                                               0195900
      A(101)=CROSS
                    (I-1)
                                                                               0196000
   48 XL=0.02*
0196100
                                                                               0196200
      DO 43 K=1,IMAX
IFIX=X(K)+1.5
                                                                               0196300
                                                                               0196400
      IF(IFIX-I)43,41,43
----LOCATE Y( X(I) )
                                                                               0196500
C----LOCATE
                                                                               0196600
   41 DO 44 J=1, JMAX
                                                                               0196700
      NY=Y(J,K)+1.5
                                                                               0196800
                                                                               0196900
      A(NY)=SYMB L(J)
                                                                               0197000
   44 CONTINUE
                                                                               0197100
      GO TO 42
   43 CONTINUE
                                                                               0197200
   -----PRINT X-CONSTANT LINE
                                                                               0197300
C--
                                                                               0197400
  42 CONTINUE
                                                                               0197500
      IF(LA.EQ.1) GO TO 51
                                                                               0197600
      WRITE(6,105) XL,(A(K),K=1,101),XL
      GO TO 52
                                                                               0197700
      WRITE(6,107) XL,(A(K),K=1,101),XL
                                                                               0197800
  51
                                                                               0197900
  52 CONTINUE
                                                                               0198000
C-----PUTTING BLANKS INTO X-CONSTANT LINE
```

```
DO 49 K=1,101
49 A(K)=BLANK
                                                                                                                                                     0198100
                                                                                                                                                     0198200
   40 CONTINUE
                                                                                                                                                     0198300
  DO 50 I=1,11
50 A(I)=.1*
                                                                                                                                                     0198400
                                   (I-1)
                                                                                                                                                     0198500
        WRITE(6,104)(A(I), I=1,11)
                                                                                                                                                     0198600
                                                                                                                                                     0198700
        WRITE(6,130)
                                                                                                                                                     0198800
         RETURN
RETURN

100 FORMAT(11H Y-AXES ARE,5X,10(1X,A10))

101 FORMAT(1H0,2X,11F10.1)

102 FORMAT(15H MAXIMUM VALUES, 10E11.3)

103 FORMAT(11H1X-AXIS IS,A3)

104 FORMAT(3X,11F10.1)

105 FORMAT(2H X,F6.2,3X,101A1,F6.2)

106 FORMAT(7H SYMBOL,11X,10(1X,A10))

107 FORMAT(/2H X,F6.2,3X,101A1,F6.2)

115 FORMAT(//,T50,'RADIAL POSITION R/D',/)

120 FORMAT(//,T50,'RADIAL POSITION 2R/D',/)

130 FORMAT(//,T45,'DIMENSIONLESS STREAMLING
                                                                                                                                                     0198900
                                                                                                                                                     0199000
                                                                                                                                                     0199100
                                                                                                                                                     0199200
                                                                                                                                                     0199300
                                                                                                                                                     0199400
                                                                                                                                                     0199500
                                                                                                                                                     0199600
                                                                                                                                                     0199700
                                                                                                                                                     0199800
                                                                                                                                                     0199900
 130 FORMAT(///, T45, 'DIMENSIONLESS STREAMLINE PLOT')
         RETURN
                                                                                                                                                     0200000
                                                                                                                                                     0200100
         END
                                                                                                                                                     0200600
                                      VELOCITY
                                       VELOCITY
                                                                                                                                                     0200700
                                   W VELOCITY
                                                                                                                                                     0200800
                                 PRESSURE
                                                                                                                                                     0200900
                           TEMPERATURE
                                                                                                                                                     0201000
                     TURBULENCE ENERGY
TURBULENCE DISSIPATION
VISCOSITY
                                                                                                                                                     0201100
                                                                                                                                                     0201200
                                                                                                                                                    0201300
    DIMENSIONLESS LENGTH SCALE
DIMENSIONLESS STREAM FUNCTION
RADIAL COORDINATE OF STREAMLINES
DIMENSIONLESS U VELOCITY
DIMENSIONLESS V VELOCITY
DIMENSIONLESS W VELOCITY
DIMENSIONLESS PRESSURE
                                                                                                                                                    0201400
                                                                                                                                                    0201500
                                                                                                                                                     0201600
                                                                                                                                                     0201700
                                                                                                                                                     0201800
                                                                                                                                                    0201900
                                                                                                                                                    0202000
    DIMENSIONLESS TURBULENCE ENERGY DIMENSIONLESS STREAMLINE COORDS DIMENSIONLESS EFF. VISCOSITY
                                                                                                                                                    0202100
                                                                                                                                                    0202200
                                                                                                                                                    0202300
```

1. Report No. NASA CR-3442  4. Title and Subtitle A COMPUTER CODE FOR SWIRLING TURBULENT AXISYM-METRIC RECIRCULATING FLOWS IN PRACTICAL ISOTHER-MAL COMBUSTOR GEOMETRIES  7. Author(s)
A COMPUTER CODE FOR SWIRLING TURBULENT AXISYM- METRIC RECIRCULATING FLOWS IN PRACTICAL ISOTHER- MAL COMBUSTOR GEOMETRIES  7. Author(s)  D. G. Lilley and D. L. Rhode  9. Performing Organization Name and Address Oklahoma State University School of Mechanical and Aerospace Engineering Stillwater, Oklahoma 74078  42. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  15. Supplementary Notes Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.
METRIC RECIRCULATING FLOWS IN PRACTICAL ISOTHER- MAL COMBUSTOR GEOMETRIES  7. Author(s)  D. G. Lilley and D. L. Rhode  9. Performing Organization Name and Address Oklahoma State University School of Mechanical and Aerospace Engineering Stillwater, Oklahoma 74078  42. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  15. Supplementary Notes Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.
MAL COMBUSTOR GEOMETRIES  7. Author(s)  D. G. Lilley and D. L. Rhode  9. Performing Organization Name and Address Oklahoma State University School of Mechanical and Aerospace Engineering Stillwater, Oklahoma 74078  42. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  15. Supplementary Notes Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.
D. G. Lilley and D. L. Rhode  9. Performing Organization Name and Address Oklahoma State University School of Mechanical and Aerospace Engineering Stillwater, Oklahoma 74078  42. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  15. Supplementary Notes Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.
D. G. Lilley and D. L. Rhode  9. Performing Organization Name and Address Oklahoma State University School of Mechanical and Aerospace Engineering Stillwater, Oklahoma 74078  11. Contract or Grant No. NAG 3-74  Stillwater, Oklahoma 74078  12. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  13. Type of Report and Period Cover 14. Sponsoring Agency Code 505-32-32  15. Supplementary Notes Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.  16. Abstract
Oklahoma State University School of Mechanical and Aerospace Engineering Stillwater, Oklahoma 74078  11. Contract or Grant No. NAG 3-74  12. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  13. Type of Report and Period Cover Contractor Report  14. Sponsoring Agency Code 505-32-32  15. Supplementary Notes Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.  16. Abstract
School of Mechanical and Aerospace Engineering Stillwater, Oklahoma 74078  13. Type of Report and Period Cover Contractor Report  14. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  15. Supplementary Notes Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.
Stillwater, Oklahoma 74078  13. Type of Report and Period Cover Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  14. Sponsoring Agency Code 505-32-32  15. Supplementary Notes Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.  16. Abstract
12. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington D. C. 20546  14. Sponsoring Agency Code 505-32-32  15. Supplementary Notes  Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.  16. Abstract
National Aeronautics and Space Administration  Washington D. C. 20546  14. Sponsoring Agency Code  505-32-32  15. Supplementary Notes  Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.  16. Abstract
National Aeronautics and Space Administration  Washington D. C. 20546  14. Sponsoring Agency Code 505-32-32  15. Supplementary Notes  Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.  16. Abstract
Washington D. C. 20546  15. Supplementary Notes  Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.  16. Abstract
Final report. Project Manager, Cecil J. Marek, Aerothermodynamics and Fuels Division, Lewis Research Center, Cleveland, Ohio 44135. The microfiche supplement at the back of report contains the output obtained for a sample computation.  16. Abstract
report contains the output obtained for a sample computation.  16. Abstract
A primitive pressure-velocity variable finite difference computer code has been developed to
l e- Lee-manner - Engagnes include
dict swirling recirculating inert turbulent flows in axisymmetric combustors in general, and
application to a specific idealized combustion chamber with sudden or gradual expansion. The
technique involves a staggered grid system for axial and radial velocities, a line relaxation p
cedure for efficient solution of the equations, a two-equation k-∈ turbulence model, a stairst
boundary representation of the expansion flow, and realistic accommodation of swirl effects.
report is a user's manual and deals with the computational problem, showing how the mather
report is a user's manual and dears with the computational program. A flow chi
ical basis and computational scheme may be translated into a computer program. A flow cha
Fortran 4 listing, notes about various subroutines and a user's guide are supplied as an aid t
prospective users of the code.
1
17. Key Words (Suggested by Author(s))  18. Distribution Statement
Computer program  Unclassified - unlimited
The North Congressed by Administration
Computer program  Unclassified - unlimited
Computer program Combustor  Unclassified - unlimited STAR Category 07
Computer program Combustor  Unclassified - unlimited STAR Category 07